



COUGAR DARTS

EC-A-AA-ENG

INSTALLATION AND OPERATION MANUAL

**COPYRIGHT 1989,1990,1991,1992
ALL RIGHTS RESERVED
VALLEY RECREATION PRODUCTS INC.
333 MORTON STREET
BAY CITY, MICHIGAN 48707 U.S.A.
P.O. BOX 656 PHONE: 517 892-4536**

TABLE OF CONTENTS

SMVO2

	PAGE
<i>Warranty</i>	
<i>Notice</i>	
Cougar SM Dart Game	
Game Specifications and Installation	1
Stability Assurance Kit	3
Game Features	6
Tru-Score II	7
Infrared Sensor	8
Dip Switches Information	9
Dip Switch Settings	10
Round Out Calculator	15
General Playing Instructions	16
Playing Instructions for Each Game	17
301/501 and Cricket Feats Readout	20
Bookkeeping	23
Self-Checking Software	29
Diagnostic Routines	31
Infrared Sensor Adjustment Procedure	33
Dart Sensor Adjustment Procedure	33
General Maintenance	34
Troubleshooting	35
Parts lists and Drawings	
Light Hood and Upper Display	43
Electronics Compartment.	44
Stationary Matrix Target Assembly	45
Replacement parts	46
Push Button Switches	47
System Diagram	48
Cables and Harnesses	49
Schematics and Diagrams	
Controller	50
Upper Display	51
Regulator Shroud	52
Power Supply, High Voltage	53
Power Supply, Low Voltage	54
Infrared Sensor	55
Matrix Interconnect	56

LIMITED WARRANTY

This product is warranted against manufacturer defects or failure of electronic components for a period of one (1) full year. Valley Recreation Products, Inc. will repair or replace any component, assembly or subassembly that fails during normal operation, free of charge, for a period of one (1) year. Any modification unauthorized by Valley Recreation Products, Inc. made to any part of this product will void all existing warranties. This warranty does not apply to damage resulting from misuse, abuse, neglect, improper installation or maintenance.

The foregoing warranty is exclusive and in lieu of all other warranties of merchantability, fitness for purpose and of any other type, whether expressed or implied. Valley Recreation Products, Inc. neither assumes nor authorizes anyone to assume for it any other obligation or liability in connection with said product and will not be liable for consequential damages.

Warranty service is available through your distributor.

Please fill in the appropriate information for easy reference.

SERIAL NUMBER:

(Found on the upper right side of the lower cabinet near the hinge)

NOTICE

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Changes or modifications not expressly approved by VALLEY RECREATION PRODUCTS, INC. for compliance could void the user's authority to operate the equipment.

This digital apparatus does not exceed the Class A limits for radio noise emissions from digital apparatus set out in the radio interference regulations of the Canadian Department of Communications.

Le présent appareil numérique n'émet pas de bruits radioélectriques dépassant les limites applicables aux appareils numériques de la Classe A prescrites dans le règlement sur le brouillage radioélectrique édicté par le ministère des Communications du Canada.


To ensure safety, modification to any part of this game is prohibited.

The keys to this game should not under any circumstances be left in the locks or be accessible in any way to unauthorized service personnel.

This TECHNICAL MANUAL is subject to change. Supplement will be available upon request.

GAME SPECIFICATIONS AND INSTALLATION

COUGAR SM DART GAME



GAME IN SHIPPED POSITION

GAME SPECIFICATIONS AND INSTALLATION

Specifications:

THIS GAME IS SUITABLE FOR INDOOR USE ONLY.

Height: 86" upright
Weight: 203 lbs

Width: 24"
Voltage: 120 Volts

Installation:

NOTE: To install this game, a working area of approximately 6' x 4' with a 90" ceiling clearance is needed. A ratchet with a 1/2" socket is recommended to secure the bolts to surface "B".

1. Unlock and open swing down door "A" to access the electronics compartment.
2. Remove the washers and bolts "C" from the plastic bag stapled inside the electronics compartment and set them aside within easy reach.
3. Slowly and carefully swing the upper section of the game upright **bracing the back until the game is securely fastened** (step 4).
4. Verify that the wires are not pinched. Replace the washers and bolts "C" in the inside top "B" of the electronics compartment and thread upward to secure the upper section of the game. **Tighten the bolts.**
5. This game is equipped with an easily replaceable power/line cord. The cord is located inside the pedestal when shipped and must be routed through the opening at the back of the game prior to operation. To do this, follow the instructions below, referring to the illustrations on page 2. Review FIG. 1 on page 2 before proceeding.
 - A. Open coin door.
 - B. Remove and retain the screw in upper corner of the line cord cover. See FIG. 2.
 - C. Turn line cord cover to expose opening. See FIG. 3.
 - D. Locate line cord (inside pedestal), and route plug end through opening. Push the entire length of the cord through the opening.
 - E. Return line cord cover to its original position making sure cord is inserted through slot in cover. Reinsert screw in upper corner and tighten.

NOTE: If the cabinet top must be folded down for any reason, the line cord must be placed back inside the pedestal.

6. Move the game to its selected location without tilting it more than 10°. Plug line cord into an appropriate outlet.

CAUTION

To ensure safety, it is recommended that the game be secured to the floor or to the wall with the Stability Assurance Kit provided according to the instructions on the following pages.

ILLUSTRATIONS FOR LINE CORD ROUTING INSTRUCTIONS

NOTE:
COIN DOOR NOT SHOWN




FIG. 1
3-D VIEW OF LINE CORD ROUTING




FIG. 2
FRONT VIEW OF LINE CORD COVER IN CLOSED POSITION





FIG. 3
FRONT VIEW OF LINE CORD COVER IN OPEN POSITION

GAME SPECIFICATIONS AND INSTALLATION

STABILITY ASSURANCE KIT

PARTS LIST



Eye bolt and chain fastened
with hex nut and screw




Machine Screw
#8-32x3/4"




Hex Nut
#8 - 3 2



Flat Washer
#10




Toggle Bolt
3/16x3"




Wire Eye Bolt



Wall Anchor
Expansion Shield
1/4x1-1/4"



Wood Eye Bolt




Lag Bolt, Hex
5/16 x 4.5"



Flat Washer
11/32" I.D.
11/16" O.D.



Floor Anchor
5/16x1-3/4"



Fender Washer


INSTALLATION INSTRUCTIONS

- TOOLS NEEDED:
- Measuring tape
 - Small screwdriver (Phillips and Flathead)
 - Pliers or crescent wrench
 - Drill with:
 - a 1/2" bit to secure the game to a hollow wall
 - a 1/2" masonry bit to secure the game to a concrete, brick, or stone wall.

ATTACHMENT OF THE CHAIN TO THE WALL:

Step 1: Fasten eye bolt and chain to the game.

- Screw the eye bolt with chain (D) into the insert on the upper back wall of the game.



GAME SPECIFICATIONS AND INSTALLATION


STABILITY ASSURANCE KIT

Step 2: Fasten to the wall according to the following instructions A, B, or C.


A. Hollow wall - plaster, drywall, etc.

1. With the game in the position where it will be played, mark a spot on the wall directly in line with the eye bolt and chain attachment on the back of the game.
2. Drill a 1/2" diameter hole at the marked spot.

3. Unscrew the wings from the toggle bolt (H).
4. Place a fender washer (R) on the toggle bolt.
5. Place the toggle bolt (H) through a loop in the chain a few inches from the end of the chain. The toggle bolt (H) may have to be threaded through the loop in the chain.
6. Slide a fender washer (R) on the toggle bolt (H) and screw the wings back on.



7. Push the toggle bolt (H) into the drilled hole in the wall.
8. Fasten the toggle bolt (H) tightly until the wings are snug against the back of the wall as shown. Keep the chain as taut as possible to minimize slack.




HOLLOW WALL WITH
1/2" Ø DRILL HOLE


B. Concrete, brick, stone wall

1. With the game in the position where it will be played, mark a spot on the wall directly in line with the eye bolt and chain attachment on the back of the game.
2. Drill a 1/2" diameter hole, 1-1/4" deep at the marked spot.

3. Pound the wall anchor (K) into the hole until it is flush with the wall surface.
4. Screw the eye bolt (J) into the wall anchor (K) until it is tight.



5. Thread the chain through the eye bolt and attach it to itself with the screw (E) and the two hex nuts (F) as shown. Keep the chain as taut as possible to minimize slack.



GAME SPECIFICATIONS AND INSTALLATION


STABILITY ASSURANCE KIT

C. Wood stud mounting

1. With the game in the position where it will be played, mark a spot on the wall directly in line with the eye bolt and chain attachment on the back of the game.

2. Screw the eye bolt into the stud at the marked spot.

3. Thread the chain through the eye bolt and attach it to itself with the screw (E) and the two hex nuts (F) as shown. Keep the chain as taut as possible to minimize slack.




ATTACHMENT TO THE FLOOR:


Fasten to the floor according to the following instructions A or B.

Concrete floor

1. Mark three spots on the floor according to the diagram.
2. Drill the three holes at the marked spots 1/2" diameter X 1-3/4" deep each.
3. Pound in the floor anchors (P).



4. Align the holes in the base of the game with the floor anchors (P).
5. Secure the game with the flat washers (N) and lag bolts (M).
6. Tighten the lag bolts until flush with the bottom of the counterbored holes in the base.



Wood floor

1. Position the game in its selected location.
2. Secure the game with the washers (N) and lag bolts (M).
3. Tighten the lag bolts (M) until flush with the bottom of the counterbored holes in the base.

NOTE: If desired, a 1/8" diameter pilot hole maybe used to start the lag bolt.

GAME FEATURES

- A. Tru-Score - Software system for correctly scoring darts.
- B. Tru-Score II - Detection of darts that miss scoring sectors of the target.
This is indicated by a short tone.
- C. Infrared Sensor - Detection of player's removal of darts from the target and the automatic change to the next player.
- D. Dart Catching Ring
- E. Dip Switch Selectable Features
- Accumulative/Non Accumulative Mode
 - Double Bull Selection
 - Attract-Sounds Disablement
 - Overhead Lamp Flashing during Win
 - Ten Round Limit
 - Cricket Round Limit
 - League Training Discounts
 - One-Dart-Out Calculator
 - Power Failure Recovery
 - Player Change Speed Up
- F. Diddle Time - Time allowed to practice or to establish position. (See the General Playing Instructions section in this manual.)
- G. Five Games - High Score, Shanghai, 301, 501, Cricket.
Five Options for 301/501 - Double In, Double Out, Double In/Double Out, Masters Out and League.
Two Options for Cricket - Cut Throat, League
- H. League Play - Permits 301, 501, Cricket or Cut-Throat team play.
- J. Handicap Round Features for 301/501 Play
- K. 301/501 and Cricket Feats Readout
- L. Dormant Time Out - Game will automatically reset after 30 minutes if no dart has been thrown.
- M. Bookkeeping - Allows the operator to set the price for each game and to keep record of games played and credits entered.


TRU-SCORE II

Your Valley Dart Game is equipped with an impact sensor to detect darts which miss the target area and bounce off the door or hit the dart catching ring; the darts which do not hit the scoring area of the target are indicated by a short tone.

By sensing all the darts which have been thrown, the game can then tell the player to remove the darts.

This feature is engaged or disengaged (locked out) using JU1 on the Controller Board.

This feature is factory adjusted and ready to use. If further adjustments are necessary, refer to the Dart Sensor Adjustment Procedure in this manual.



MISSED DART SENSING AREAS

-  DART CATCHING RING
-  TARGET DOOR SURFACE


INFRARED SENSOR

Your Valley Dart Game is equipped with an infrared sensor to detect the player removing darts at the end of his turn.

The infrared sensor is activated after the 3 darts have scored or hit the door and have been detected by the Tru-Score II Impact Sensor. The player does not have to push the Player Change button as the game senses the player removing the darts. The "Don't Throw Dart" lamp will light when the player's hand is detected by the infrared sensor. The game then automatically moves on to the next player's turn, a few seconds after the player has removed his darts and walked away. The "Throw Dart" lamp will light.

However, if all darts have not been counted, such as when a dart misses the game completely or when Tru-Score II is disengaged and some darts missed the target area, the Infrared Body Sensor is not active and it will be necessary to press the Player Change Button.


To adjust the infrared sensor sensitivity refer to the Infrared Sensor Adjustment Procedure in this manual.



INFRARED DETECTION AREA


DIP SWITCHES

TOP



ROCKER

TOP







SLIDE

Dip Switches allow the operator to choose mode selection and option selection. The dip switch packages (SW1, SW2, SW3) are located on the Controller board.

Presently there are two types of DIP switches found in our games (SEE ABOVE). The switch is open when the SLIDE bar is moved away from the "ON" position or when the ROCKER is depressed toward the bottom of the switch.

LEGEND FOR PAGES 10 - 14 DIP SWITCH SETTINGS

 = 
 ROCKER DIP SWITCH
 SIDE VIEW
 ROCKER POSITION
 (WHERE DEPRESSED)
 IS REPRESENTED BY
 SHADED AREA

 = 
 SLIDE DIP SWITCH
 SIDE VIEW
 ACTUAL POSITION
 OF SLIDE STYLE DIP SWITCH
 IS REPRESENTED BY
 SHADED AREA

DIP SWITCH SETTINGSSW1

DOES NOT ACCUMULATE CREDIT	ON →	1	ACCUMULATES CREDIT
ONE-DART-OUT CALCULATOR ACTIVE	→	2	ONE-DART-OUT CALCULATOR INACTIVE
ATTRACT-SOUNDS ENABLED	→	3	ATTRACT-SOUNDS DISABLED
DART ALARM	→	4	NO DART ALARM
POWER FAILURE RECOVERY	OPEN	5	NO POWER FAILURE RECOVERY
COUNTS EVERY DART	→	6	COUNTS 3 DARTS PER ROUND
STARTING POSITION CANNOT BE CHANGED	→	7	GAME STARTING POSITION OPTION
IR SENSOR DISENGAGED	→	8	IR SENSOR ENGAGED

SWITCH POSITION

- 1** Allows the selection of accumulative/non-accumulative mode.
CLOSED Allows the game to accumulate credit.



- OPEN** Does not allow the game to accumulate credit.
 NOTE: In the Non-accumulative mode, adding coins while game is in progress will reset the game.

- 2** **One-Dart-Out Calculator.**
CLOSED No single-dart-out segment calculation is displayed.



- OPEN** Displays the segment(s) to hit in order to win in 1 dart.

- 3** **Attract-sounds disablement.**
CLOSED Tones are disabled during attract mode.



- OPEN** Tones are enabled during attract mode.

DIP SWITCH SETTINGSSW1

- 4**
CLOSED **Warning if the game is used before money is deposited.**
No alarm whistle and the overhead lamp remains on.



- OPEN** Causes alarm whistle to sound and overhead lamp to go off when target is struck.
Overhead lamp remains off for 1 minute after last dart is thrown.

- 5**
CLOSED **Power Failure Recovery.**
Does not allow the game to resume after an interruption in power.



- OPEN** Allows the game to resume after an interruption in power.

- 6**
CLOSED **Allows the game to calculate the number of darts thrown.**
Automatically counts 3 darts per round except in handicap and winning rounds.



- OPEN** Counts only each dart which hits the target or is registered by the dart sensor.

- 7**
CLOSED **Option in the method of starting a game using the Player Change Button.**
The Player Change button can be used to start a game at a position other than one after the Remove Darts Time is over (5 seconds). (Ex. If player 1 missed the target, the game can start with player 2.)



- OPEN** The Player Change button can only be used to change the number of players in the SELECT mode until the first dart scores.

- 8**
CLOSED **Infrared Sensor feature.**
Infrared Sensor engaged.



- OPEN** Infrared Sensor disengaged.

DIP SWITCH SETTINGS SW2

301/501 GAME AS PROGRAMMED

OVERHEAD LAMP DOES NOT FLASH

HIGH SCORE 10 ROUNDS


CRICKET NO ROUND LIMIT

301/501 NO LIMIT

CRICKET 50 POINT SINGLE BULL

CRICKET DOUBLE BULL

DOUBLE BULL



1 CREDIT COST FOR ANY 301/501 GAME

OVERHEAD LAMP FLASHES

HIGH SCORE 7 ROUNDS

CRICKET ROUND LIMIT

301/501 ROUND LIMIT

CRICKET 25 POINT SINGLE BULL

CRICKET SINGLE BULL

SINGLE BULL

SWITCH POSITION

1
CLOSED



League Training Discount (regardless of programming)
301/501 game costs one credit.

OPEN 301/501 options cost as programmed.

2
CLOSED

**Overhead Lamp Option**

Overhead lamp flashes during WIN. (Not recommended for fluorescent light.)

OPEN Overhead lamp does not flash during WIN.






3
CLOSED

**High Score Round Limit.**

Allows a seven round limit.


OPEN Allows a ten round limit.

DIP SWITCH SETTINGS**SW2**

- 4**
CLOSED  **Cricket Round Limit.**
Determined by the Round-Out-Calculator (refer to page 15).
- OPEN** No limit.
- 5**
CLOSED  **301/501 Round Limit.**
Determined by the Round-Out-Calculator (refer to page 15).
- OPEN** No limit.
- 6**
CLOSED  **Cricket Single Scoring Bullseye.**
Only in effect when switch 7 is in closed (on) position.
Scores 25-point Bullseye.
- OPEN** Scores 50-point Bullseye.
- 7**
CLOSED  **Cricket Single/Double Bullseye Option.**
Scores Single Bullseye.
(Both sections score 1 mark and points according to SW2, position 6.)
- OPEN** Scores Double Bullseye. (Inner Bullseye = 2 marks and 50 points
Outer Bullseye = 1 mark and 25 points.)
- 8**
CLOSED  **Single/Double Bullseye option for all other games.**
Scores Single Bullseye.
- OPEN** Scores Double Bullseye.

DIP SWITCH SETTINGS**SW3**

TEAM LOSES WHEN PLAYER "FROZEN"
NORMAL TIME



PLAYER BUSTS WHEN "FROZEN"
SPEED UP TIME

1
CLOSED



Option for "frozen" Player reaching zero during League.

Player will bust when "frozen" and reaches "0" during League, but the game will continue.

OPEN

The team loses when one of its player is "frozen" and reaches "0" during League, and the game ends.

2
CLOSED



Option for shortened delay time between players.

Time between players reduced to 2 seconds following removal of body from the IR Beam.

OPEN

Time between players set at 3 seconds following removal of body from the IR Beam.

ROUND-OUT-CALCULATOR

The cost of a 301 game is considered the "base" price to determine the number of rounds of all the other games and options.

<u>GAME</u>	<u>ROUND OUT FORMULA</u>
HI-SCORE	7/10 DIP SWITCH SELECTABLE
SHANGHAI	7
301	12
301 DOUBLE IN OR DOUBLE OUT	$\frac{301 \text{ DOUBLE IN PRICE}}{301 \text{ PRICE}} \times 12$
301 DOUBLE IN/DOUBLE OUT	$\frac{301 \text{ DOUBLE OUT PRICE}}{301 \text{ PRICE}} \times 12$
301 MASTERS OUT	$\frac{301 \text{ MASTERS OUT PRICE}}{301 \text{ PRICE}} \times 12$
501	$\frac{501 \text{ PRICE}}{301 \text{ PRICE}} \times 12$
501 DOUBLE IN OR DOUBLE OUT	$\frac{501 \text{ DOUBLE IN PRICE}}{301 \text{ PRICE}} \times 12$
501 DOUBLE IN/DOUBLE OUT	$\frac{501 \text{ DOUBLE OUT PRICE}}{301 \text{ PRICE}} \times 12$
501 MASTERS OUT	$\frac{501 \text{ MASTERS OUT PRICE}}{301 \text{ PRICE}} \times 12$
CRICKET	$\frac{\text{CRICKET PRICE}}{301 \text{ PRICE}} \times 15$
CRICKET CUT-THROAT	$\frac{\text{CRICKET CUT-THROAT PRICE}}{301 \text{ PRICE}} \times 15$

[Example. If a 301 game costs 3 credits and a 301 Double In game costs 5 credits, the number of rounds is $5/3 = 1.67 \approx 2.00 \times 12 \text{ rounds} = 24 \text{ rounds.}$]

NOTES:

- Any fraction of price ratios will round out to the next integer.
- Price ratios of 4 or greater will result in unlimited rounds.
- 301 Double In will always be the same price as 301 Double Out, or vice versa. The same is true for 501 Double In or 501 Double Out.

GENERAL PLAYING INSTRUCTIONS

1. Insert at least one coin. Select game by pushing one of the flashing selection buttons. At this time, price per player will be displayed. The number of coins entered will be displayed in "TEMPORARY SCORE". Enter correct number of coins for each player.

DIDDLE TIME

After coining up and selecting a game, but before pushing the PLAYER CHANGE Button, there will be two minutes for players to "diddle" for position without setting off the "DART ALARM".

2. Press the "PLAYER CHANGE" button for the desired number of players if in the accumulative mode. In the non-accumulative mode the number of players is determined by the amount of credits; press the "PLAYER CHANGE" button once to display the players' scores.
3. Wait for the "THROW DARTS" to be displayed (about 5 seconds) before beginning to play. Any dart thrown before "THROW DARTS" is displayed will not receive a score.

To start the game:

- Throw the first dart, or
- Press the "LEAGUE" button to enter the Handicap Round (301/501 only), or
- Select a different game (the game selection can be changed by pressing the button of the desired game and then the "PLAYER CHANGE" button, or

if SW1 position 7 is closed:

- Press the "PLAYER CHANGE" button to start at a position other than one.
4. Each player throws 3 darts per round from the throw-line, 8' from the Shoot Darts Label on the base of the game.
 5. After 3 darts have been thrown the player can remove the darts. If the Infrared Sensor feature is **engaged**, the game will display "REMOVE DARTS" until the player moves away from the front of the game and will automatically change players.

NOTE: If the 3 darts have not been registered the player must press "PLAYER CHANGE" before removing the darts.

PLAYING INSTRUCTIONS FOR EACH GAME

HIGH SCORE

- Each player throws 3 darts per round.
- Highest score after 7 or 10 rounds of play wins.

SHANGHAI

- Player(s) begin by throwing 3 darts per turn.
- The object is to hit each sector with one dart in sequence beginning with sector #1 and working up to sector #20, and ending with the bullseye. The player with the highest score after 7 rounds or a "Shanghai" score wins the game.
- A "Shanghai" is an automatic win achieved by throwing 3 consecutive scoring darts consisting of a single, a double and a triple sector in any order.
[Ex. Player is shooting for 4, 5, 6 in round 4 of game.
Player hits the triple 4 sector, then single 5 sector, and double 6 sector:
that qualifies as a "Shanghai".]
- Game will prompt player for next sector at beginning of each round except 1st round, first play.

301

- Beginning with a score of 301, player(s) must score down to exactly "0". First player to reach "0" wins.
- Any points scored exceeding the point total needed to reach "0" for a win will result in a "Bust". Player loses turn and forfeits any remaining darts not thrown. Player's score will return to the original point total of round before "Bust".

501

- Same game as "301" except that the starting score is 501 points.

PLAYING INSTRUCTIONS FOR EACH GAME

301/501 OPTIONS

Double In:

- Player(s) must hit a double number an inner Bull's eye or a 50 point outer Bull's Eye to begin game play for each position. Player's score will remain at "301" until then.
Note: Darts thrown prior to the first scoring-throw will not receive credit.

Double Out:

- Player(s) must reach "0" exactly by scoring a double number, an inner Bull's eye or a 50 point outer Bull's eye . (A score of "1" will automatically bust player in this game.)

Double In/Double Out:

- This is a combination of the Double In game and the Double-Out game mentioned above.

Masters Out:

- This is played the same as Double Out, but the player can also go out by hitting a triple or a bull's eye.

LEAGUE

- Can only be chosen when there are enough credits to start a four player 301/501 game.
- Players 1 and 3 are Team "A". Players 2 and 4 are Team "B".
- The objective is for one player on a team to reach "0" ; the score of the other player on the team must be less or equal to the total score of the opposing team. A player will not be able to win the game if his partner's score is greater than the opposing team's **combined** score; this situation causes that player to be "frozen", i.e., if the partner's score is 50 and the opposing team players have 15 and 10 totalling 25 points. If a player is "frozen" and reaches "0", the game will cause this player to bust when DIP Switch SW3, position 1 is closed or the game will cause the team to lose when DIP Switch SW3, position 1 is open.

CRICKET

- Is played using segments 20, 19, 18, 17, 16, 15 and Bull's eye.
 The objective is to close out and to score in one of the usable numbered segments. A player can close out a numbered segment by throwing 3 darts or the equivalent of 3 darts into that particular number.
 [Ex. Before scoring can begin in #20, the player must throw 3 darts in the single, or 1 dart in the single and 1 dart in the double, or 1 dart in the triple #20.]
- The player to close out a numbered segment first can score on that segment until it is closed out by his opponent(s).
- The game ends when one player has closed out all segments from #20 through Bull's eye and has the highest score, or tied for it.

Cricket Cut-Throat

- For 2, 3 or 4 players.
- Is played the same as Cricket, except that the player with a "closed out" number adds to the opponent's score.
- Player that has "closed out" all the numbers and has the lowest points wins the game.

PLAYING INSTRUCTIONS FOR EACH GAME

CRICKET LEAGUE:

- Can only be chosen when there are enough credits to start a four player Cricket game.
- Players 1 and 3 are Team "A". Players 2 and 4 are Team "B".
- Before scoring can begin on a segment, **both** players on one team must have the number closed out. Scoring only occurs against the opposing team member(s) not having the segment closed out. [Ex. If Team B has #18 closed out and only Player 1 on Team A has #18 closed out, Team B can score until Player 3 closes out #18.]
- The game ends when both members on a team close out all segments 20-15 and Bull's eye and have the highest **combined** score.

CUT-THROAT LEAGUE:

- Is played the same as Cricket League except that the points scored are added to the score of the opposing team member(s) not having the segment closed.
- The team with the lowest **combined** score wins.

HANDICAP ROUND FEATURE

- "0" Round for handicapping players.
- Only handicapped player feats are tracked in "0" Round.
- Non-handicapped players are not affected in "0" Round.
- Handicap Round allows accurate scoring of darts thrown, feats and rounds for all players ; No player adjustments are necessary at game's end.

To enter Handicap Round "0":

1. Deposit coin.
2. Select 301/501, with/without options.
3. Deposit correct number of coins for game/options selected.
4. Push "PLAYER CHANGE" and wait for "THROW DART" light to come on.
5. Push "LEAGUE" button again to reach Round "0".
6. Using "PLAYER CHANGE" button, advance to handicap player(s) position to throw darts.
7. After Handicap Round, advance back to Player ONE for Round ONE and the start of match.

CAUTION - In Round "0" if a player is accidentally "skipped over", advancing back around to that player will put you into Round One.

FEATS READOUT


The feats will be displayed for a period of 6 seconds each.

The feats will continue to cycle for two minutes.

The display will then return to the ATTRACT mode display unless credits remain.

If credits remain or are added during feats readout, a new game may be started.

SAMPLE FEATS DISPLAY FOR WIN



301/501 FEATS READOUT

Feats will be displayed one minute after the game has ended. To display feats sooner, press "LEAGUE" button.

The feats that have been achieved will be displayed as follows:

<u>FEAT</u>	<u>AS SHOWN ON TEMPORARY DISPLAY</u>	<u>DESCRIPTION</u>
Points per Dart	PPD	Shows average points per dart for each player
WIN	LUIN	A win
6 th Dart out	bdo	A win in 6 darts

301/501 FEATS READOUT

7th Dart out

7do

A win in 7 darts

8th Dart out

8do

A win in 8 darts

9th Dart out

9do

A win in 9 darts

4th Round out

4EH

A win in the 4th round

Hat Trick

HAE

3 Bull's eyes in one turn

TON

ton

A score of 100 to 150
in one turn

High TON

Hten

A score of 151 or greater
in one turnTotal number of Darts
Thrown

tdt

See Dip Switch setting SW1,
Position 6.

NOTE: A "bust" situation will cancel any feat obtained in that player's round.
The Hat Trick can be accomplished on an inner or an outer Bull's eye.
When 100 points or more are accumulated in a Hat Trick, the Hat Trick
will be the only feat recorded.

CRICKET FEATS READOUT

Feats will be displayed automatically one minute after the game has ended. To display feats sooner, press "LEAGUE" button.

The feats that have been achieved will be displayed as follows:

<u>FEAT</u>	<u>AS SHOWN ON TEMPORARY DISPLAY</u>	<u>DESCRIPTION</u>
WIN	WUN	A win
9 Mark	9nn	9 marks in one round
8 Mark	8nn	8 marks in one round
7 Mark	7nn	7 marks in one round
6 Mark	6nn	6 marks in one round
5 Mark	5nn	5 marks in one round
White Horse	WUH	Marking 3 different unmarked triples in one round
Ton-Eighty	T80	Marking 3 triple 20s in one round
Hat Trick	HAE	Marking 3 Bull's eyes in one round

NOTE: Marking triples and marking bull's eyes indicate that the player is not closed out.

BOOKKEEPING

FEATURES

Bookkeeping is a programming device to set prices for each individual game as well as a system to keep record of games played and credits entered. Prices and records are retained in a battery backed up RAM. The validity of this RAM is tested every time the game is powered up. (See the Self-Checking Software section in this manual.)

Bookkeeping features two modes:

The Programming mode, displayed as "Prg", allows the operator to set the price for each game, including options, as well as to set the number of credits for the value of each coin slot.

The Bookkeeping mode, displayed as "StA" (for statistics), allows the operator to determine the amount spent for each game, the total number of credits entered in the left and the right coin slots and the total number of credits spent.

OPERATIONS

NOTE: It is necessary to enter a security code before either the bookkeeping mode or the programming mode may be used.

This security code will prevent an unauthorized person from changing any settings. Entering an invalid security code will cause the game to return to the attract mode.

You may change this 4-digit security code which is set at "0000" on a new game.

(The four zeros were entered by pressing Bull's Eye 4 times.)

For further information, see Bookkeeping Security Code section.

The following parts of the game are used to enter and change data:

ON THE CONTROLLER BOARD

- SW4: Press once to enter the TEST mode (tSt).
- SW5: (RESET) Press once to reset and exit from "StA" or "Prg".

TARGET:

- To enter any number, press the corresponding segment 1-20. Doubles and triples have the same value as singles.
- To enter zero, press Bull's eye.

BOOKKEEPING

PROGRAMMING MODE

This mode is used to change the price of games, the number of credits per coin, the language of the "CREDITS PER PLAYER" message, and the coin counter advances per coin. Once in the "Prg" mode, any of these areas may be altered without leaving and re-entering the "Prg" mode.

Getting in and out of the Programming Mode (Prg)

While in the ATTRACT mode or SELECT mode before the beginning of a game:

- Press SW4 to enter the TEST mode (tSt).
- Press the "LEAGUE" button **twice** to enter the Programming Mode "Prg".
- Enter the security code.
- If desired, change data. (See next page.)
- Press "PLAYER CHANGE" or reset SW5 to return to ATTRACT mode or SELECT mode.

Price Programming:

NOTE: Your game will come with the following factory setting for each game:

1 CREDIT	2 CREDITS	3 CREDITS
HIGH SCORE	301 DOUBLE IN	501 DOUBLE IN
SHANGHAI	301 DOUBLE OUT	501 DOUBLE OUT
301	301 DOUBLE IN/DOUBLE OUT	501 DOUBLE IN/DOUBLE OUT
	301 MASTERS OUT	501 MASTERS OUT
	501	
	CRICKET	
	CRICKET/CUT-THROAT	

To familiarize yourself with these settings, while in the "Prg" Mode press each game button. An amount will be displayed in "CREDITS PER PLAYER" for each game. Follow the steps on the next page to change any setting.

BOOKKEEPING

While in the "Prg" mode:

- Press the button of the game requiring a price change. The lamp for that game will light and the number of credits per player for that game will be displayed.
- Enter a new price by pressing the appropriate target segment.
- Store the selection by pressing the "LEAGUE" button.
- Press the button of the next game requiring a price change.

[Example: If you wish to program a 301 game with Double In and Double Out for 3 credits, press the 301, Double In, Double Out buttons. All three lamps will light. Now press the "3" on the target and press "LEAGUE" to store it.]

NOTE: The Double In and Double Out options, pertaining to the 301/501 games will automatically program to the same value.
(i.e. If you program a 301 Double In for 2 credits, 301 Double Out will automatically become 2 credits, and vice versa.)

Cash/Play Programming

This feature allows the operator to control the number of credits for the value of each coin. This feature is useful when coins with different values are used.

NOTE: Your game will come with a factory setting of:

1 QUARTER = 1 CREDIT = 1 COIN METER ADVANCE

As long as you wish to retain this credit programming, omit the cash/play instructions. If you elect to observe or change any portion of that credit programming use the following steps.

While in the "Prg" mode:

- Drop a coin into the right coin slot. The number of credits for that coin will be displayed.
- Change to the desired number of credits by pressing the appropriate target segment.
- Store this number by pressing the "LEAGUE" button.
- The number of credits will go out for a few seconds, then another number will be displayed. This number represents the advances of the coin counter for the coin in the right slot. It is suggested that the number of credits and the advance-number be the same, but they may be different to serve your purpose.
- Change the advance-number by pressing on the target to enter the advance-number desired.
- Press "LEAGUE" to store the new advance-number.
- Use the same procedure for the left coin slot.

BOOKKEEPING

Messages:

The message "CREDITS PER PLAYER" can be displayed in different languages.

NOTE: Your game will come with a factory setting in the English version.
 If you wish to retain the English version, omit the instructions below.
 If you elect to use another language (German, French, Italian or Spanish) follow the steps below.

While in the "Prg" mode:

- Press the "MASTERS OUT" button for the previously programmed message.
- Press again until the message in the desired language is displayed.
- Press the "LEAGUE" button to store the message or to exit the message programming routine.
- Press "PLAYER CHANGE" to exit the "Prg" mode.

Easy Factory Setting:

To return to one of the initial factory settings without having to reprogram all the game settings:

While in the 'Prg" mode:

- Press the "MASTERS OUT" button **once** for the programmed message currently used.
- Press the "MASTERS OUT" button **again** until the message in the desired language is displayed.
- **Press and hold** the "LEAGUE" button and **press** the "MASTERS OUT" button **simultaneously**.

The game will **beep** to signal that the initial factory settings have been programmed.

BOOKKEEPING MODE

This mode is used to keep track of the credits entered and the games played. Refer to the programming mode to alter the information displayed.

Getting in and out of the Bookkeeping Mode (StA)

While in the ATTRACT mode or the SELECT mode before the beginning of a game:

- Press SW4 once to enter the TEST mode (tSt).
- Press the "LEAGUE" button **once** to enter the Bookkeeping Mode "StA"
- Enter the security code.
- Obtain the desired statistics using the game and coin switches.
- Press "PLAYER CHANGE" or TEST button SW4 to exit.

BOOKKEEPING

- NOTE:** - When the TEST button SW4 is used to exit the bookkeeping mode all totals will be erased and the game will return to the TEST mode (tSt). Data in programming is not affected.
- If the RESET button SW5 is accidentally pressed or power is turned off, data will be retained and the game will return to the ATTRACT mode or the SELECT mode if credits were left over when bookkeeping was started.
- When the "PLAYER CHANGE" button is used to exit the bookkeeping mode all totals are retained and the game will return to the ATTRACT mode.

Coin Slot Totals

The information on credits will be displayed as follows:

```

t o t
L           "X"
r           "X"
```

The "L" and "r" represent the left and the right coin slots. The upper right digit following "L" represents the number of advances for the left coin slot. The lower right digit following "r" represents the number of advances for the right coin slot.

Game Totals

Press any game/option button to obtain information on games.

The information will be displayed as follows:

```

t o t
P           "X"
C           "X"
```

The upper right digit following "P" represents the number of players in the selected game. The lower right digit following "C" represents the number of credits spent for the game. [Example: P=4 and C=8 indicates that four players used two credits each.]

BOOKKEEPING

Other information displayed

While in the "StA" mode:

To return to coin totals:

- Press "MASTERS OUT" to obtain the number of credits passing through each coin slot.
- Press "LEAGUE" to obtain the combined total of credits for both the left and the right coin slots for all the games played after last reset.

To exit without clearing totals:

- Press "PLAYER CHANGE" button.

To exit clearing all totals to zero:

- Press "TEST" button, SW4.

SECURITY CODE

It is recommended that each operator change the security code from the factory setting to another numerical sequence to insure against any unauthorized access.

Changing the Security Code

1. Press the SW4 switch on the Controller board. "tSt" will appear in the "Temporary Score" display for TEST mode.
2. Press and hold the "PLAYER CHANGE" button while entering the OLD code via the target segments. "Ent" will appear in the "Temporary Score" display.
3. Release the "PLAYER CHANGE" button and enter the NEW code via the target segments. The 4 numbers of the new security code will appear one each in the players' display.
4. Press the "PLAYER CHANGE" button **once** to return to the TEST mode.
5. Press the "PLAYER CHANGE" button **twice** to return to the ATTRACT mode.

NOTE: If changing to a RAM chip that is not factory initialized, you will need to enter the security code and to follow the Bookkeeping Programming Mode procedures.

SELF-CHECKING SOFTWARE

The following self-checking tests are done automatically by the software used in our game.

1. **POWER-UP SWITCH TEST** - Used to check the ten (10) front panel switches.

If a switch is closed, the three (3) character identification will be displayed and a tone will sound (see next page for abbreviations).

2. **TARGET WATCHDOG** - Used to check target switches. If a segment is stuck closed, a "beep" tone will be heard and the problem segment number will be displayed on the "TEMPORARY SCORE".

NOTE: The lamps flash in addition to the signal stated above when a segment becomes stuck during the play of a game. Once the problem has been corrected the score will be given after a 3 second delay.

3. **POWER-UP RAM TEST** - Used to test RAM for valid data on power-up.

If a problem with the data is found, the RAM will be reprogrammed with factory settings and the credit message will be blanked. If this condition occurs it is recommended to replace the RAM.

DIAGNOSTIC ROUTINES

Each game has built-in diagnostic software. The scope of this software is to test the electronic hardware, to verify that the game is functioning properly, and to indicate problem areas.

There are two push button switches located on the Controller board inside the electronics compartment:

SW 5 - right hand switch is a RESET button. Pressing this switch resets the game.

SW 4 - left hand switch is the TEST button. Pressing this switch puts the game in self-diagnostic mode.

To enter into the TEST mode (**tSt**), press the test switch. The "TEMPORARY SCORE" display will read:

tSt

To exit the TEST mode (**tSt**), press the "PLAYER CHANGE" button. The game may now be used as normal.

The following **nine tests** may be used while in the TEST mode (**tSt**).

Test One - Push Button Switch Test

Press test switch SW4 once to enter the TEST mode and press it again to activate this test.

NOTE: The game must first be in the TEST mode (**tSt**).

Displays will be blank until the first switch is pressed. This test will check the operation of all the front panel switches. As each switch is pressed, the "Temporary Score" will display three (3) characters to identify it.

DIAGNOSTIC ROUTINES

The characters displayed for each switch are as follows:

HIS

(HIGH SCORE SWITCH)

SHI

(SHANGHAI SWITCH)

301

(301 SWITCH)

501

(501 SWITCH)

CrI

(CRICKET SWITCH)

dIn

(DOUBLE IN SWITCH)

dOt

(DOUBLE OUT SWITCH)

nno

(MASTERS OUT SWITCH)

LEA

(LEAGUE SWITCH)

PLC

(PLAYER CHANGE SWITCH)

To exit this test press the TEST switch and return to the TEST mode (tSt).

DIAGNOSTIC ROUTINES

Test Two - 7-Segment Display Test

To activate press the "HIGH SCORE" button. Each display will show 0-9. After all segments have been checked this test will automatically return to the test mode.

To interrupt this test press the "HIGH SCORE" button.

Test Three - Audio Test

To activate press the "SHANGHAI" button. This will generate a tone to check and to adjust the volume of the audio circuit. The volume adjustment is located on the Controller board in the very upper right corner at location R33.

To exit this test press the "SHANGHAI" button.

Test Four - Target Segment Test

To activate press the "301" button. The "TEMPORARY SCORE" display will be blank. This test is used to check that each segment of the target will register darts thrown at it. As each segment is depressed, its value or designation will be displayed on the "TEMPORARY SCORE" display. A double or triple will be shown as a "d" or "t" preceding the number of the segment [Ex. A double 20 will be displayed as d20].

In addition to the temporary score, player's 1-3 score digits show the status of DIP switches 1-3 respectively. The status is shown as a hexadecimal number.

To exit this test press the "301" button.

In the TEST mode (tSt) to mark the difference

6 =  b = 

Test Five - Lamp Test

To activate press the "501" button. Each lamp will light individually in the following order: Remove Darts, Throw Darts, Logo, Player Change, each game selection button from left to right and the overhead light.

After each lamp has been checked, this test will automatically return to the TEST mode.

Test Six - Cricket Display Test

To activate this test press the "CRICKET" button. The LEDs will light starting with Player 1 - 20 through Bull, Player 2 - 20 through Bull, Player 3 - 20 through Bull, and finally Player 4 - 20 through Bull. This will be followed by Cricket backlighting lamps in the same order, each of the four-Player lamps and all the LEDs in the Dart Indicators.

It is possible to skip from one phase of the test to the next phase of the test by pressing the "CRICKET" button. For example it is possible to go into the Cricket backlighting lamps test before the end of the Players LEDs test.

Test Seven - Burn-In Test

To activate this test press the "DOUBLE IN" button. This test is a production burn-in test used to cycle on and off all the lamps and LEDs and their associated circuitry.

Press and hold the "DOUBLE IN" button. All lamps will light.

Press the "DOUBLE IN" button **again**: all lamps will turn off, all LEDs will light.

Press the "DOUBLE IN" button **once again** to return to TEST mode.

DIAGNOSTIC ROUTINES

NOTICE: For Tests Eight and Nine to function properly be sure that the jumpers are in the correct position to enable the circuitry. To accomplish Tests Eight and Nine, other portions of the circuitry must be functioning properly. We suggest that Test Three and Test Five be completed before attempting these tests.

Your game is shipped to you with the Tru-Score II (Dart Sensor) and Infrared Sensor Features engaged.

The **Dart Sensor Feature selection jumper** is located below SW4 on the Controller board at location JU1. To disengage it, move the jumper clip to the right covering the middle and right pins.

To disengage the **Infrared Sensor Feature** open Position 8 of DIP Switch 1.

NOTE: Always disengage the Dart Sensor feature at the jumper clip and the Infrared Sensor feature at the DIP Switch, **NOT** by unplugging the cords or ribbon cable because that **WILL NOT** fully disengage the circuits.

Test Eight - IR Sensor Test

To activate this test press the "DOUBLE OUT" button. At this time the "LOGO" lamp will light signifying the test is active.

To test the IR Sensor, stand in front of the game at arms length. The "THROW DARTS" lamp should be lit. Move your hand slowly upward towards the target. As your hand enters the IR sensor detection area (a couple-inches below the lower part of the dart catching ring), the "THROW DARTS" lamp should go out and the "REMOVE DARTS" lamp should light. Remove your hand and ensure that the "REMOVE DARTS" lamp goes out and the "THROW DARTS" lamp lights. If adjustments are necessary, refer to the Infrared Sensor Adjustment Procedure on the following page.

To exit this test press the "DOUBLE OUT" button.

Test Nine - Dart Sensor Test

To activate this test press the "MASTERS OUT" button. The "LOGO" lamp will flash signifying the test is active. To test the dart sensor and its circuitry, tap the front panel and listen for an audible "Beep" from the speaker. The "REMOVE DARTS" lamp will flash as the "Beep" is sounded.

If no "Beep" is heard, an increase to the sensitivity may alleviate the problem.

The sensitivity adjustment is located at R17 on the controller card, just to the left of the two RCA plugs. (See Dart Sensor Adjustment Procedure.)

To exit this test press the "MASTERS OUT" button.

The "LEAGUE" button is reserved for entering Bookkeeping and Programming modes.
(See the Bookkeeping section.)

This concludes the Diagnostic routines.

Press the "RESET" button on the CPU Board or the "PLAYER CHANGE" Button to return to the ATTRACT mode.

INFRARED SENSOR ADJUSTMENT PROCEDURE

To adjust the IR Sensor sensitivity:

- Put the game in the TEST mode (tSt) by pressing SW4 on the Controller board and the "DOUBLE OUT" button.
- Access the potentiometer through the hole on the right side of the IR sensor housing with a small blade screwdriver. The sensitivity is decreased by turning the screwdriver in a clockwise direction and is increased by turning in a counter-clockwise direction.

NOTE: The following steps should be performed without darts in the target or dart catching ring and while standing to the side of the game. Also make sure the target door is in place.

- 1) Turn the potentiometer back and forth to find the sensitivity threshold point of the sensor. This is the point at which the "THROW DARTS" lamp turns off and the "DON'T THROW DARTS" lamp come on.
- 2) Slowly turn the potentiometer clockwise until the "THROW DARTS" lamp comes on.
- 3) Verify the adjustment:
 - Stand in front of the game at arms length from the target. Starting at the logo below the target, move your hand upward towards the IR Sensor. The threshold point should be at a level where the hand passes between the dart catching ring and the bottom of the door.
- 4) Repeat steps 1 through 3 until the IR sensor is properly adjusted.

DART SENSOR ADJUSTMENT PROCEDURE

NOTE: Set up and test should be done on site.

- Put the game in the TEST mode (tSt) by pressing SW4 on the Controller board and the "MASTERS OUT" switch. The center lamp on the door will be flashing.
- Start with the lowest sensitivity setting on the potentiometer, R17 on the Controller board, full clockwise to 7 o'clock.
- Turn the potentiometer, R17, up to 6 o'clock setting.
- Throw bar darts at all areas on the door. (Bar darts have the lightest weight.) Dart detection is indicated by a short tone and "Remove Darts" lamp will flash on, then off.
- Repeat this procedure, by using small increments when turning up the potentiometer, R17, counter clockwise until all darts thrown with reasonable force at the door are detected by the microphones.

CAUTION: DO NOT OVERSENSITIZE!

Loud music will cause oversensitivity of Dart Sensor to deduct darts. When properly adjusted, however, the Dart Sensor can operate up to 110 decibels sound level.

FINAL NOTE: If you choose to disengage the Dart Sensor, LEAVE THE DART SENSOR PLUGGED IN and disengage the circuit by moving JU1 to the LOCKOUT position. If this method of eliminating this feature is not followed, potential problems for game performance exist.

GENERAL MAINTENANCE

To replace Lamps in the Upper Display:

- Turn the game off and unplug from the wall outlet.
- Tools needed:
 - #1 Phillips screwdriver
 - #2 Phillips screwdriver
- Remove the four corner screws holding the Shroud and Display sub-assembly.
- Slowly pull the Shroud and Display sub-assembly and turn it over.
- Remove the quick-disconnect tab to disconnect the ground wire.
- Disconnect the in-line power connector and the ribbon cable
- Remove the four screws holding the marquee.
- Replace lamps as necessary.

CAUTION:

- Make sure the ground wire is reconnected.
- Make sure the wires are tucked under the channel cover when replacing the Shroud and Display sub-assembly.

To remove debris and tips from the target:

- Turn the game off and unplug from the wall outlet.
- Open the lock on the Cabinet Top Dart Door.
- Remove the door.
- Flip down the right and left latches in the upper corners of the Spider DCR Board.
- Carefully lower the Spider DCR Board and remove debris and tips.

TROUBLE SHOOTING

This troubleshooting section provides quick solutions to game problems and guides the more experienced technician in pinpointing possible trouble areas.

This section is not intended to be a service guide.

GENERAL SYMPTOMS	POSSIBLE CAUSE/SOLUTION
GAME APPEARS DEAD	<ul style="list-style-type: none"> • Game unplugged • Main power switch off • Power cord not fully connected to the power supply • Fuses blown. F1, F2 on High Voltage Board. F5, F6 on Low Voltage Board.
UPPER DISPLAY DEAD OR GARBLED	<ul style="list-style-type: none"> • Check power cable from display. • Refer to other symptoms in the Upper Display section.
GAME CONTINUALLY BEEPING AND LIGHTS FLASHING	<ul style="list-style-type: none"> • Segment jammed. (Temporary Score shows the segment number) <ul style="list-style-type: none"> - Push on segment to release. • Dart tip stuck in/or between segments. <ul style="list-style-type: none"> - Lower DCR board and inspect for debris or tips.
GAME CONTINUALLY BEEPING, NO LIGHTS FLASHING	<ul style="list-style-type: none"> • Stuck game switch. (Temporary Score indicates which switch) <ul style="list-style-type: none"> - Inspect switch for jamming. - If switch is good swap Controller board.
OVERHEAD LAMP OUT	<ul style="list-style-type: none"> • Check fluorescent lamp and starter. • Plug in light fixture to power supply. • Make sure connections correspond to High Voltage power supply. • Swap High Voltage Power Supply board. • Swap Controller board.
OVERHEAD LAMP NOT GOING OUT	<ul style="list-style-type: none"> • Dip switch setting SW2, position 2 • High Voltage Power Supply board Q1, U1. • Controller Board U6, U5.

TROUBLE SHOOTING

GENERAL SYMPTOMS	POSSIBLE CAUSE/SOLUTION
THROW/DON'T THROW PANEL LAMPS OUT	<ul style="list-style-type: none"> • Check bulbs (Refer to parts list for proper replacement.) • Controller board connection J3, IC'S U3, U5, U6, U7, U8, U9, Q4, Q5. <p>QUICK FIX: Swap Controller Board.</p>
GAME SWITCH LAMPS NOT LIGHTING	<ul style="list-style-type: none"> • Light bulb blown. (See parts list for proper replacement.) • Controller board connectors J1 or J2, ICs U2, U3, U4, U8, U9 OR U10. <p>See schematic for driver display associated with lamp in question.</p> <p>QUICK FIX: Swap Controller board.</p>
WHEN TURNED ON, GAME DISPLAYS SCORES FROM LAST GAME PLAYED	<ul style="list-style-type: none"> • Hit necessary segments to end game. • Power failure recovery option. <ul style="list-style-type: none"> - See dip switch setting for power failure recovery.
GAME LOCKING UP (NO RESPONSE FROM COIN GAME SWITCHES OR TARGET, OR GAME RESETTING AT RANDOM	<ul style="list-style-type: none"> • Grounding problem <ul style="list-style-type: none"> - Make sure game is plugged in a three-wire outlet (earth ground). - Make sure ground wire from coin mechanism frame is securely fastened to the power supply chassis. - Check connections from transformer to power supply boards. - Check power supply harness connections for a clean tight fit. - Check tightness of hardware. - Make sure the socket connections on the Controller board are clean and tight. <p>QUICK FIX: Swap Controller board.</p> <p>(See "Upper Display" in this troubleshooting section.)</p>
GAME LOCKING UP AFTER FIRST THREE DARTS	<ul style="list-style-type: none"> • Check IR Sensor calibration. <p>(Refer to Test Eight in the Diagnostic routines in the manual.)</p>

TROUBLE SHOOTING

GENERAL SYMPTOMS	POSSIBLE CAUSE/SOLUTION
WILL NOT RESUME GAME LOST IN PROGRESS AFTER POWER FAILURE	<ul style="list-style-type: none"> • Power failure recovery disengaged • Check dip switch setting • Check RAM U16. Re-enter security code (see "Security Code" in Book-keeping section in manual and reprogram RAM or install a pre-programmed factory RAM.
GAME FEATURES NOT WORKING	<ul style="list-style-type: none"> • Software related. <ul style="list-style-type: none"> - Check EPROM for correct version (number listed under "Table of Contents" in the manual. - Refer to "Dip Switch Settings" section in the manual.
DIP SWITCH FEATURES NOT WORKING	<ul style="list-style-type: none"> • Debris in Dip Switch, bad connection. • Dip Switch settings <ul style="list-style-type: none"> - Refer to "Dip Switch Settings" section in manual. QUICK FIX: Swap Controller Board.
NOT READING GAME SWITCHES	<ul style="list-style-type: none"> • Check corresponding switch for closure. • Controller connectors J1 or J2, ICs U1 or U4. • Check if switch mechanism is snug in plastic housing. QUICK FIX: Swap Controller board.
301 AND/OR CRICKET GAME ENDING BEFORE FINISHED	<ul style="list-style-type: none"> • 301 round limits enabled. <ul style="list-style-type: none"> - Disable positions 4, 5 on SW2. (See "Dip Switch Settings" section in the manual.)
TARGET SYMPTOMS	POSSIBLE CAUSE/SOLUTION
GAME NOT DEDUCTING NON-SCORING DARTS	<ul style="list-style-type: none"> • Dart Sensor circuit disabled. <ul style="list-style-type: none"> - Move Ju1 off lockout. • Verify connections to Matrix Interconnect board J3, J4. • Sensivity set too low. <ul style="list-style-type: none"> - Refer to "Dart Sensor Adjustment Procedure" in the manual. • Controller board IC U21 • Target door not tight against the target.

TROUBLE SHOOTING

TARGET SYMPTOMS	POSSIBLE CAUSE/SOLUTION
GAME DEDUCTING DARTS ERRATICALLY	<ul style="list-style-type: none"> • Sensitivity too high. <ul style="list-style-type: none"> - Refer to the "Dart Sensor Adjustment Procedure" in the manual. • Music or other noise is causing a malfunction. <ul style="list-style-type: none"> - Refer to the "Dart Sensor Adjustment Procedure" in the manual.
TARGET "DEAD" DURING GAME AND TEST MODE (TEST 4 -DIAGNOSTIC ROUTINES) NOTE: THE TERM "DEAD" IS USED WHEN TARGET SEGMENT DOES NOT REGISTER DARTS THROWN AT IT.	<ul style="list-style-type: none"> • Target unplugged at J1 or J2 of Matrix Interconnect board. • Check Controller board U9, U10, U11.
TARGET "DEAD" DURING GAME ONLY	<ul style="list-style-type: none"> • Dart Sensor circuitry malfunction <ul style="list-style-type: none"> - Disable dart sensor circuitry by putting JU1 on the Controller board in the lock out position. - Check U14 on the Controller board. - Check dart sensor connections.
ONE OR MORE QUADRANTS NOT SCORING (SEE TABLE NEXT PAGE)	<ul style="list-style-type: none"> • Check Matrix Switch and connections. • Controller board U11, U9, U10.
FOUR RELATED SEGMENTS OF TARGET NOT SCORING (SEE TABLE NEXT PAGE)	<ul style="list-style-type: none"> • Check Matrix Switch and connections. • Check Controller board U9, U10, U20.
ONE SEGMENT, OR SEVERAL UNRELATED SEGMENTS NOT SCORING	<ul style="list-style-type: none"> • Bad physical contact between target segment and Matrix Switch. <ul style="list-style-type: none"> - Check for short on Matrix Interconnect board. • Bad switch pad.
BULLSEYE NOT SCORING CORRECT AMOUNT OF POINTS	<ul style="list-style-type: none"> • Dip Switch setting. <ul style="list-style-type: none"> - Check positions 6, 7, 8 on SW2. (See "Dip Switch Settings" section in manual.)

TROUBLE SHOOTING

TARGET QUADRANTS

THERE ARE FOUR QUADRANTS DETERMINED BY THE STROBE LINES:

QUADRANT 1	PIN 19	2, 15, 10, 6, 13, BE
QUADRANT 2	PIN 20	4, 18, 1, 20, 5
QUADRANT 3	PIN 2	16, 7, 19, 3, 17, DBE
QUADRANT 4	PIN 1	12, 9, 14, 11, 8

RELATED SEGMENTS IN GROUPS OF FOUR.

d2	2	d15	d10	10	d6	6	d13
d4	4	d18	d1	1	d20	20	d5
d16	16	d7	d19	19	d3	3	d17
d12	12	d9	d14	14	d11	11	d8

8	DBE	T12	T9	T14	T11	T8
17	BE	T16	T7	T19	T3	T17
13		T2	T15	T10	T6	T13
5		T4	T19	T1	T20	T5

UPPER DISPLAY SYMPTOMS	POSSIBLE CAUSE/SOLUTION
DISPLAYS GARBLED, RANDOM LAMPS, NO COIN ACCEPTANCE TONE	<ul style="list-style-type: none"> Controller board U12 or U15. QUICK FIX: Swap Controller board.
DISPLAYS GARBLED BUT COIN ACCEPTANCE TONE OK	<ul style="list-style-type: none"> Controller board J11, U24. Check tightness of hardware Check shroud regulator voltages (+5V, +3V DC). QUICK FIX: Swap Shroud assembly or Display board.
COIN MECHANISM CREDITS	POSSIBLE CAUSE/SOLUTION
GAME FUNCTIONING BUT NOT GIVING CREDIT	<ul style="list-style-type: none"> Coin cable harness. Controller board J14, U18. Coin switches not programmed. <ul style="list-style-type: none"> - Refer to "Cash/Play Programming" in Bookkeeping section in the manual.
GAME NOT ACCUMULATING CREDITS OR APPEARS TO BE LOSING CREDITS	<ul style="list-style-type: none"> Dip Switch setting. <ul style="list-style-type: none"> - Check position 1 on SW1. (See "Dip Switch Settings" section in the manual.)

TROUBLE SHOOTING

AUTOMATIC PLAYER CHANGE	POSSIBLE CAUSE/SOLUTION
GAME NOT CHANGING PLAYERS AUTOMATICALLY	<ul style="list-style-type: none"> • IR sensor's sensitivity set too low and not seeing the removal of darts. <ul style="list-style-type: none"> - Re-calibrate IR sensor. (Refer to Test Eight in the Diagnostic Routines section in the manual.) - Check Dip Switch for IR sensor - Check Cable at J12 on Controller board.
GAME CHANGING PLAYERS, BUT NOT SWITCHING TO "THROW DARTS"	<ul style="list-style-type: none"> • Dart still in the target. • IR sensor's sensitivity set too high. <ul style="list-style-type: none"> - Re-calibrate IR sensor. (Refer to Test Eight in the Diagnostic Routines section in the manual.)
GAME CHANGING PLAYERS ERRATICALLY	<ul style="list-style-type: none"> • IR sensor's sensitivity is set on threshold point. <ul style="list-style-type: none"> - Re-calibrate the IR sensor. (Refer to Test Eight in the Diagnostic Routines section in the manual.)
SOUND SYMPTOMS	POSSIBLE CAUSE/SOLUTION
NO SOUND	<ul style="list-style-type: none"> • Volume down. <ul style="list-style-type: none"> - Turn pot R33 (CW) • Speaker harness unplugged. <ul style="list-style-type: none"> - Check J6 on the Controller board. - Check Controller board Q6 or ICs U28, U12, U7. <p>QUICK FIX: Swap Controller board.</p>
GAME CONTINUALLY BEEPING AND LIGHTS FLASHING/NOT FLASHING	<ul style="list-style-type: none"> • Refer to general symptoms section.
GARBLED SOUND	<ul style="list-style-type: none"> • Speaker. • Controller board ICs U28 or Q6.
CONSTANT HUMMING SOUND	<ul style="list-style-type: none"> • Grounding problem. <ul style="list-style-type: none"> - Refer to game locking up or resetting at random. • Check Controller board U28, Q6. <p>QUICK FIX: Swap Controller board. Swap Power supply.</p>


TROUBLESHOOTING

BOOKKEEPING-CASH/PLAY	POSSIBLE CAUSE/SOLUTION
CREDITS PER GAME NOT MATCHING FACTORY SETTING	<ul style="list-style-type: none"> • RAM programmed improperly <ul style="list-style-type: none"> - Refer to "Programming Mode" in "Bookkeeping" section in the manual.
CREDITS PER PLAYER MESSAGE NOT IN PROPER LANGUAGE	<ul style="list-style-type: none"> • Programmed incorrectly. <ul style="list-style-type: none"> - Refer to "Messages" in the "Bookkeeping" section in the manual.
TOTALS ARE NOT STORED FOR EACH GAME	<ul style="list-style-type: none"> • RAM not initialized. <ul style="list-style-type: none"> - Refer to "Changing Security Code" in "Bookkeeping" section in the manual. • Change RAM, U16 <ul style="list-style-type: none"> - Re-enter security code (see "Security Code" in the "Bookkeeping" section in the manual and reprogram the RAM or install a pre-programmed factory RAM.
GAME RETURNING TO ATTRACT MODE WHEN SECURITY CODE IS ENTERED	<ul style="list-style-type: none"> • Invalid security code. <ul style="list-style-type: none"> - Enter 4 bullseyes <ul style="list-style-type: none"> If successful, check cash/play programming and enter a new security code. If unccessful, change RAM to a factory initialized RAM. (Refer to "Security Code" in the "Bookkeeping" section in the manual.
" CREDITS PER PLAYER" MESSAGE BLANK	<ul style="list-style-type: none"> • Problem with the battery baccked-up RAM not retaining data. <ul style="list-style-type: none"> - Replace with a factory initialized RAM.

PARTS LISTS


SCHEMATICS

DIAGRAMS



LIGHT HOOD AND UPPER DISPLAY ASSEMBLIES PARTS LIST

1	G72	Light Fixture, Fluorescent
2	206-0275	Channel Cover
3	201-1001	Sheet Metal Screw #8x1/2", Pan Head, Phillips
4	R03	IR sensor Enclosure Assembly
5	A55	PCB Assembly, IR Sensor
6	205-0363	PCB Mount, adhesive backed
7	203-1001	KEP Nut #4x40
8	206-1064	Standoff 4-40x1/2"
9	A60	PCB Assembly, Upper Display with Cricket
10	206-0253	Standoff 4-40x3/8"
11	ADF-0-02-01	Marquee with Cricket
12	201-0114	Machine Screw #4-40x3/8", Pan, Phillips, Black Oxide
13	201-0099	Machine Screw #8-32x1-1/2, Pan, Phillips, Black Oxide
14	205-0492	Spacer, Nylon, 3/16 round, 1/2"
15	201-0018	Machine Screw, #4-40x3/4", Pan, Phillips, Zinc



ELECTRONICS COMPARTMENT PARTS LIST

20	A73	PCB Assembly, Controller
21	A56	Matrix Interconnect Board
22	217-0273	Piezo film, with female connector
23	M84	Panel Lamps Assembly
24	201-1014	Machine Screw #10-32x3/4"
25	204-1003	Washer #10
26	H09	Power Supply, universal
27	G73	Speaker Assembly
28	201-1052	Machine Screw #8-32x3/8"

STATIONARY MATRIX TARGET ASSEMBLY PARTS LIST


31	206-0274	Dart Door Finger
32	205-1022	Segment, Dart Catching Ring, American
33	201-0111	Adjustment Screw 1/4-20x1-9/32" coated
34	206-0279	Latch, Matrix Switch
35	ADF-0-03-01	Cabinet Top American Spider DCR Mounting Board Assembly
	Q51	Target Assembly, T-R SM American (Kit N73)
36	205-1222	Spider, American, White, Thin-Ribbed
37	Q28	Segment Set, 4 Pieces, Thin-Ribbed, American, Red
38	Q29	Segment Set, 4 Pieces, Thin-Ribbed, American, Blue
39	205-1221	Inner Bullseye, Red
40	205-0340	Outer Bullseye, Blue, American
41	ADB-0-04-01	Cabinet Top Matrix Switch Mounting Board Assembly
42	206-0272	Hinge, SM Target
43	204-1003	Washer #10
44	201-1046	Machine Screw #8-32x1/2", Pan, Phillips, Zinc Plated
45	204-1017	Lock washer #8, Internal tooth
	Q52	Matrix Switch Assembly, T-R SM American (Kit N65)
46	227-0003	Matrix Switch, American, Thin-Ribbed
47	207-0048	Rubber Sheet, American, Thin-Ribbed
48	212-0023	Lock
49	206-0008	Anchor Plate
50	ADF-0-01-01	Cabinet Top Valley Dart Door Assembly

REPLACEMENT PARTS LIST

A56	Matrix Interconnect PCB Assembly, SM
A73	Controller PCB Assembly
EF1	Power Harness, SM
EF5	IR Sensor Ribbon Cable, SM
EF6	Matrix Interconnect Ribbon Cable
EF7	Upper Display Power Harness, SM
G72	Light Fixture, Fluorescent, SM
G73	Speaker Assembly, SM
J23	Shroud and Display Sub-assembly, SM
N65	Matrix Switch, American, T-R, SM
N73	Target, American, T-R, SM

LAMPS: Replace only with same type and rating.

WEDGE BASE
14V, 80 mA, Type 658
Valley Part#223-1006-0
(Game Switches)



BAYONET
14V, 240 mA, Type 1891
Valley Part#223-0003-0
(Throw/Don't Throw)




BI-PIN
14V, 80 mA, Type 5810
Valley Part#223-0006-0
(Upper Display)



WEDGE BASE
28V, 60 mA, Type 656
Valley Part#223-1008-0
(Coin Door)

PUSH BUTTON SWITCHES PARTS LIST



51 Button Housing, 1" square

- 205-0224-0 "High Score" Legend
- 205-0225-0 "Shanghai" Legend
- 205-0227-0 "301" Legend
- 205-0228-0 "501" Legend
- 205-0238-0 "Cricket" Legend
- 205-0230-0 "Double In" Legend
- 205-0241-0 "Double Out/Cut-Throat" Legend
- 205-0232-0 "Masters Out" Legend
- 205-0233-0 "League" Legend


52 Button Housing, 2" square

- 205-0242-0 "Player Change" Legend
- 227-0016-0 Microswitch, DPST
- 223-1006-0 Lamp, miniature, Wedge, 14V DC

53

54


NOTE: For best operation, continue using a GE658 when replacing this lamp.




CABLES AND HARNESES PARTS LIST

EE2	Harness, Output, Regulator Shroud
EE4	Cable Ribbon, Upper Display
EF1	Harness, Power, Controller Card
EF2	Cable, Light Fixture, Fluorescent
EF3	Harness, Speaker
EF4	Harness, Lamp Assembly
EF5	Cable Ribbon, Infrared
EF6	Cable Ribbon, Matrix Interconnect
EF7	Harness, Upper Display Power
EHI	Harness Coin Door Universal
	- EE6 Harness, Coin Door Ground
	- EE7 Harness, Coin Door Power
	- EE8 Harness, Coin Mechanism
	- EE9 Harness, Coin Meter
EK9	Ground, Static, Controller Card
G69	5 Switch Assembly, F
G70	5 Switch Assembly, E
G71	Coin Door Assembly
	- M73 Cougar Darts & Tips Bag Assembly
	- M92 Stability Assurance Kit
242-0006	Line Cord
244-0008	F8 - Ferrite Bead


CONTROLLER CARD COMPONENT LAYOUT







CONTROLLER CARD 2-SIDED
COMPONENT LAYOUT
A73-0-00-00


CONTROLLER CARD





UPPER DISPLAY COMPONENT LAYOUT








51A

UPPER DISPLAY


A60-0-00-00






229-0040-1

CONFIDENTIAL			
THIS MATERIAL IS CONFIDENTIAL AND THE PROPRIETARY PROPERTY OF VALLEY RECREATION PRODUCTS INC., ELECTRONIC DIVISION, AND SHOULD NOT BE USED OR DISCLOSED WITHOUT PRIOR WRITTEN AUTHORIZATION.			
DATE: 7 - 26 - 90	FINISH:	DECIMAL .XXX +/- .005	DRAWN BY: WJS
SCALE:	MATERIAL:	.XX +/- .02	APPROVED BY:
UPPER DISPLAY w/ CRICKET			
VALLEY RECREATION PRODUCTS INC. ELECTRONIC DIVISION 320 NORTH AVENUE, SYCAMORE, IL 60178 / (815) 895-8188 / FAX (815) 895-2118		DRAWING NO. A60-0-00-00	




REGULATOR SHROUD


J24-1-00-00



POWER SUPPLY, HIGH VOLTAGE




229-8842-8				CONFIDENTIAL		DATE: 6/25/91
MODIFICATIONS				THIS MATERIAL IS CONFIDENTIAL AND THE PROPRIETARY PROPERTY OF VALLEY RECREATION PRODUCTS, INC., ELECTRONIC DIVISION, AND SHOULD NOT BE USED OR DISCLOSED WITHOUT PRIOR WRITTEN AUTHORIZATION.		
DATE ECN REV CHKD				DRAWN BY: LSS		
10/23/92 E-1249 8 405				APPROVED BY:		
HIGH VOLTAGE PCB ASSY.						
				DRAWING NO.		
				A57-0-00-00		
				VALLEY RECREATION PRODUCTS, INC. ELECTRONIC DIVISION 285 PRATT AVENUE, STAMFORD, CT 06178 (203) 308-0100 / FAX (203) 308-4110		



**NOTE: ALL ITEMS SHOWN ARE LOCATED ON PCB,
EXCEPT FOR TRANSFORMER.**


POWER SUPPLY, LOW VOLTAGE

A58-1-00-00




VALLEY RECREATION PRODUCTS
A55


INFRARED SENSOR COMPONENT LAYOUT



INFRARED SENSOR



MATRIX INTERCONNECT



MATRIX INTERCONNECT

A 56-0-00-00