

PACMAN INSTALLATION INSTRUCTIONS

Congratulations on the purchase of the first PacMan sideart stencil set. Enclosed you will find detailed installation instructions to help assure trouble-free stenciling.

Each kit includes:

3 Right Side Stencils (Black, Blue, Red)
3 Left Side Stencils (Black, Blue, Red)
3 Front Stencils (Black, Blue, Red)

You will need:

Roll of Masking tape,
Yellow, Black, Red, and Blue spray paint
Scissors
Squeegee (Credit card works great)

It is important to properly prepare each surface by sanding to remove old paint chips or flaking. Failure to do so may result in unsatisfactory results. Please note: each layer of paint takes time to dry - depending upon what type of paint you choose to use. Do not rush the process - allow proper drying time between stencil separations.

Also, please note these stencils are not intended to be re-usable, as the pieces are pre-positioned onto the premask material for application to the cabinet. Once the premask is removed during installation, the many stencil pieces are extremely difficult to reposition for use on another cabinet.

1. After properly prepping surface, paint entire cabinet yellow and allow time to dry.

This is a three part stenciling process - first applying black, then red, and finally blue. Note: Cabinets were originally stenciled with red and blue, and then screen printed black. Restoring your cabinet to original condition by stenciling requires a slightly different process. We have chosen to

stencil black first as an aid in registration of the two remaining colors.

1. Separate stencil sets into left, right and front.
2. Position black stencil onto appropriate side, and tape along the top edge using masking tape. When positioned to your liking, apply a long strip of masking tape along the top edge of the stencil (making a hinge).
3. Lift the entire stencil away from the cabinet along your tape hinge, and carefully peel back approx. 12 inches



of the backing material. Holding the exposed stencil away from the cabinet, gently apply the stencil with the squeegee using soft, overlapping strokes. Continue this process until the entire stencil is applied.

4. Remove the premask material leaving the stencil on the cabinet. NOTE: If you have trouble removing the premask, a spray bottle filled



with water helps soften the adhesive.

5. Repeat steps 2 through 4 with the black stencil on the other side of the cabinet and front. NOTE: Due to the

time required for the paint to dry, we recommend that you prepare and paint all three sides with the appropriate color at the same time.

6. Mask off any exposed areas that are not covered by the stencil material (to control any over-spray).

7. Paint the stencil using the appropriate color using controlled, overlapping strokes. Be sure to get a good coat, as once the stencil is removed, it's extremely difficult to use it again.

8. Allow proper time for paint to completely dry. We recommend overnight. NOTE: If you do not allow proper time, the adhesive on the next stencil may peel off some paint.

9. Remove the stencil. If all went well, no touch-up will be necessary - but now's the time to examine the results for any necessary touch-up.

10. Repeat steps 2 - 9 using the blue stencils. Note: The outside edge of all stencils are the same size, so use the outside edge marked in step 4 as a guide for alignment of the blue and red.

Congratulations! You are now have a restored PacMan cabinet!

