

Piggy rams and 732 as pool

9L Lift Pir 13 link to ground WR6+WR4 =

8M Lift Pir 11 and join tracks 11 to 9 WR6

Cut pir 11 of 8M. Join track 9 and 11 under board

Piggy 138 on top of 8P, 8N or 8M

and pins as follows

\ Pir 1 down to Pir 2

ADDR 12

\ Pir 2 ——— Pir 3

AD 13

\ Pir 3 to ground

\ Pir 4 to 8D Pir 9

\overline{RD}

\ Pir 5 to 8E Pir 4

$\overline{WR6}$

PROG SHEET 1

\ Pir 14 to Eprom *2*

\ Pir 15 to Eprom *1*

\ Pir 13 to 157 Pir 2

\ Pir 12 to 157 Pir 3

\ Pir 6 to ~~157~~ +5

Piggy 157 nearby

\ Pir 1 to 259 9M lifted Pir 6

\ Pir 2 to 13 or 138 Piggy

\ Pir 3 to 12

\ Pir 4 to Eprom *4*

\ Pir 7 to Eprom *3*

\ Pir 6 link to pir 62 of same 157

\ Pir 5 ——— 3 ———

\ Pir 15 to ground