

## BLASTEROIDS CPU BOARD PINOUT

### VIDEO

1	Red
2	
3	KEY
4	Green
5	
6	Blue
7	
8	GND
9	Csync
10	
11	

### AUD

1	Test
2	GND
3	Audat
4	Full
5	KEY
6	Aud Flag
7	Aud Clk
8	GND
9	GND
10	+5V
11	+5V

### LET

1	GND
2	GND
3	+5V
4	KEY
5	P1 CLK
6	P1 DIR
7	P2 CLK
8	P2 DIR
9	+5V
10	GND
11	GND

### POWER ( AMP NLOK )

1	+5V
2	+5V
3	+5V
4	GND
5	GND
6	GND

### CTRA

1	GND
2	KEY
3	1P FIRE
4	2P FIRE
5	1P THRUST
6	2P THRUST
7	1P TRANS
8	2P TRANS
9	
10	
11	GND

## ATARI AUDIO BOARD A043713 PCB

CC1+	Coin Counter 1
CC2+	Coin Counter 2

### ACDC ( MOLEX KK)

1	+5V
2	-5V
3	GND
4	+12V
5	
6	GND
7	GND
8	17VAC ( not used)
9	12VAC ( not used)
10	12VAC ( not used)
11	KEY
12	GND

### JSCOM ( connect to AUD on CPU Board)

1	Test
2	GND
3	Audat
4	Full
5	KEY
6	Aud Flag
7	Aud Clk
8	GND
9	GND
10	+5V
11	+5V

### JCOIN

1	
2	
3	Coin 2
4	Coin 1
5	KEY
6	GND

### JSPK ( MOLEX KK)

1	GND
2	SPK2+
3	KEY
4	
5	SPK1+
6	GND