



使用 1 COIN 1 Play
 2 COIN 2 Play
 1 COIN 2 Play の切替 付

75				
74				
73	MO5750P	スライドスイッチ	1	
72	AAT51801	抵抗	3	R6
71	AAT51781	"	1	R5
70	AAT51777	"	1	R4
19	AAT51765	"	9	R3
18	AAT51763	"	8	R2
17	AAT51749	抵抗	4	R1
16	AAT41749	74V1-4	6	C5
15	AAT41738	74V1-4	1	C6
14	AAT41031	電圧調整	1	C7
13	AAT41027	電圧調整	1	C3
12	AAT41021	"	1	C2
11	AAT41018	電圧調整	4	C1
10	AAT37016	TTL IC	1	IC5
9	AAT37070	"	8	IC4
8	AAT37047	"	1	IC3
7	AAT37008	"	1	IC2
6	AAT37001	TTL IC	1	IC1
5	AAT17017	ダイオード	6	D
4	AAT11034	トランジスタ	1	TR3
3	AAT11030	"	1	TR2
2	AAT11005	トランジスタ	8	TR1
1	SP070017	74ピンチップ	1	

No.	部品番号	品名	規格	数量	記号

for W/N