## DIP SW-F1 DREAM

DIP sw A

T. C.

ITEM	DESCRIPTION					1	2 .	3	4	5	6	7	8
COIN 2	1	COIN	/	1	CREDIT	OFF	OFF	OFF					
	1		/	2		ON	OFF	OFF					
	1		/	3		OFF	ON	OFF			·		
	.1		/	4		ON	ON	OFF					
	1		/	6		OFF	OFF	ON					
	2		/	1		ON	OFF	ON					9
	3		/	1		OFF	ON	QN					
	4		/	1		ON	ON	ON	·				
COIN 1	1	COIN	/	1	CREDIT				OFF	OFF	OFF		
	1		/	2					ON	OFF	OFF		
	1		/	3					OFF	ON	OFF		
	1		/	4					ON	ON	OFF		
	1		/	6					OFF	OFF	ON		
	. 2		/	1					ON	OFF	ON		
	3		/	1				ļ	OFF	ON	ON		
	4		/	1					ON	ON	ON		
TEST MODE	NORMAL										OFF		
		TEST										ON	
SCREEN FLIP	NORMAL											OFF	
		FLIP			•								ON

DIP sw B

ITEM	• DESCRIPTION		1	2	3	4	5	6	7	8
						, F				
		·								
TYPE ,	TABLE				OFF					
	UP RIGHT				ON					
F1 ADVANCE POINT	12 POINT	•				OFF	OFF			
	16 *	٠				ON	OFF			
	18 *					OFF	ON			
	20 *					ON	ON			
DIFFICULTY (LEVEL)	NORMAL							OFF		
	EASY							ON		
					*					
CONTINUE MODE	ON								. \	OFF
	OFF								. ,	ON