



x → Kap List

LEFT-
No. 15416-A Amplifier Assem
(Top View)

Part No.	Description
① 15157	20 Mfd. Input Filter Capacitor
2 15153	Output Transform
3 15154	Power Transform
4 PH-3191	Type 6L6G Tubes
5 PH-3190	Type 5U4G Tube
6 15155	Type 12AU7 Tube
7 15156	Type 12AX7 Tube
8 PH-3740	5 Prong Socket
9 15203	Input Socket
10 PH-3740	5 Prong Socket
x ① 15158	20-20-20 Mfd. Fil. Capacitor
12 12769	Speaker Terminal Strip
13 PH-3523	3-Amp. Fuse
14 ST-3092	10-Amp. Fuse

Rockola-1432-34

RIGHT-
No. 15416-A Amplifier Assembly (Bottom View)

Part No.	Description
1 PH-3270	2 Prong Socket
2 11555	Fuse Holder
3 PH-3177	50 Mfd. 50V. Condenser
4 15399	.0075 Mfd. 1600 V. Condenser
5 13188	Tube Socket
6 13034	.1 Mfd. 600 V. Condenser
⑦ 13034	.1 Mfd. 600 V. Condenser
8 15187	12,000 Ohm 1 Watt Resistor
9 15161	9 Pin Miniature Socket
10 15201	Filter Resistor
11 15187	12,000 Ohm 1 Watt Resistor
12 12994	Tone Switch
⑬ 15194	.002 Mfd. 600 V. Capacitor
⑭ 15204	.25 Mfd. By Pass Capacitor
⑮ 15191	.02 Mfd. 600 V. Condenser
16 12994	Tone Switch
17 13187	.25 Mfd. 200 V. Condenser
⑰ 15190	.01 Mfd. Capacitor 200V
⑱ 15190	.01 Mfd. Capacitor 200V
20 15161	9 Pin Miniature Socket

Part No.	Description
⑳ 13040	.5 Mfd. 150 V. Condenser
22 13077	390 Ohm Carbon Resistor
23 13188	Tube Socket
24 15189	47 Ohm 5 Watt Resistor
25 15335	Cancel Socket
26 11559	3 Prong Socket
27 13028	Tube Heater Relay
28 PH-3270	2 Prong Socket

