- INSERT COIN(S).
- PUSH PLAYER 1 BUTTON FOR 1 PLAYER.
- PUSH PLAYER 2 BUTTON FOR 2 PLAYERS.
- USE JOYSTICK CONTROL TO MOVE SHIP UP AND DOWN AND FOR FAST FORWARD SPEED OR RETRO.
- PUSH BUTTONS TO FIRE MISSILES OR DROP BOMBS.
- THE GAME PROCEEDS THROUGH ALL THE PHASES MARKED AT THE TOP OF THE SCREEN AS LONG AS THE PLAYER HAS SHIPS REMAINING.
- IN THE ULTIMATE PHASE THE OBJECT IS TO DESTROY THE ENEMY'S MASTER FUEL RESERVE.