



TIME WARNER INTERACTIVE



Showcase Supplement for Primal Rage™

*Supplement to the Primal Rage Operator's Manual (TM-395)
and the Showcase 33 Deluxe Service Manual (TM-393, 2nd printing)*

Introduction

THIS SUPPLEMENT describes the parts unique to your Showcase 33 cabinet version of Primal Rage™. Besides this supplement, you should have received with your game the *Showcase 33 Deluxe Service Manual* (TM-393, 2nd printing) and the *Primal Rage Operator's Manual* (TM-395). Those manuals, together with this supplement, provide the information you need for setting up, playing, testing, and maintaining your Primal Rage game.

Parts Unique to the Primal Rage Showcase 33 Deluxe Cabinet

- Ground plane and two-part metal "hat" section over the board stack (see Figure 1 of this supplement). The board stack in this Showcase cabinet does not require a JAMMA Filter PCB. Therefore, ignore any references in the *Primal Rage Operator's Manual* to that printed-circuit board.
- Primal Rage control panel assembly (see Figure 2)
- Attraction decal (see Figure 2)
- Game wiring diagram for the Showcase cabinet (see Figure 3)

CAUTION


The low-impedance (75Ω) Neotec NT-2515C monitor (used in the Atari Games standard upright cabinet) and the high-impedance Hantarex Polo 33" monitor (used in the Showcase 33 cabinet) are **not** interchangeable. If you do plan to replace an existing monitor with the other type, you must change resistors in the video driver circuits on the Primal Rage game PCB. Refer to the game PCB schematic on page 5-6 of the Primal Rage Operator's Manual for more details.

If you need technical assistance, call your distributor or Atari Games Customer Service at one of the following locations:


United States: (408) 434-3950
Atari Games Corporation,
737 Sycamore Drive, Milpitas, CA 95035
(Monday–Friday, 7:30 a.m.–4:00 p.m. Pacific time)

OR

Europe: 062-52155
Atari Games Ireland Limited,
Tipperary Town, Ireland
(Monday–Friday, 9:00 a.m.–5:30 GMT)



**Figure 1 Primal Rage Board Stack Assembly
(Showcase 33 Deluxe Cabinet Only)**



**Figure 2 Primal Rage Showcase 33 Deluxe Cabinet
(Front View)**




Figure 3 Primal Rage Game Wiring Diagram (Showcase Cabinet Version)

053515-01 Rev. A




Figure 3 Primal Rage Game Wiring Diagram, Continued (Showcase Cabinet Version)

053515



TIME WARNER INTERACTIVE

Atari Games Corporation • 675 Sycamore Drive • Milpitas, CA 95035