



NOTES: \perp IS COMMON CENTER TAP
 |||| IS SPECIAL GROUND AND CAN BE CONNECTED TO COMMON CIRCUITS
 POWER SUPPLY TO BE USED WITH MOTHER BOARD P.C.A082-90002-X000