Shadow Dancer

PARTS		SOLDER
GND	1	GND
GND	2	GND
+5V	3	+5V
+5V	4	+5V
+12V	5	+12V
	6	
	7	
1P SHOT	8	2P SHOT
1P ATTACK	9	2P ATTACK
1P JUMP	10	2P JUMP
	11	
1P DOWN	12	2P DOWN
1P UP	13	2P UP
1P RIGHT	14	2P RIGHT
1P LEFT	15	2P LEFT
	16	
	17	
	18	
	19	
COIN 1	20	1P START
COIN 2	21	2P START
	22	
	23	
SPEAKER +	24	SPEAKER -
RED	25	GREEN
BLUE	26	SYNC
GND	27	GND
GND	28	GND

DIP SW NO.1:

	1	2	3	4	5	6	7	8
1 COIN 1 CREDIT	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF
1 2	ON	OFF	OFF	OFF	ON	OFF	OFF	OFF
1 3	OFF	ON	OFF	OFF	OFF	ON	OFF	OFF
1 4	ON	ON	OFF	OFF	ON	ON	OFF	OFF
1 5	OFF	OFF	ON	OFF	OFF	OFF	ON	OFF
1 6	ON	OFF	ON	OFF	ON	OFF	ON	OFF
2 1	OFF	ON	ON	OFF	OFF	ON	ON	OFF
3 1	ON	ON	ON	OFF	ON	ON	ON	OFF
4 1	OFF	OFF	OFF	ON	OFF	OFF	OFF	ON
5 1	ON	OFF	OFF	ON	ON	OFF	OFF	ON
FREE PLAY	ON	ON	ON	ON	ON	ON	ON	ON

DIP SW NO.2:

		1	2	3	4	5	6	7	8
TYPE	TABLE	OFF							
	U/R	ON							
DEMO SOUND	OFF		OFF						
	ON		ON						
NUMBER OF PLAYERS	3			OFF	OFF				
	4			ON	OFF				
	5			OFF	ON				
	FREE			ON	ON				
DIFFICULTY	NORMAL					OFF	OFF		
	EASY					ON	OFF		
	HARD					OFF	ON		
	HARDEST					ON	ON		
ENEMY BULLET	BLOW							OFF	
	FAST							ON	
DISPLAY	JAPANESE								OFF
	ENGLISH								ON