



Coin Door and Option Switch Inputs



Analog Vector-Generator PCB Outputs




Adjustment of R73 and R74
 If you replace the Battlezone™ Analog Vector-Generator PCB, you may have to adjust two controls on this board. Follow this procedure:
 Enter the self-test. Locate the two potentiometers at R73 and R74 on the Analog Vector-Generator PCB. These control X and Y centering. Turn the controls in either direction until the diagonal lines on all four sides of the screen touch or barely overscan outside the horizontal and vertical frame lines.

Adjustment of R88 and R98
 If you replace the Battlezone™ Analog Vector-Generator PCB or the monitor, you may have to adjust certain controls on this board or monitor. Do not do these adjustments unless you are a qualified technician. The monitor has very high voltages near the yoke adjustment tabs! Follow these steps:
 1. Enter the attract mode. Locate the two potentiometers at R88 and R98 on the Analog Vector-Generator PCB. These control X and Y amplitude or the overall fit within the die-cut holes in the cardboard bezel. (These adjustments are roughly equal to horizontal width and vertical height in a raster-scan monitor.) Adjust so that the picture generally fits into the holes.
 2. Enter the play mode by pushing the start button. Now carefully locate the two black tabs on the monitor yoke magnets (inside the large white ring). Remember that the yoke area has very high voltages! These tabs control X and Y offset.

Adjust these tabs until the radar "screen" is within the circular hole. Then drive the tank up to one of the cubes until you bump into it. Make sure the cube does not overscan so it appears in the radar screen area or the rectangular message areas.
 Return to Step 1 if necessary.

NOTICE TO ALL PERSONS RECEIVING THIS DRAWING
 CONFIDENTIAL: Reproduction forbidden without the specific written permission of Atari, Inc., Sunnyvale, CA. This drawing is only conditionally issued, and neither receipt nor possession thereof confers or transfers any right in, or license to use, the subject matter of the drawing or any design or technical information shown thereon, and any right to reproduce this drawing or any part thereof. Except for manufacture by vendors of Atari, Inc., and for manufacture under the corporation's written license, no right to reproduce this drawing is granted or the subject matter thereof unless by written agreement with or written permission from the corporation.



Sheet 2, Side B
BATTLEZONE™
CABARET
 Analog Vector-Generator PCB
 Switch Inputs
 Analog Vector-Generator PCB
 Video Output
 Analog Vector-Generator PCB
 Coin Counter Output
 Section of 035742-01 & -02 B

NOTE
 □ Indicates edge connector
 ○ Indicates interconnect connector
 ◻ Indicates test point