

©1983 Exidy, Inc.

FAXTM

Operation and Service Manual 1st Edition

(c) 1983 Exidy, Inc. 390 Java Drive, Sunnyvale, California 94089-1271 Telephone: (408) 734-9410 Toll-free: (800) 538-8402 Telex: 357-499 (EXIDY MNTV)

ſ

.

٠

.

Exidy Ireland Gortlandroe Industrial Estate Nenagh, County Tipperary Ireland Telephone (067) 32555 Telex: 70009 (EXDY EI)

FOREWORD

Part One of this manual contains Preliminary Procedures, describing game inspection, installation, and checkout. Also, Adjustment Procedures are given for Power Supply, Audio Volume, and Operator Selectable Options.

Part Two, Modes of Operation, describes the four FAXTM modes: Automatic Self-Diagnostic Test Mode, Attract Mode, Game Play Mode, and Vanity Mode.

Appendix A contains game schematics, with a circuit description on each page opposite.

Appendix B is the Illustrated Parts List. Parts are pointed out in the drawings and listed opposite each drawing.

EXIDY FAXTM OPERATION AND SERVICE MANUAL

TABLE OF CONTENTS

I.	PRELIMINARY PROCEDURES 1
	A. GAME INSPECTION 1 1. Filing a Claim 1 2. Visual Inspection 1
	B. INSTALLATION 2
	C. PRELIMINARY CHECKOUT PROCEDURE 2
	 D. ADJUSTMENTS
11.	MODES OF OPERATION 6
	 A. AUTOMATIC SELF-TEST MODE
	B. THE ATTRACT MODE
	C. GAME PLAY MODE 10
	D. VANITY MODE

APPENDIX A: SCHEMATICS

Page 1: GAME LOGIC A-1

Master Oscillator, Element (Horizontal) Counters, Line (Vertical) Counters, Screen RAM Addresses, Coin Input Decoding, Hardware Generated Line Positioning Proms, Blanking and Video Clocking

- Page 2: Logic A-2 Screen Controller PROM, Screen RAM, Character Image Storage, PROM Power and Signal Selection, Character Generator Output Shift Register
- Page 3: Logic A-3 Character Generator Image Storage, Plane Interface Board
- Page 4: Logic A-4 The 6502 Microprocessor, Power-on Reset circuit, Processor Workspace RAM, Main Address Decoding
- Page 5: Logic A-5 Program Memory, PROM Address Selection, Memory Device "Personality" Selection
- Page 6: Logic A-6 Moving Object Horizontal Position, Moving Object Vertical Position Counters, "Write Moving Object" Decoding, Color Interface Output
- Page 7: Logic A-7 Moving Object Multiplexing, Moving Objects Image PROM, Moving Object Video Output Shift Registers, Moving Objects Shift Register Load Logic, Moving Object Shift Register Control Logic, Memory Device Personality Configuration
- Page 8: Logic A-8 Interrupt Status Latch, Option Switch Port, Control Inputs Port, Moving Image Latch, Audio Board Port, Control Port Latch, I/O Decoding

Page 9: Memory and Expansion I/O Board A-9

AUDIO/COLOR PCB-GENERAL DESCRIPTION A-10

- Page 1: Audio/Color..... A-11 Logic and Power Interface, Communications and Address Decoding
- Page 2: Audio/Color A-12 6502 Microprocessor, Peripheral Interface Adapters, Address Decoding, Music Generator, Master Oscillator, Program Memory, Output Filter
- Page 3: Audio/Color A-13 Clock Manipulation and Noise Generation Circuit, Amplitude Modulation Control, Output Summation and Special Effects, Volume Control

- Page 4: Audio/Color..... A-14 Summing Amplifier, Integrator and Audio Power Amplifier, Volume controls
- Page 5: Audio/Color..... A-15 Pattern Character Color Division, Priority Encoder, Color Data Latches, Color Selection Multiplexers, Video and Sync Signal Polarity Selection, Final Video Output Resychronization

Wiring Harness Diagrams/Schematics

i

Block Diagrams, A.C. Power and Monitor, Power Supply Assy, Main Harness, Control Panel Harness, Coin Door Harness, Power Supply Schematic, Game Monitor Schematic.

APPENDIX B: ILLUSTRATED PARTS LIST..... B-1

A. FINAL ASSEMBLY B-2
B. FAX TM POWER SUPPLY ASSY B-3
C. ISOLATION TRANSFORMER ASSEMBLY B-4
D. COIN DOOR ASSEMBLY B-5
E. LOGIC AND AUDIO BOARD ASSEMBLY B-6
F. PRINTED CIRCUIT, UNIVERSAL POWER SUPPLY B-7
G. LOGIC BOARD B-8
H. AUDIO/COLOR BOARD ASSEMBLY B-9
I. PLANE INTERFACE BOARD B-10
J. MEMORY & I/O EXPANSION BOARD B-11

COPYRIGHT

Copyright (c) 1983 by Exidy Inc. All rights reserved. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form, or by any means without the prior written permission of Exidy, Inc. 390 Java Drive, Sunnyvale, California 94089.

DISCLAIMER

Exidy Inc. makes no representations or warranties with respect to the contents hereof and specifically disclaims any implied warranties of merchantibility or fitness for any particular purpose. Further, Exidy Inc. reserves the right to revise this publication from time to time in the content hereof without obligation of Exidy Inc. to notify any person of such revision or changes.

TRADEMARKS

FAXTM is a trademark of Exidy Inc.

WARNING

This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instruction manual, may cause interference to radio communications. It has been tested and found to comply with the limits for a Class A computing device pursuant to Subpart J of Part 15 of FCC Rules which are designed to provide reasonable protection against such interference when operated in a commercial environment. Operation of this equipment in a residential area is likely to cause interference in which case the user at his own expense will be required to take whatever measure may be required to correct the interference.

١

QUESTIONS

Exidy encourages technicians to use the toll-free customer service hotline for any questions they may have regarding FAX^{TM} . That number is (800) 538-8402.

I. PRELIMINARY PROCEDURES

A. GAME INSPECTION

All Exidy equipment is carefully packaged in well-padded cardboard containers to prevent damage during shipment. Before signing the delivery receipt, you should follow this procedure:

- 1. Check for obvious damage and make certain that the physical piece count of the shipment matches the piece count on the bill of lading. These two procedures should always be done before signing the delivery receipt.
- 2. Shortages and/or obvious damage to the packaging on any given shipment should be noted in writing on the delivery receipt before signing for the delivery.
- 3. If concealed damage is suspected on any shipment, those packages believed to contain the damaged goods should be opened in the presence of the delivery driver. If the goods have sustained concealed damage, a description of said damage should be noted in writing on the delivery receipt before signing for the delivery.
- 4. Never apply power to any game with noticeable damage.

1. Filing a Claim

ł

To file a claim, follow this procedure:

- 1. Any and all damaged freight, including packaging, should be retained by the consignee until a physical inspection of said freight can be made by a representative of the carrier involved.
- 2. The Claims Manager for the carrier involved should be notified as soon as possible, after the damaged goods are received. Preferably, the carrier's Claims Manager should be notified within forty-eight (48) hours of receipt of the goods by the consignee.
- 3. If warranted, a written claim should be filed with the carrier involved. A detailed description of the damage(s) should be provided and copies of all supporting documents, including bill of lading and/or delivery receipt, inspection report, and invoice, should be attached.
- 4. The sconer a claim is filed, the better for all parties concerned. The carrier against which a claim is filed is required, by law, to respond to (acknowledge) that claim within thirty (30) days of receiving same and must reach a final disposition in the matter within one hundred twenty (120) days.

2. Visual Inspection

- 1. Remove the rear and front access doors with the appropriate packaged key.
- 2. Examine each major and electrical component thoroughly for scrapes, dents, broken or missing parts and loose or missing screws.
- 3. Check for loose cable connectors.

4. Visually verify that all the integrated circuit devices (IC's) plugged into sockets are properly seated and that no IC pins are bent or misaligned.

If you find any damage during this inspection, file a claim with the carrier. Send a complete report of the damage to Exidy Inc.

B. INSTALLATION

Planning the location of the game should involve both physical and electrical considerations. Such physical considerations concern the placement of the equipment with respect to these clearances:

Height: 55.50 inches, 140.2 cm. Width: 37.25 inches, 94.5 cm. Depth: 24.00 inches, 61.0 cm.

An indoor, relatively dust-free environment is necessary, with proper conditions required of any electrical device. Electrical considerations include availability of an AC outlet with the correct voltage and frequency. You should consider the working space required for technicians and operators including access to the rear of the game.

NOTE:

The cabinet must be within seven feet of an AC outlet. Be certain that a ground jack or terminal is available at the outlet.

CAUTION:

DO NOT remove the AC ground prong from the plug. Doing so voids your warranty!

\$

C. PRELIMINARY CHECKOUT PROCEDURE

After properly installing FAXTM, we suggest following this procedure to check its operation:

- 1. Connect the AC power plug into the AC outlet.
- 2. Once powered up, after five seconds of silence, a quick beep sounding like an organ chord, is heard. This is part of the Exidy Audio Diagnostic Test. A single beep indicates all is well with the audio board. If more than one beep is heard, refer to Part II, Automatic Diagnostic Test Mode.
- 3. Allow 8-10 seconds to pass for the CRT to warm up.
- 4. Observe the TV monitor display. After Exidy Diagnostic Test are completed assure the correct attract mode is present on the screen, as described in Part II B, Attract Mode. If the FAXTM display is incorrect, contact Exidy's Customer Service Department.
- 5. Insert the appropriate coin or token into each of the coin slots. The message in the attract mode will flash the following lines:

FAXTM

CREDITS

Press Start

One or Two Players

A ONE PLAYER CHALLENGE

A TWO PLAYER RACE

depending on the number of coins dropped into the coin slot, or the number of credits awarded for each coin..

6. Press one or two player start and play the game to verify that all screen images are displayed as described in Part II C, Game Play Mode.

If assistance or repairs are necessary, contact the Exidy's Customer Service Department, (800) 538-8402.

D. ADJUSTMENTS

1

1. Power Supply Information and Adjustments

All DC Power required to operate FAXTM is supplied in the Exidy Power Supply Module. These supply outputs are as follows:

+5v DC	@	6 amps
-5v DC (Not used)	6	l amp
+12v DC (HI)* +12v DC (LO)*	@	3 amps
	9	l amp
-12v DC (HI)* -12v DC (LO)*	@	3 amps
-12v DC (LO)*	@	l amp

* (HI) refers to "high current"

(LO) refers to "low current"

CAUTION: Only certified technicians should make adjustments on all components of FAXTM. Only the +5v DC is adjustable. This must be adjusted to:

+5.00v DC +/- .lv

as measured on the Main Logic PCB near the 6502 Microprocessor (location 2A).

2. Audio Board Adjustments

The following drawing points out the three individual audio adjustments and the location of the DIP switch. The audio board rides piggyback on the logic board, mounted on the back wall of the game.



3. Operator Selectable Options

 FAX^{IM} has several switch selectable options controlled by an 8-position DIP switch located on the main logic board at position 16A. This switch is accessible through the left front door of the game.

 FAX^{TM} is shipped with the DIP switch already set for optimum dollar return, that is 48 seconds game clock 3:12 play time with 36 seconds bonus clock time at 13,000 point level. Actual game time play for the average player will be aproximately 2 to 4 times the game clock time as the game clock (bottom of screen) starts and stops at various times throughout the play of a game. The game clock starts when the answer to the first question appears on the screen, and stops when a player (both players in a two player game) selects an answer, right or wrong. This sequence is repeated for all questions. Should you decide to change the settings, you may select any of the following options by setting the proper switches accordingly:

a. COINAGE			Swi	tch 4	Swit	tch 5	Switch 8	
F/S	1 Coin - 2 Coins -			OFF OFF		OFF ON	OFF OFF	
	l Coin - 2 Credits			ON		OFF	OFF	7
	l Coin - 4	4 Credits		ON		ON	OFF	,
	l Coin - : OR 2 Coins -	3 Credits 7 Credits		OFF		ON	ON	
	l Coin in Left Slot- l Credit, l Coin in Right Slot- 5 Credits*			OFF		OFF	ON	
l Coin in Left Slot- l Credit, l Coin in Right Slot- 4 Credits [*]				ON		OFF	ON	
	1 Credit,	n Left Slot- l Coin in t- 3 Credits*		ON		QN	ON	
b. (GAME TIMES			Swi	tch	Swit	ch	
с	Game lock Time	Approx. Play Time	Bonus Time	6	•	7		
	:32	2:08	:24	OF	Ŧ	OFF	P	
F/S	:48	3 :12	:36	ON	I	OF	,	
	1:04	4:16	:48	OF	Ŧ	ON		
	1:12	4:48	1:Ø4	ON	I	ON		
c. BONUS TIME (Extra time awarded when selectable number of points are made. Max- imum of 2).		5	witch 2	S	vitch 3			
	8,000			OFF		OFF		
F/S	1 3,000			ON		OFF		
	18,000			OFF		ON		
	25,000			ON		ON		

* Requires dual harness. F/S=factory setting. switch 1 is not used adn should be off.

1

à

FREEPLAY: For those wishing to demonstrate FAX $^{\rm TM}$, a freeplay mode may be achieved by turning switches 2 through 8 ON.

II. MODES OF OPERATION

A. AUTOMATIC SELF-TEST MODE

 $\rm FAX^{\rm TM}$ automatically tests the logic data and audio boards on power up. To run the Control and Color Test, activate the coin switch while powering up.

You may bypass both diagnostic modes by depressing either the one or two player start button while powering up. After 8 seconds of the message "STAND BY VERSION X", (where X is a number representing the software version) the Attract Mode appears.

1. LOGIC DIAGNOSTIC TESTS

a. The RAM Test

When FAXTM is first turned on, a processor and video RAM test are done. If the RAM passes, it goes immediately into the EPROM test, without a message indicating it passed the RAM test.

If a RAM chip fails, an attempt is made to indicate the RAM chip where a failure was detected. Since the screen depends on a properly functioning RAM, this indication may not be displayed. A failed RAM may be indicated by a digit from \emptyset to 3 in every position on the screen. The code for these digits is as follows:

Number on Screen	RAM chip to check on logic board	Number on Screen	Location on Plane Interface board
Ø	4A,5A (2114)	3	Ul (6116)
1	7B,8B (2114)		
2	9C (6116)		

The RAM test cycles if the failure is persistent

b. The EPROM Test

If the RAM test passes, the EPROM test begins. The message "PROGRAM EPROM CRC TEST" first appears on the screen to indicate the FAX^{TM} program logic Eproms are been tested. One by one, "X"'s appear on the screen. Each X indicates half of a 2732 EPROM, in locations 13A through 6A, on the logic board has passed the diagnostic test. Note that each EPROM is represented by two X's. To indicate the FAXtm Questions and Answer Data Eprom's are been tested. After 16 X's appear the message "DATA EPROM CHECKSUM TEST" appears on the screen. Again X's will appear to indicate 2764 EPROMS in locations 1C through 8C, 1B through 8B and 1A through 8A on the MEMORY EXPANSION & I/O BOARD*, have passed the diagnostic test. Each EPROM is represented by one X with the first X assigned to 1C and the last to 8A.

If any failure is detected during the EPROM test, an alpha/numerical digit appears instead of "X" with a "BAD EPROM" message. The key for which chip to check is as follows:

DATA EPROM CHECKSUM TEST

Ø123456789ABCDEFGHIJKLMN

1C 3C 5C 7C 1B 3B 5B 7B 1A 3A 5A 7A 2C 4C 6C 8C 2B 4B 6B 8B 2A 4A 6A 8A

PROGRAM EPROM CRC TEST

Ø1 23 45 67 89 AB CD EF 13A 12A 11A 1ØA 9A 8A 7A 6A

*NOTE: All locations may not be filled depending on the amount of memory required. (I.E. 7A and 8A are presently empty.)

2. AUDIO DIAGNOSTIC TESTS

While the Logic Board tests are underway, the Audio board is also being checked.

Five seconds after power on, one or more quick beeps, like an organ chord, are heard. This is part of the Exidy Audio Diagnostic Test. The number of beeps that sound indicate different conditions of the Audio board. The following code is an indication only, of where to first check the Audio Board. Because this diagnostic test only evaluates certain components, other circuitry is relied upon for the test. Should this other circuitry fail, the diagnostic test may not, then, point directly to the failure. Please use the results of this test as a guideline for further troubleshooting.

The code is as follows:

- Ø beep: If no beeps are heard, along with a hum or random notes, this may indicate a failure in 3A and/or 7A, or volume control have been turned off.
- 1 beep: All audio hardware is OK. However, be sure to check the Attract Mode Cycle for a possible message to check the Audio Board. In occasional instances, this can occur. The message will further direct you.
- 2 beeps: ZERO PAGE RAM failure. Check 6532 RAM I.O. Timer Array at location 7B on the audio board.

4

- 3 beeps: (will not occur)
- 4 beeps: ROM failure
- 5 beeps: INTERRUPT failure. Check 6532 at location 7B.

In addition, this message appears during the Attract Mode only if the Audio Board needs to be checked:

"AUDIO COMM ERROR" or "TEST ERROR"

3. CONTROL AND COLOR DIAGNOSTIC TESTS

If desired, you may test all player controls and screen colors for monitor adjustments To do so, activate either coin switch at power-up. The game then enters the Control/Color Test Mode. This mode lasts for 100 seconds to give you time to test and make adjustments. After that, the Attract Mode begins.

In the Control/Color Test Mode, the screen shows this pattern:



The grid pattern tests your screen for any distortion or convergence.

The solid blocks of color (blue, white, green, and red) allow you to adjust the color. When either of the player control buttons (one player or two player) or coin switches (coin 1 coin 2) are activated, their name appears below the blue box. When any of the lettered answer buttons ("A" through "D" for player 1 or 2) are activated, their name appears below the blue and white boxes.

B. THE ATTRACT MODE

After FAXTM goes through its automatic self-diagnostic test mode on power-up, a series of screen displays are shown repeatedly. The first screen identifies the game and manufacturer, along with credit information. The second screen gives game instructions. The third screen is the dean's list, with the initials and scores of the eight highest scoring players.

The final screen shows the comparative progress display. The cycle then repeats.

C. GAME PLAY MODE

FAXTM is a timed trivia game of multiple choice, YES/NO, and TRUE/FALSE questions for either one or two players. Naturally the object of the game is to correctly answer as many questions as possible and score as many points as possible. A player first selects one of the four categories and the difficulty level (choice of three). After each question appears on the screen, the possible answers will appear directly below. The player only has one chance to answer the question. He cannot change is mind once an answer is chosen. The quicker a question is answered correctly, the more points are scored. The game is played until time runs out. Bonus time is awarded for high scores. In a two player game both players play simultaneusly and the first correct answer wins the points.

D. VANITY MODE

Anytime a player's score exceeds one of the fifty current high scores, he is eligible to enter his initials in the Vanity Table. Only the top eight scores will be displayed in the Attract Mode. If both players of a two player game are record high scorers, the higher of the two is first invited to enter his initials. To do so, he uses the A thru D buttons. Use the "A" or "B" button to run the alphabet letters up or down respectively. Once the desired letter appears enter it in by depressing either the "C" or "D" buttons. The game will return to the Attract Mode either after all the initials have been entered or after approximately 100 seconds have elapsed.

APPENDIX A: SCHEMATICS

PAGE 1, GAME LOGIC PCB

1. Master Oscillator (1D)

From this oscillator all dynamic operations are derived, such as the processor clock, the main element and line counters, the shift register clocks, as well as all other forms of timing signals.

2. Element (Horizontal) Counters (1C, 1E, 2E)

These components form the final stages of horizontal timing. All operations in this game requiring horizontal positioning or timing have their origin here. Note that, beginning with signal HCLK (from Clock Divide Counter 2D), there are 256 counts prior to setting signal E256 high. When this signal goes high, it indicates that the horizontal blanking period is in progress. At this time the final counter (IE) is preloaded with a higher number than previously loaded. This creates a shorter count the second time around. The shorter count measures the retrace interval. When the retrace count is finished, the counter preloads with a lower number, establishing a longer count sequence again for "real time" sweep of the electron beam across the face of the CRT.

3. Line (Vertical) Counters (4F, 5F, 6E)

entire form the These components vertical timing operation starting with a clock derived from horizontal timing. These counters count 256 times and then preload with a higher number, causing a shorter count the second time. This shorter count measures the vertical retrace interval. Note that signal L256, when high, indicates vertical blanking is in progress. After the completion of the vertical retrace count, the counters once again preload with a lower number. This way they count 256 times during the sweep of the electron beam down the face of the CRT, allowing the horizontal timers to sweep one complete horizontal line for each count of the vertical counters. Thus, the electron beam reaches the bottom of the CRT, after completing 256 horizontal line sweeps. It then begins the vertical retrace count, and the whole cycle begins anew with the beam starting again at the top of the CRT.

4. Screen RAM Addresses (7D)

During the time the screen RAM is examined by the logic for output to the monitor screen, addresses must be applied to the screen RAM to count up at a rate corresponding to the image cells conceptually arranged on the screen in a 32 x 32 matrix. The counts used here, 4 from the element counters, and 4 from the line counters, fulfill this timing requirement. The least significant element count used (E8) represents an interval exactly eight times that of one element. The least significant line count used represents an interval exactly eight times that of one horizontal line, or eight times a single line count. Dividing a 256 element line by 8 yields 32, and likewise dividing a 256 line vertical sweep by 8 yields 32. Thus the screen RAM address lines (RAMØ through RAM9) count at a rate that creates 32 horizontal counts and 32 vertical counts as the electron beam sweeps the face of the CRT. This makes 1024 conceptual "image cells" into which can then be inserted images of 8 elements by 8 lines. For more information concerning these images, refer to the text for pages 2 and 3 of the Logic Schematics.

5. Coin Input Decoding (1H)

Some models of FAXTM contain two separate for special coinage coin inputs applications. NOR gate 1H combines these separate inputs, making signal 5COINT, which sets the interrupt flipflop (6E on page 8) when either coin input becomes active, thus forcing the microprocessor to jump to the interrupt service routine. This interrupt driven operation prevents ever missing a coin when inserted. However, this also means that when a game is first powered up, the coin input must be inactive. If for some reason the coin input switch is enabled at the time of power up, the game comes up with test pattern ilustrated in page 9.

6. Blanking and Video Clocking (5H)

Flip-flop 5H merely combines blanking and all other video.

PAGE 2, GAME LOGIC PCB

1. Screen Controller PROM (6D)

This PROM controls the direction of data flow into and out of the screen RAM and character generator RAM. It prevents timing errors and buss conflicts, assuring that the microprocessor can write to either the screen or character generator RAM, or read back from either.

2. Screen RAM (7B, 8B)

The screen RAM is comprised of two 1024 x 4 static RAMs, configured to act as a single 1024 x 8 RAM. This creates a screen matrix of 32 horizontal by 32 vertical positions. A single byte code is stored in each of these positions to represent a particular character. During "real time" (the time the CRT is being swept by the electron beam) these character codes address the character generator RAM.

These character codes, when used as addresses, are combined with the three least significant line counts (Ll, L2, L4) to present to the character generator output shift register all the necessary data to form an 8 element wide by 8 line high character on the CRT, located within one of the 1024 positions mentioned immediately above; that is, the 32 horizontal by 32 vertical positions.

The screen, then, is a storage place for single byte codes that call up an 8×8 character and place it into the corresponding character cell. This character is stored in the character generator RAM, shown on page 3 of the schematic.

3. Character Image Storage

Shown on this page are two PROMS (9C, 10C). They could be used as a permanent set of characters. However, FAXTM uses RAM instead, to increase the flexibility in character manipulation. This portion of RAM appears on page 3 of the Logic schematics.

4. <u>PROM</u> <u>Power</u> and <u>Signal</u> <u>Selection</u> (10B)

This Dip Shunt configures the logic for different types of PROM devices. For FAXTM, however, this Dip Shunt is unnecessary due to the fact that RAM has been used rather than PROM.

5. <u>Character</u> <u>Generator</u> <u>Output</u> <u>Shift</u> Register (12B)

Video from the character generator memory devices (RAM in the case of FAXTM) is formed by this shift register as a byte of data that displays one line at a time from left to right on the CRT. This ultimately forms an 8 line high by 8 element wide character positioned on the screen according to the time it is presented to the shift register.

Output from this shift register are all the images seen on the screen except the lower body of the characters climbing the ladders.



.



.

Image Storage RAM

1. <u>Character</u> <u>Generator</u> <u>Image</u> <u>Storage</u> RAM and Plane Interface Board (9C, U1)

These two RAMs, when used in this configuration, act as a 4096 x 8 bit RAM. The two color images placed on the screen are stored in this RAM by the microprocessor, according to the game program. In this RAM images are established, altered, shifted slightly, and even replaced with a new set, if required by the program.

When called by the logic to do so, the RAM presents, to the character generator shift register, a single byte, representing one line of a particular image. Each image is composed of 8 lines of data, each line is one byte-wide. Thus, 256 images of 8 x 8 bits can be stored here simultaneously and "called up" by the screen RAM to be displayed on the CRT in any of the 1024 character cell positions. A single byte code, stored in the screen calls up a character. The RAM, character may change or move by replacing the single byte code in the screen RAM, or by altering the data in the character generator RAM which forms the image.



• *

PAGE 4, GAME LOGIC PCB

1. The 6502 Microprocessor (2A)

For detailed information concerning this microprocessor, refer to the MOSTEK publication, 6500-10A, MCS Microcomputer Family Hardware Manual.

One feature that should be mentioned here, however, is that this microprocessor has "memory-mapped I/0". This means that all ports interfacing to peripherals of any type must be located within the normal memory map, with no duplication of addresses, since no instructions are specifically oriented toward I/0 operations.

2. <u>Power-on Reset circuit (connected to</u> 2A pin 40)

When power is first applied to a game, a particular sequence of events must occur to set up all logic conditions. If this sequence is broken for whatever reason, the microprocessor may become confused, and the game will not start and run.

This sequence is accomplished when the reset line to the microprocessor is the last line allowed to reach a "high" logic level. The Power-on reset circuit makes sure this occurs by utilizing the charge time of an RC network as a delay.

If any kind of power interruption occurs during normal game play, the power-on reset circuit insures that the microprocessor is reset. This alleviates confusing the microprocessor, while it also recreates the original power-on sequence.

3. Processor Workspace RAM (4A, 5A)

The RAM, or workspace, consists of the lowest 1024 bytes of memory and can be divided into three separate sections due to distinctly different functions.

The lowest 256 bytes (Ø to FF Hexadecimal) is reserved for special software register operations, and is called "zero page". The processor uses this area to store dynamic variables. For details of this type of operation, refer to 6502 technical literature regarding "Zero Page Addressing".

The next higher 256 bytes (100 to 1FF Hex) is reserved for the 6502 stack. The processor stores return addresses in the stack when interrupted or called to execute a subroutine. The game program may also request the processor to store other kinds of information here for later retrieval.

The next higher 512 bytes (200 to 3FF Hex) are used as a scratchpad area. Miscellaneous calculations and their results are temporarily stored here. If an error in this RAM occurs, the screen will not retain the condition that existed prior to losing the last turn, or between players.

1

4. Main Address Decoding (5C, 5D, 5E)

This circuit is the first stage of the address line decoding necessary to organize the memory map; that is, it places specific functions or devices within generalized blocks of the memory map, grouped by function.

PAGE 5, GAME LOGIC PCB

1. Program Memory (6A through 13A)

These memory devices are 2732 EPROMS. Note that four of the lines to each memory device (PCSO through PCS7, PAP19, PAP20, PAP21) are programmable through jumper configurations located at 4B and 11B. This allows different memory devices to be used and/or facilitates interconnection to the memory expansion PCB (if used).

2. PROM Address Selection (4B, 5B)

This is a second stage of address decoding, used to select each individual memory device when addressed. Signal ROMSEL (from page 4 Main Address Decoding) selects the Program Memory devices in general, and jumper 4B, together with decoder 5B further defines an address to a particular memory device.

3. <u>Memory</u> <u>Device</u> <u>"Personality"</u> <u>Selec</u>tion (11B)

The dip shunt, or jumpers block, alters control signal configuration to the program memory devices. This allows the use of alternate size EPROMS and/or those created by different manufacturers whose control signal pinouts may not be identical to one another.

PAGE 6, GAME LOGIC PCB

1. Moving Object Horizontal Position Counters (13F, 15F, 14F, 16F)

Counters 13F and 15F form a byte-wide counter which horizontally positions Moving Object 1 on the screen. These counters are preloaded to a certain value by the microprocessor during Vertical Retrace time. Then, after each occurrence of the Horizontal Sync, they begin to count. The count outputs AND'ed through 15E give rise to signal M1HW, the Horizontal Position Window for Moving Object 1. Counters 14F and 16F are the equivalent circuit for Moving Object 2.

2. <u>Moving Object</u> <u>Vertical</u> <u>Position</u> <u>Counters</u> (16E, 12E, 1E, 13E)

Counters 16E and 12E form a byte-wide counter which positions Moving Object 1 vertically on the screen. These counters are preloaded to a certain value by the microprocessor during Vertical Retrace time. Then, after each occurrence of Vertical sync, they begin counting. The four count outputs of the least significant of these two counters (MLL1, ML2, ML3, ML4) are sent to the moving object image PROM to specify which line of the image is presently being displayed. The AND'ed outputs of the second counter give rise to signal MLVW, the Vertical Position Window for Moving Object 1. Counters llE and l3E are the equivalent circuit for Moving Object 2.

3. <u>"Write Moving Object" Decoding (6F,</u> 16H, <u>5E</u>, <u>3F</u>)

Consists of two distinctly different functions. 6F and 16H form the circuit that generates the load pulses for the moving object position counters, while 5E and 3F simply prevent the counters from counting during blanking.

4. Color Interface Output (16B)

This is a 14 pin DIP socket used as the connector interface to the color selection circuitry, located on the audio PCB. The signals and their functions are listed below:

Pin

1	5SRLOAD	= Shift Register Load Pulse (Neg. True)
2	CBLB	= Composite Blanking
3	CSYNC	= Composite Sync
4	5CVID	= Composite Video (Neg. True)
5	5SCLK	= Shift Register CLock (Neg. True)
6	HSYNC	= Horizontal Sync
7	GND	-
8	VSYNC	= Vertical Sync
9	5MO2VID	= Moving Object 2 Video (Neg. True)
1Ø	5MO1VID	= Moving Object 1 Video (Neg. True)
11	DBDIR	= Character Generator Address Line 9
12	CSSR	= NOT USED ON FAX^{TM}
13	VD7A1Ø	= Character Generator Address Line 10
14	+5V	

1. Moving Object Multiplexing (14A, 14E)

These two multiplexers pass information to the moving objects image PROM. They contain two codes: one determines which image should appear, and the other specifies which line of that image is to be displayed.

The data passed alternates between data for Moving Object 1 and Moving Object 2, depending on the state of element count E32.

The upper multiplexer (14A) passes the "which image" code, and the lower multiplexer (14E) passes the "which line of that image" code.

2. Moving Objects Image PROM (11D)

This EPROM accepts as an address the image and line codes of moving objects 1 and 2 (see "Moving Object Multiplexing" above). It then presents the appropriate data for one line of the image to the output shift registers.

The timing of the logic insures that the correct pair of shift registers are loaded with the data, then shifted out at the correct time to become, one line at a time, the 16 lines of video for that character (Moving Object 1 or 2).

3.	Moving	Obje	ct V	ideo	Output	Shift
Reg	isters	(12D,	13D,	14D,	15D)	

Shift registers 12D and 13D together form a 16 bit shift register whose task is to accept, as data, 16 bits (2 bytes) representing a single line of the image for Moving Object 1, then shift these 16 parallel bits out serially to become video. This operation is repeated for 16 consecutive lines, resulting in a video image that is 16 bits wide by 16 lines high on the monitor screen. Shift registers 14D and 15D together form this same type of circuit, identical in function, for Moving Object 2.

4. Moving Objects Shift Register Load Logic (2F, 16H)

This circuit sends properly timed load signals to the Moving Object Video Shift Registers. These load signals are needed to load the image data into the shift registers at locations 12D, 13D, 14D, and 15D.

5. <u>Moving Object Shift Register Control</u> Logic (15H, 14H)

The input signals to the upper two gates (15H) represent horizontal and vertical position "windows" for the two moving objects (for example, M1HW = Moving Object 1 Horizontal Window, M2VW = Moving Object 2 Vertical Window). These windows allow the Moving Object shift registers to shift only at the right time. This insures the image is generated at the correct position on the screen.

The lower 2 gates of 15H are, in HARD HATTM, used for later decoding in the color selection circuitry, located on the audio and color plane interface PCB's

6. Memory Device Personality Configuration (10D)

This is another Dip Shunt which reconfigures the PC board in order to use an EPROM (11D) of another type or manufacturer.

PAGE 8, GAME LOGIC PCB

1. Interrupt Status Latch (8E)

This latch is set when a coin is dropped or vertical sync occurs. When the latch is set, the CPU is interrupted; that is, signal IRQ goes low. This forces the CPU to jump to the interrupt service routine. The interrupt service routine instructs the CPU to check for a coin input, and then run a debounce routine on the coin bits of ports 9E or 15A, depending on which coin input bit was set at 8E.

If the CPU finds no coin input bit set at latch 8E, it will assume the Interrupt condition was caused by vertical sync. This tells the CPU that it should now jump to the routine that services the normal game play, and that the screen can now be updated with new data. The screen can only be updated during the vertical retrace interval.

2. Option Switch Port (15A)

This port provides input from the option dipswitch, at location 16A. Data from the dipswitch is gated onto the data buss and read by the CPU at game start. This allows such options as number of turns, coins per game, additional game versus extra turn, etc.

Note that one input of this port (labeled COIN 2) does not come from the switch. Instead, it comes from Coin Input 2, and is used for debouncing the auxiliary coin input switch.

3. Control Inputs Port (9E)

This port can provide up to 8 control imputs. For FAX^{IM} only the coinl input is used. Data from this port is gated on to the data buss for examination by the CPU during the regular service routine (which is synchronized to the vertical interval).

The COIN1 input to this port is used for debouncing the standard coin input.

4. Moving Image Latch

Only the CPU can write to the moving image latch. This latch contains the code that specifies which image or images are presently being displayed by the hardware moving object circuitry.

5. Audio Board Port

This latch is written to and read by the CPU, and transmits instructions to the audio board when any sounds are enabled, disabled, or the game is initialized. In addition, this port passes data sent to select colors for screen images. For the functions of these instructions, see the audio board schematic and/or description of operation.

6. Control Port Latch (9D)

This latch, used only in table versions, is written to only by the CPU and keeps track of which player is "up", in order to select which controls are active, that is, player one or player two.

7. <u>I/O</u> <u>Decoding (7E)</u>

The upper half of this decoder generates the chip selects for those I/O devices written to by the CPU, and the lower half generates the chip selects for those I/O devices which are read by the CPU. See the detailed memory map for more precise information.



,

.

. .

٠

.



.

•

•

.

٠





٠

•

•

MEMORY EXPANSION AND I/O BOARD

The FAXTM Memory Expansion and I/O Board serves two purposes.

The first is to allow the CPU access to large amounts of data required because of the large number of questions that FAX^{TM} contains (3500 - 4000). The board can hold up to 24 8K byte chip's. The total capacity of the board is therefore 192KB. The CPU can access only one Eprom at a time. The contents of the latch at 11C determines which Eprom resides in the CPU's memory map at any given point in time.

The second function is to provide a mechanism to allow the CPU access to control panel information consisting of "A" through "D" buttons for both player 1 and player 2 as well as player 1 start and player 2 start.

This is accomplished via buffers at 4D and 7D plus associated support circuitry.



.



ine.

7

...



•

•

•

-

٠
AUDIO/COLOR PCB-GENERAL DESCRIPTION

The Audio/Color PCB is so named because it contains not only the circuitry required to generate all sounds, but also the main color selection decoding circuitry and video output connector.

This PCB contains a dedicated 6502 microprocessor and circuitry to support the simultaneous generation of many types of sound, including three channel music. The Logic PCB simply sends commands to the Audio/Color PCB via a bidirectional communications port and the Audio/Color PCB takes it from there. In some cases this PCB even aids the Logic PCB in some of it's calculations when there is not enough processing time available on the Logic PCB.

As a result of this structure, the actual program to generate sounds or music resides on the Audio/Color PCB. There is also a handshake required between the two PCB's in order for the system to power up correctly, and of course, there is no video output without the Audio/Color PCB connected.

PAGE 1 OF 5, AUDIO/COLOR PCB

1. Logic and Power Interface (P5, J2, J3)

Connector P5 provides the audio/color PCB with all the power it requires to operate. Also fed through this connector are the two speaker output leads. P5 interfaces only to the power supply module and the speaker, through the main harness.

Connectors J2 and J3 are the most significant path of communication between the Logic and Audio/Color PCB's. Address lines, Bi-directional Data lines, processor control lines, and the Audio/Color PCB Select line are all passed through these two connectors.

2. <u>Communications and Address Decoding</u> (9B, 13D)

*

Peripheral Interface Adapter (PIA) 9B, in concert with 8B (another PIA, shown on page two) serves as a bi-directional communications path between the Logic PCB and the Audio/Color PCB. During information transfer between the two PCB's. both PIA's are in use. Information from the Logic PCB microprocessor passes through the PIA at 9B to the PIA at 8B, then to the microprocessor on the Audio/Color PCB. When information is passed the other direction, the path is the same, but the direction is reversed.

During the time that no information transfer is occurring between the two PCB's, both microprocessors can continue to operate independently.

Also shown on page one is 13D, a 3-line to 8-line decoder, used to generate the write signals for the Color Data Latches. These Latches will be covered in the text for page five of the Audio/Color PCB.

1. 6502 Microprocessor (3B)

This microprocessor is the same as that used on the Logic PCB, but is exclusively dedicated to the generation of sound. It can communicate with the Logic PCB microprocessor, and receives it's instructions thereby. Once it has received it's instructions, however, it asserts complete control over all Audio/Color PCB circuitry and ignores the Logic PCB microprocessor until such time as it is informed that another command is ready. Some commands are of a type that must be processed immediately, irregardless of other operations in progress, and some commands can wait until the operations in progress are completed. The program on the Audio/-Color PCB handles all these eventualities appropriately.

2. <u>Peripheral Interface Adapters (8B,</u> 7B)

The PIA at 8B, as mentioned in the text for page one, is used in bi-directional communications between the microprocessors on the Logic PCB and the Audio/Color PCB.

The PIA at 7B is used for two fundamental purposes on this PCB. The first, and most important, is that it contains the RAM that the microprocessor uses for zero page and stack operations. The PIA only contains 128 bytes of RAM, which under normal circumstances would not be sufficient for both zero page and stack. In this case, however, the memory map on this PCB has been altered, so that when the microprocessor thinks it is putting the stack at address ØIFFH it is actually putting it at address ØØ7FH.

The second use of this device is that of a programmable interval timer, used for various purposes unique to the specific sounds being generated on this game. The ability of this device to generate interrupts at time out is utilized here.

3. Address Decoding (4B)

Keyboard Encoder (4B) is used here to generate the chip selects of all devices located in the memory map of the Audio/Color PCB.

4. Music Generator (2B)

Another Programmable Counter/Timer device is used here to generate music (and sometimes other special effects) in up to three channels (or voices) simultaneously. The music is created by a special software operating system, and all but the counter/timer chip is therefore invisible.

5. Master Oscillator (Al,Bl)

This oscillator is the source of all timing on the Audio/Color PCB. If this clock stops running, so does everything else on the Audio/Color PCB. It is, however, completely independent of the clock and other timing signals generated by the Master Oscillator located on the Logic PCB.

6. Program Memory (5A, 6A, 7A)

The memory devices used here are 2716 (2048×8) EPROMS. The DIP shunt located at 8A is used to reconfigure the control and power supply lines, if necessary, for equivalent devices from different manufacturers, whose pinouts may not be the same.

7. Output Filter Latch (1C)

This latch is used simply to switch different output filter capacitors in or out of the circuit to soften or shade the sound, according to program requirements, or to change the volume.

1. <u>Clock Manipulation and Noise Gen</u>eration Circuit (3D,4D,6D,5E)

The timers inside Programmable Timer Module 3D can be incremented or decremented either internally by the Phase Two clock input, or externally from the "C" inputs (C1,C2,C3). Both options are used by the program. When the counters are being controlled by the Phase Two clock, the "C" inputs have no effect, and the noise generation circuit is therefore inoperative. In order to generate sounds that are classified as noise, or contain some kind of noise within them, the counters are programmed to decrement in accordance with the input on the "C" inputs. While in this mode, the combination of 6D (Dual "D" Flip-Flop) and 5E (128 Bit Shift Register), are used to "randomize" the clock inputs to the Programmable Timer Module (3D). The "randomizer" can be clocked with either the Phase Two clock or counter output Q1.

2. <u>Amplitude</u> <u>Modulation</u> <u>Control</u> (2D, 7D, 8D, 9D)

Counter (3D) outputs Q1,Q2, and Q3 are already highly complex sounds, but in order to create much more specialized audio they must be modulated in amplitude. Each channel is separately controllable in amplitude by associated Digital-to-Analog converters comprised of analog multiplexers and a resistive ladder network. Three control bits on each multiplexer select a voltage to output, according to which input pin is addressed (since each input pin is tied to a different point, and therefore voltage, in the resistive ladder). The voltage thus selected is applied to one of the two inputs to each segment of 2D (another triple analog switch). The other input is tied to ground. Note that the control bit to each analog switch segment is one of the previously mentioned count outputs (Q1,Q2,Q3). In this manner, each output can be controlled for frequency and amplitude individually.

Note also that the count output from Ql, unlike Q2 and Q3, first passes through yet another analog switch whose function is to turn off the count output of Ql prior to reaching the Digital-to-Analog conversion stage. This is done because the Ql output is the one used for selective clock frequency generation, and would therefore interfere with other sounds if not disabled at the appropriate time.

3. Output Summation and Special Effects Volume Control (2E)

The three segments of Operational Amplifier 2E are configured as voltage followers (for impedance considerations), and their outputs are summed together at the top of a 10K POT, R31. output volume, therefore is The determined by the voltage applied at each input and the adjustment of the POT. Note that the resistors used to sum these three outputs together are large in value, so that each channel will have minimal effect on the others when conflicting signals arrive simultaneously (except, of course, that their sum will appear at the output).

This summed output is then again summed with all other sounds generated by this PCB at the input to the final Power Amplifier.

PAGE 4 OF 5: AUDIO/COLOR PCB

1. <u>Summing Amplifier and Master Volume</u> Control (3F, R46)

One segment of Operational Amplifier 3F is used here as a point at which all the various sounds generated on this PCB are brought together. Note that the output goes immediately to a 10K POT (R46) which has ground on the other end. The wiper, therefore, varies the final output volume of all sounds together.

2. <u>Integrator and Audio Power Amplifier</u> (3F, 10F)

Another segment of Operational Amplifier 3F is used here as an integrator; that is, it is used to "roll off" the higher frequency sounds in order to prevent the power amplifier from going into unwanted oscillation. The Audio Power Amplifier (10F) is a Dual Audio Amplifier IC configured as a "Bridge Amplifier" and may be either a LM377 or LM378 for Revision A, Audio/Color PCB. Revision letters are located at position 11C. Information regarding this is available in the operators manual for this game, or contact the Exidy Customer Service Department for assistance if you must use an alternate device.

Volume Controls

Master Volume R46, see the fourth page of Audio/Color PCB schematics.

<u>Music Volume</u> R9, see the fourth page of Audio/Color PCB schematics.

<u>Special Effects Volume</u> R3, see the fourth page of Audio/Color PCB schematics.

1. Pattern Character Color Division (10A,9A)

The two segments of Flip-Flop 10A, using the upper two address lines from the character generator circuit, divide the character generator RAM space into four (4) conceptual groups (or quadrants) according to address. This is done in order to assign different colors to different characters.

Using this method, any character stored in a particular quadrant will be the same color as any other character stored in that same quadrant. If the same character is stored in a different quadrant, it will be displayed with a different color. The output of 9A (Twoline to Four-line decoder) applies the separated video lines of these quadrants to priority encoder 10B, whose task is to determine which image is to take visual preference when two or more coincide on the TV screen; that is, which image is to appear to be in the "foreground", and which is to appear to be in the "background".

2. Priority Encoder (10B)

All the video signals generated by the logic PCB are applied to the priority encoder. The signals assigned the higher priority are shown at the top, and the lower priority are shown on the bottom. The output of this device is a 3 Bit code representing the highest priority video line active at that instant. This output code is then sent to the color multiplexers as an address which will select the appropriate color for the imagery generated on that video line. Note that the lowest priority input to the encoder is tied permanently low (active). This insures that when no other video is being generated, there is a background color present, unless of course, the program has selected a background color of black at that time.

3. Color Data Latches (11C, 12C, 13C)

These latches are addressed directly by the Logic PCB microprocessor. Here the microprocessor stores the data that determines which character is what color. This data is then passed to the color selection multiplexers.

4. <u>Color</u> <u>Selection</u> <u>Multiplexers</u> (11B, 12B, 13B)

Each of the three multiplexers controls the video output to a different color gun in the CRT. One turns the red gun on or off, one turns the green gun on or off, and the third does the same for the blue gun. The output combination of the three multiplexers provides for one of eight possible colors to be displayed at any given instant. The color displayed is determined by two things: what type of video is present (e.g. which character), and what color the microprocessor has currently assigned to that type of video. As mentioned above, the color assignations are stored in the color data latches. The priority encoder (10B) issues the code representing the type of video currently displayed. Using these two pieces of information, the multiplexers look at the appropriate bits in the color latches and send the data directly to the TV to turn the color guns on or off.

5. <u>Video</u> and <u>Sync</u> <u>Signal</u> <u>Polarity</u> Selection (11A, 12A)

Before being reclocked one last time, all video outputs are passed through an Exclusive-Or gate (11A), so that one input of each segment can be used to invert the video (make it 180 degrees out of phase with respect to the input to the gate). This feature insures compatibility with TV monitors made by several different manufacturers.

The TV Sync signals are also routed through Exclusive-Or gate segments (12A) for the same purpose.

6. <u>Final Video Output Re-synchroniza-</u> tion (13A)

To insure that all video signals and sync signals are accurately synchronized in time, they are all re-clocked one last time together by a HEX "D"Flip-Flop. It "cleans up" any spurious irregularities or propagation delays that may have crept into any of the video or sync signals.



.

e



٠

Ά.

٠

•



.





*

٠

.

APPENDIX B: ILLUSTRATED PARTS LIST FOR FAXTM

The following is an illustrated parts list to aid you, should you need to order replacement parts for FAXTM. The drawings have all parts labeled by a number within a circle. This number refers to the item number on the Parts List directly across from the drawing. In the case of the Final Assembly list, the second drawing has numbers referring to the Final Assembly list found opposite the first drawing.

Following the Illustrated Parts List is a list of parts for the Logic, Audio and Plane Interface boards, Memory Expansion Board and overall cabinet hardware.

A. FAXTM FINAL ASSEMBLY

Item

Part Number	Description
90-0073-00	Assy, Cabinet
65-0091-00	Speaker Grill
61-0049-00	Face panel Assy
65-0092-00	Retainer Channel
51-2104-25	Screw #8A Sq.Dr.x 1/2
80-0054-00	FAX TM Display Plex
65-0090-00	Plex Bracket
59-0052-00	O-Ring #2 5/32IDx1/16
54-1100-00	Kep Nut #6-32
90-0074-00	TV Bezel Assy
79-0001-00	Monitor, 13in 13K48Ø1
51-3806-20	Screw, #1Ø HiLo Pan Hdx3/4
53-3000-00	Washer #1Ø
80-0058-00	Anti-Glare Filter, 13in.
95-0023-00	Fluoresent Bulb
95-0025-00	Fluoresent Socket Bryant
49-0028-05	Assy Lamp Harness
65-0094-00	Bracket Lamp Holder
50-1102-00	Screw, 6-32x1/4
51-2204-00	Screw, #8AB Pan Hd x 1/2
48-3002-00	Switch Assy Starpoint
48-3003-00	Switch Assy Starpoint
61-0048-00	Front Door Assy
61-0035-00	Rear Door Assy
90-0075-00	Power Supply Assy
51-2008-01	Screw #8 FH Wood x 1.0
90-0076-00	Isolation Transformer Assy
51-2008-01	Screw #8 FH Wood x 1.0
95-0014-00	Coin Door Assy
49-0023-05	Assy FAX TM Coin Door Harness
51-2204-00	Screw, #8AB Pan Hd x 1/2
65-0089-00	Coin Box Door
65-0088-00	Bracket Hasp
50-3306-22	Bolt Carriage 10-24x3/4
54-3300-01	Kep Nut 10-24

A.FAXTM FINAL ASSEMBLY continued

Item	Part Number	Description
	95-0016-00	Cash Box, Plastic
	65-0099-00 95-0015-00 51-2204-00 50-0006-00	Bracket Coin Counter Coin Counter Screw #8AB Pan Hd.xl/2 Screw #4-4Ø Pan Hd.x3/4
	95-0017-00 65-0095-00 51-2006-01 49-0027-05 48-5001-00 65-0096-00 65-0097-00 51-2204-00	Speaker 9x6 Oval Speaker cover Screw #8 FH Wood x3/4 Assy Speaker Harness Interlock Switch Interlock Sw.Brk.x.50 Interlock Sw.Brk.x.75 Screw,#8AB Pan Hd x 1/2
	49-0029-05 51-2204-00	Power Cord Assy Screw #8AB Pan Hd x 1/2
	77-0007-05 77-0008-05 77-0015-05 77-0006-05 51-2204-00	PCB Audio PCB Logic PCB Memory Expansion PCB Plane Interface Screw #8AB Pan Hd x 1/2
	49-0024-05 49-0026-05 49-0025-05 51-2204-00	Assy FAX TM Main Harness Assy FAX TM Control Harness Assy FAX TM A.C. Power Harness Screw #8AB Pan Hd X 1/2

B. FAX POWER SUPPLY ASSEMBLY, 90-0075-00

ŧ

ą

.

Item	Part Number	Description
1	32-0001-00	POWER SUPPLY, 5V @ 6AMPS
2	77-0001-00	PCB REGULATOR
3	30-0001-00	XFMR STEP DOWN
4	31-0001-00	EMI FILTER
5	60-0350 00	POWER SUPPLY MOUNTING BOARD
6	51-3204-00	SCREW, #10 AB PAN HD x1/2
7	51-1204-00	SCREW, PAN HD, #6 X 1/2" LG. TYPE AB
8	55-0001-00	SPACER, #6 x .1/8 NON-METALLIC
9	50-1105-00	SCREW, PAN HD. #6-32 x 5/8" LG.
10	53-1004-00	WASHER, FLAT, #6
11	54-1100-01	NUT, KEP, #6-32
12	13-4085-00	CAP ELECT 4000 MF 50V
13	13-3364-00	CAP ELECT 33 MF 25V
14	13-6844-ØØ	CAP ELECT 6.8 MF 25V
15	21-ØØØ3-ØØ	TRANSISTOR 2N3055
16	21-0004-00	TRANSISTOR 2N6246
17	21-0006-00	REGULATOR 7912
18	20-0003-00	DIODE 6Ø\$1/UT 4Ø1Ø
19	20-0005-00	RECTIFIER, BRIDGE MDA-97Ø-1



C. ISOLATION TRANSFORMER ASSEMBLY, 90-0076-00

Item	Part Number	Description
1	30-0002-00	TRANSFORMER, ISOLATION
2	30-0004-00	FLUORESENT LAMP BALLAST
3	95-0026-00	FLUORESENT STARTER SOCKET
4	95-0024-00	FLUORESENT STARTER (F&S)
5	6ØØ351ØØ	MOUNTING BOARD
6	51-38ø6-2ø	SCREW, #10 Hilo PAN HD x3/4
7	53-3000-00	WASHER #10 FLAT
8	51-0105-20	SCREW, #4A PAN HD x 5/8
9	51-2204-00	SCREW, #8AB PAN HD x 1/2



D. COIN DOOR ASSEMBLY, 95-0014-00

<u>Item</u> <u>I</u>	Part Number	Description	
	95-0014-00 19-0023-00	COIN DOOR COIN HARNESS ASSY	

ŧ

•

E. LOGIC AND AUDIO BOARD ASSEMBLY 90-0005-00

1	77 - ØØØ8-Ø5	PWA LOGIC
2	77 - ØØØ7 - Ø5	PWA AUDIO COLOR
3	55-0002-00	SPACER NON-METALLIC #6-32 X 7/8 LONG
4	50-1102-00	SCREW, PAN HD. PHIL #6-32 x 1/4 LG
5	36000600	CABLE ASSY, RIBBON, 14 PIN
6	59-0056-00	WASHER, FLAT, NYLON #6
7	36-0005-00	PLANE INTERFACE RIBBON CABLE
8	77-0006-05	PLANE INTERFACE PCB ASSEMBLY

F. PRINTED CIRCUIT ASSEMBLY-UNIVERSAL POWER SUPPLY, 77-0009-05

1	77-0009-04	UNIVERSAL POWER SUPPLY BOARD
2	13-4085-00	CAP, ELECT. 4000MF, 50V AXIAL LEAD
3	13-3364-00	CAP, ELECT. DIP 33MF 25V + 20%
4	13-6844-00	CAP, ELECT. DIP 6.8MF 25V + 20%
5	20-0003-00	DIODE 60S1 or UT4010
6	20-0005-00	RECTIFIER, BRIDGE MDA-970-1
7	21-0003-00	TRANSISTOR, 2N3Ø55
8	21-0004-00	TRANSISTOR, 2N6246
9	21-0005-00	REGULATOR 7905
1Ø	21-0006-00	REGULATOR 7912
11	84-0012-00	HEATSINK
12	84-0013-00	HEATSINK
13	40-0002-00	CONNECTOR 12 PIN (WAFER HEADER)
14	50-4027-00	SCREW, PAN HD #4-40 x 3/8 LG (PHIL)
15	53 - 4Ø11 - Ø1	NUT, KEP #4-40
16	37-0001-00	TIE WRAP 5 1/2"

G. LOGIC BOARD, 77-0008-05

Item	Part Number	Description	Location
1	77-0008-04	PCB LOGIC	
2	22-0001-02	I.C. 74LSØØ	3D, 15C, 15H
3	22ØØØ2Ø2	I.C. 74LSØ2	1H, 6H, 8F
4	22-0003-02	I.C. 74LSØ4	1D, 4D, 3F, 1ØF, 11F
5	22-0004-00	I.C. 74Ø7	2C
6	22ØØØ5Ø2	I.C. 74LSØ8	5E
7	22-0006-02	I.C. 74LS11	ЗН
8	220007-02	I.C. 74LS20	2F
9	22-0008-02	I.C. 74LS21	12F, 15E
1Ø		I.C. 74LS27	7F, 2H
11	22-0010-02	I.C. 74LS32	6F
12		I.C. 74LS74	1C
13	22-0012-02	I.C. 74LS112	2E, 6E
14		I.C. 74LS138	5B, 5D
15	22-0014-02	I.C. 74LS139	7E, 16H
16		I.C. 74LS157	14A, 14E
17	22-0016-02	I.C. 74LS161	1E, 2D, 4F, 5F
18		I.C. 74LS166	12B, 12D, 13D, 14D, 15D
19	22-0018-02	I.C. 74LS193	10E, 12E, 13F, 15F, 14FM 16F, 11E 13E
2Ø	22-0019-02	I.C. 74LS241	1A, 3A, 15A, 3B, 6B, 9B, 8C, 7D, 9E, 4H
21	22-0020-02	I.C. 74LS245	3C, 4C, 6C, 13B, 15B
22	22-0021-02	I.C. 74LS374	1F, 14B, 7C, 9D, 8E
23	25-0004-00	MICROPROCESSOR 6502	2A
24	28-0004-00	2114 RAM (1K \times 4)	4A, 5A, 7B, 8B
25	24-0011-00	6301 PROM (256x4) P2L5C-1	5C
26	24-0012-00	6331 PROM (32x8) P2L6D-1	6D
27	24-0013-00	6331 PROM (32x8)	14H
20	og gggi gj	HRL14H-1	
28	20-0001-01	1N4002 DIODE	8E, 9F, 2H
29 20	Ø2-4712-ØØ	RES. 470 OHM 1/4W 5%	1D, 2H
3Ø	Ø2-1222-ØØ	RES. 1.2K 1/4W 5%	20
31	Ø2–1822–ØØ	RES. 1.8K 1/4W 5%	1C, 2C
32	Ø2-2222-ØØ Ø2-2722-ØØ	RES. 2.2K 1/4W 5% RES. 2.7K 1/4W 5%	7E, 2A 1C, 2C
33 34	02-2722-00 09-0007-00	RES. 220 OHM $1/8W$ 5%	9E
		lØ Pin Sip	
35	Ø9 - ØØØ4 - ØØ	RES. 2.2K 1/8W 5% 10 Pin Sip	
36	09-0008-00	RES. 4.7K 1/8W 5% 10 Pin Sip	15A
37	Ø9 - ØØØ9 - ØØ	RES. 6.8K 1/8W 5% 10 Pin Sip	14A
38	23-0045-00	CAPØluf CERAMIC	1D
	10 1001	DISC	- /-
39	10-1034-1	CAPluf CERAMIC DISC	A/R

G. LOGIC BOARD, continued

Item	Part Number	Description	Location
4Ø	10-1044-1	CAP. 6.8uf 25v DIPTANT	lC, 15D, 6E, 13F
41	13-6844-1	CAP. 33uf 25V	1C, 2C
		ELECTROLYTIC	-
42	13-3365-Ø	CAP. 470uf 10V	10н
		ELECTROLYTIC	
43	13–4775 – Ø	DIPSHUNT JUMPER PAKS	4B, 11B, 1ØD
		16 PIN	
44	47-0001-00	DIP SWITCH 8 POS.	16A
45	49-5002-00	CRYSTAL 11.289mhz	1D
		(SERIES)	
46			16C, 16F
47	40-0061-00		
		LOW PROFILE	14H, 1ØD
48	44-1601-00	DIP SOCKETS 24 PIN	6A thru 13A, 11D
		LOW PROFILE	
49	44-2401-00	DIP SOCKETS 40 PIN	2A
		LOW PROFILE	
5Ø	44-4001-00	DIP SOCKETS 14 PIN	16B
		LOW PROFILE	
51	44-1401-00	DIP SOCKETS 18 PIN	
		LOW PROFLE	12C, 13C, 14C
52		CAP luf DIPTANT	C45 thru C52, 5D, 2H
53		RES. 220 OHM 1/4W 5%	R2ØØ, R311
54	Ø2-2212-ØØ	RES. 18 OHM 1/4W 5%	R300 thru R302
55	Ø2–18Ø2–ØØ	CAP. 330 pf CER. DISC	
56		E PROM, 2732 FXL	6A
57		E PROM, 2732 FXL	
58		E PROM, 2732 FXL	8A.
59	- ~	E PROM, 2732 FXL	9A
6Ø	10-2214-4	CAP 220 pf CERAMIC DIS	
61		E PROM, 2732 FXL	1ØA
62		E PROM, 2732 FXL	114
63		E PROM, 2732 FXL	12A
64		E PROM, 2732 FXL-6	
65		E PROM, 2716 FXL	11D

H. AUDIO/COLOR BOARD ASSEMBLY 77-00007-05

1	77-0007-04	PRINTED CIRCUIT BOARD	
2	22-0013-02	I.C. 74LS138	13D
3	26-0003-00	I.C. 652Ø	8B, 9B
4	25-0002-00	I.C. 6532	7B
5	25-0004-00	I.C. 65Ø2	3B
6	27-0001-00	I.C. 684Ø	3D
7	22ØØ22Ø2	I.C. 74LS154	4B
8	27-0002-00	I.C. 8253	2B
9	22-0023-00	I.C. 4Ø69	1A
1Ø	22-0055-00	I.C. 4Ø13B	1B

H. AUDIO/COLOR BOARD ASSEMBLY, continued

Item	Part Number	Description	Location
11	22-0003-02	I.C. 74LSØ4	5D
12	22-0001-02	I.C. 74LSØØ	6B
13	22-0021-02	I.C. 74LS374	1C, 11C, 12C, 13C
14	22-0024-00	I.C. 4053	2D, 4D
15	22-0025-00	I.C. 4175	6E, 73, 8E, 9E
16	22-0056-00	I.C. 4562	5E
17	22-0011-02	I.C. 74LS74	10A, 6D
18	22-0026-00	I.C. LM324	3F, 2E
19	22005400	I.C. 7406	1D
2Ø	22002702	I.C. 74LS86	11A, 12A, 4E
21	22-0028-00	I.C. 4051	7D, 8D, 9D
22	22-0014-02	I.C. 74LS139	9A
23	22-0057-00	I.C. LM377	lØE
24	22-0029-02	I.C. 74LS148	1ØB
25	22003002	I.C. 74LS151	11B, 12B, 13B
26	22-0031-02	I.C. 74LS174	13A
27	10-1044-1	.1 uf. CERAMIC CAP 25V LA	thru 7A, 9A, 11A, 13A, 1B, 6B, 9B, 11B, 1C, 11C,
			13C, 1D 3D, 5D, 7D, 9D, 11D, 13D, 1E, 2E, C7,
			C9, C10, 3E, 5E, 7E, 9E, C12, 13E, 2F, 4F, 12F,
28	10-2204-1	22pf CERAMIC CAP 16V	9E, 2E, 3F Cl
28 29	10-2204-1	.Ø1 uf CERAMIC CAP 16V	
29 3Ø	13-3365-1	33uf CAP, 25V,	Cl3, Cl5, Cl7 thru
30	13-3303-1	ELECTROLYTIC W/AXIAL	C21
		LEADS	221
31	13-1075-00	100uf CAP ELECTRO-	C16
		LYTIC 16V	
32	13-4755-00	4.7uf CAP ELECTRO-	C3, C4, C5
		LYTIC 16V	
33	13-1055-00	1.0/uf CAP ELECTRO-	C27, C32, C2
		LYTIC 16V	
34	Ø2–1822–ØØ	1.8K RES. 1/4W 5%	R3, R4, R5
35	Ø2 - 3322 - ØØ	3.3K RES. 1/4W 5%	R6
36	Ø2 - 1Ø22-ØØ	1K RES. 1/4W 5%	R14
37	Ø2-1Ø62-ØØ	10M RES. 1/4W 5%	R2
38	Ø2 - 3Ø12-ØØ	300 OHM RES. 1/4W 5%	Rl
39	Ø2-1Ø42-ØØ	100k res. 1/4w 5%	R10, R11, R12, R27
49	<i>~</i> ~~~ <i>~</i> ~~~ <i>~</i> ~~		R47, 428, R29
40	Ø2-2232-ØØ	22K RES. 1/4W 5%	R15, R3Ø
41	Ø2-1Ø52-ØØ	1M RES. 1/4W 5%	R32 R33, R35
42	Ø2-3332-ØØ	33K RES. 1/4W 5%	R34
43	Ø2-2722-ØØ Ø2-2722-ØØ	2.7K RES. 1/4W 58	R21
44 45	Ø2-2732-ØØ	27K RES. 1/4W 5%	R44 R26
45 46	Ø2-1322-ØØ Ø2-6812-ØØ	1.3K RES. 1/4W 5% 680 OHM RES. 1/4W 5%	R20 R19
40 47	Ø2-3312-ØØ	330 OHM RES. 1/4W 5%	R7, R8, R24
47 48	02-3312-00 02-1612-00	160 OHM RES. 1/4W 58	R7, R5, R24 R25
	ND 1012 00	TOO OTTA TOO T/ TH 30	

é

•

H. AUDIO/COLOR BOARD ASSEMBLY, continued

Item	Part Number	Description	Location
49	Ø2 - 82Ø2-ØØ	82 OHM RES. 1/4W 5%	R2Ø
5ø	Ø2-39Ø2-ØØ	•.	
51	07–1032–00		
		-	
52		10K POT	R9, R31, R46
53	Ø9 - ØØØ8-ØØ	4.7K RES. PAC 10 PIN	4D
		SIP	_
54	29-0002-00	3.579545 MHZ CRYSTAL	2A
55	47-0001-00	16 PIN DIP SHUNT	8A, 11E
56	44-1401-00	14 PIN DIP SOCKET	J2Ø, 1A, 1B, 5E
57	44-2401-00	24 PIN DIP SOCKET	3A, 4A, 5A, 6A, 7A, 2B
58	44-2801-00	28 PIN DIP SOCKET	3D
5 9	44-4001-00	40 PIN DIP SOCKET	3B, 7B, 8B, 9B
6Ø	44-1601-00	16 PIN DIP SOCKET	2D, 4D, 8A, 11E, 6E- 9E, 7D-9D
61	13 - 4735-ØØ	.47 uf CAP ELECTRO-	C14
		LYTIC 16V	
62	40-0005-10	10 PIN MALE CONNECTOR	P21
63	37-0009-00	10 PIN FLAT CABLE	J2, J3
		ASSEMBLY	
64	75-0006-00	HEATSINK STAVER V7-1	ONLY W/ LM277, LM278
65		E PROM 2716, FXA-2	5A
66		E PROM 2716, FXA-2	6A
67		E PROM 2716, FXA-2	7A
68	41000300	FEMALE 10 PIN	

I. PLANE INTERFACE BOARD 77-0006-05

Part Number Description

77000604	PLANE INTERFACE BOARD
10-1044-1	.luf cap., 25 volt
220001-02	I.C. 74LSØØ
22-0017-02	I.C., 74LS166
22002002	I.C. 74LS245
23-0045-00	I.C., 6116
44-1401-00	14 PIN SOCKET
44-2401-00	24 PIN SOCKET

J. MEMORY & I/O EXPANSION BOARD 77-0015-05

77-0015-04 PCB board 22-0001-02 I.C. 741s00 22-0010-02 I.C. 741s32 22-0013-02 I.C. 741s138 22-0014-02 I.C. 741s139 22-0020-02 I.C. 741s139 22-0031-02 I.C. 741s174 22-0037-02 I.C. 741s174 22-0037-02 I.C. 741s125 22-0061-02 I.C. 741s244 09-0003-00 22 Ohm Res.Pac 09-0004-00 2.2 k Sip Pac 10-1044-10 .luf cap 13-4707-00 470uf cap ele.16v 40-0005-10 10 pin molex .156 40-0021-10 10 pin inline .100	Part Number	Description
22-0010-02 I.C. 741s32 22-0013-02 I.C. 741s138 22-0014-02 I.C. 741s139 22-0020-02 I.C. 741s245 22-0031-02 I.C. 741s174 22-0037-02 I.C. 741s125 22-0061-02 I.C. 741s244 09-0003-00 22 Ohm Res.Pac 09-0004-00 2.2 k Sip Pac 10-1044-10 .luf cap 13-4707-00 470uf cap ele.16v 40-0005-10 10 pin molex .156	77-0015-04	PCB board
22-0013-02 I.C. 741s138 22-0014-02 I.C. 741s139 22-0020-02 I.C. 741s245 22-0031-02 I.C. 741s174 22-0037-02 I.C. 741s125 22-0061-02 I.C. 741s244 09-0003-00 22 Ohm Res.Pac 09-0004-00 2.2 k Sip Pac 10-1044-10 .luf cap 13-4707-00 470uf cap ele.16v 40-0005-10 10 pin molex .156	22 - ØØØ1 - Ø2	I.C. 741sØØ
22-Ø014-Ø2 I.C. 741s139 22-Ø02Ø-Ø2 I.C. 741s245 22-Ø031-Ø2 I.C. 741s174 22-Ø037-Ø2 I.C. 741s125 22-Ø061-Ø2 I.C. 741s244 Ø9-Ø003-Ø0 22 Ohm Res.Pac Ø9-Ø004-Ø0 2.2 k Sip Pac IØ-1Ø44-1Ø .luf cap 13-4707-ØØ 47Øuf cap ele.16v 4Ø-Ø005-1Ø IØ pin molex .156	22-0010-02	I.C. 741s32
22-0020-02 I.C. 741s245 22-0031-02 I.C. 741s174 22-0037-02 I.C. 741s125 22-0061-02 I.C. 741s244 09-0003-00 22 Ohm Res.Pac 09-0004-00 2.2 k Sip Pac 10-1044-10 .luf cap 13-4707-00 470uf cap ele.16v 40-0005-10 10 pin molex .156	22-0013-02	I.C. 741sl38
22-ØØ31-Ø2 I.C. 741s174 22-ØØ37-Ø2 I.C. 741s125 22-ØØ61-Ø2 I.C. 741s244 Ø9-ØØØ3-ØØ 22 Ohm Res.Pac Ø9-ØØØ4-ØØ 2.2 k Sip Pac IØ-1Ø44-1Ø .luf cap 13-4707-ØØ 47Øuf cap ele.16v 4Ø-ØØØ5-1Ø IØ pin molex .156	22-0014-02	I.C. 741s139
22-ØØ37-Ø2 I.C. 741s125 22-ØØ61-Ø2 I.C. 741s244 Ø9-ØØØ3-ØØ 22 Ohm Res.Pac Ø9-ØØØ4-ØØ 2.2 k Sip Pac IØ-1Ø44-1Ø .luf cap 13-4707-ØØ 47Øuf cap ele.16v 4Ø-ØØØ5-1Ø 1Ø pin molex .156	22-0020-02	I.C. 741s245
22-0061-02 I.C. 741s244 09-0003-00 22 Ohm Res.Pac 09-0004-00 2.2 k Sip Pac 10-1044-10 .luf cap 13-4707-00 470uf cap ele.16v 40-0005-10 10 pin molex .156	22-0031-02	I.C. 741s174
Ø9-ØØØ3-ØØ 22 Ohm Res.Pac Ø9-ØØØ4-ØØ 2.2 k Sip Pac 1Ø-1Ø44-1Ø .luf cap 13-4707-ØØ 47Øuf cap ele.l6v 4Ø-ØØ05-1Ø 10 pin molex .156	22-0037-02	I.C. 741s125
09-0004-00 2.2 k Sip Pac 10-1044-10 .luf cap 13-4707-00 470uf cap ele.16v 40-0005-10 10 pin molex .156	22-0061-02	I.C. 741s244
10-1044-10 .luf cap 13-4707-00 470uf cap ele.16v 40-0005-10 10 pin molex .156	Ø9-ØØØ3-ØØ	22 Ohm Res.Pac
13-4707-00 470uf cap ele.16v 40-0005-10 10 pin molex .156	Ø9 - ØØØ4-ØØ	2.2 k Sip Pac
40-0005-10 10 pin molex .156	10-1044-10	.luf cap
	13-4707-00	470uf cap ele.16v
40-0021-10 10 pin inline .100	40-0005-10	10 pin molex .156
	40-0021-10	10 pin inline .100
40-0021-12 12 pin inline .100	40-0021-12	12 pin inline .100
41-0005-00 40 pin connector	41-0005-00	40 pin connector
44-1601-00 16 pin socket	44-1601-00	16 pin socket
44-2801-00 28 pin socket	44-2801-00	28 pin socket
23-0076-00 Data E-PROM set FXD-xx Consist of up to 24-2764	23-0076-00	Data E-PROM set FXD-xx Consist of up to 24-2764
EPROMs depending on data version (xx) . Location		
possible are 1C thru 8C, 1B thru 8B, 1A thru 8A.		possible are 1C thru 8C, 1B thru 8B, 1A thru 8A.
24-0014-00 Prom FXD-1 12B	24-0014-00	Prom FXD-1 12B
49-0030-05 Ribbon Cable	49-0030-05	Ribbon Cable

۶

÷

.



•

٠

*

٠

• • •



.



.

٠

.

•

,





.

Ť.



٠

٠

.

•



٠

,

•

.



MODELS 13K4801, 13K4806, 13K4851, 13K4856

13

•

`



390 JAVA DR. SUNNYVALE, CA 94086 408-734-9410 TELEX 357-499