


# Wells-Gardner 19-Inch Color Raster Video Display

Model 19K4914



## Service Manual



**© 1985 by Atari Games Corporation**

**All rights reserved.**

No part of this publication may be reproduced by any mechanical, photographic, or electronic process, or in the form of a phonographic recording, nor may it be stored in a retrieval system, transmitted, or otherwise copied for public or private use, without permission from the publisher.

The game play, all graphic designs, and this technical manual are protected by the U.S. Copyright Act of 1976.

This Act provides for increased penalties for violating federal copyright laws. Courts *can impound* infringing articles while legal action is pending. If infringers are convicted, courts can *order destruction* of the infringing articles.

In addition, the Act provides for payment of statutory damages of up to \$250,000 in certain cases. Infringers may also have to pay costs and attorneys' fees and face an imprisonment of up to five years.

Atari Games Corporation will aggressively enforce its copyrights against any infringers. *We will use all legal means* to immediately halt any manufacture, distribution, or operation of a copy of video games made by us. Anyone who purchases such copies risks forfeiting such a game.

Published by  
Atari Games Corporation  
1272 Borregas Avenue  
P.O. Box 3618  
Sunnyvale, California 94088

Printed in the U.S.A.      **9P**

# **⚠ WARNINGS ⚠**

## **Power-Up Warning**

Before making any servicing or testing, make certain that you use an isolation transformer between the AC supply and the AC plug of the video display. The chassis and the heat sink are *directly connected* to one side of the AC line, which could present a shock hazard.

Before making any servicing, read all the precautions on the CRT and chassis.

## **X-Ray Radiation Warning**

Parts which influence X-ray radiation in the horizontal deflection and high-voltage circuits, the picture tube, etc., are indicated by a star (★) in the parts list. When replacing these components, use **only** the type shown in the parts list.

## **High Voltage**

This video display contains **high voltages** derived from power supplies capable of delivering **lethal** quantities of

energy. Do not attempt to service the video display until you have observed all precautions necessary for working on high-voltage equipment.

## **CRT Handling**

Do not bump or scratch the picture tube because this may cause the picture tube to implode—resulting in injury. Shatter-proof goggles must be worn when handling the CRT. High voltage must be completely discharged before handling. Do not handle the CRT by the neck.

## **Product Safety Notice**

For continued safety, replace safety-critical components **only** with manufacturer-recommended parts. These parts are identified by **⚠** on the schematic diagram.

For replacement purposes, use the same type or specified type of wire and cable; make certain that you follow the positioning of the wires (especially for the high-voltage and power-supply circuits). Shock hazard, fire hazard, or video display damage may result if you use alternative wiring or positioning.

# Table of Contents

## Specifications

Supply .....	1
High Voltage (EHT).....	1

## Control Adjustments

1.0 Black Level Control.....	1
2.0 Vertical Size (Height).....	1
3.0 Vertical Damping.....	2
4.0 Circuit Protection.....	2
5.0 Focus .....	2
6.0 Horizontal Hold Control, VR351 .....	2
7.0 Horizontal Video Position .....	2
8.0 Vertical Raster Position .....	2
9.0 Horizontal Raster Position .....	2
10.0 Horizontal Width .....	2

## Servicing Adjustments

1.0 Degaussing.....	3
2.0 Color Purity .....	3
3.0 Static Convergence .....	4
4.0 Dynamic Convergence.....	5
5.0 White Balance .....	7

## Parts List

Main Board .....	9
Neck Board.....	12
Vertical Position Board.....	12

# List of Illustrations

Figure 1	Input Connectors and Controls .....	2
Figure 2	Convergence and Purity Adjustments.....	3
Figure 3	Neck Board—Component Side (With Horizontally Mounted CRT) .....	4
Figure 4	Video Image for Color Purity Adjustment.....	4
Figure 5	Adjustment of Red and Blue Beams During Static Convergence.....	5
Figure 6	Location of Color Purity and Convergence Controls .....	6
Figure 7	Proper Positioning of Rubber Wedges Under Deflection Yoke .....	6
Figure 8	Adjustment of Red and Blue Beams During Dynamic Convergence .....	7
Figure 9	Adjustment for Parallelism During Dynamic Convergence.....	8
Figure 10	Waveform for Black Level Voltage .....	8
Figure 11	Main PC Board Assembly (Component Side) .....	14
Figure 12	Main PC Board Assembly (Foil or Circuit Side).....	15
Figure 13	Neck Board .....	16
Figure 14	Schematic Diagram.....	19

# List of Tables

Table 1	Video Display Adjustment Controls.....	I
Table 2	Typical DC Voltages With Input Signal .....	13

# Specifications

## Supply

Voltage	108–132 VAC
Frequency	50–60 Hz

### NOTE

Apply supply voltage through an isolation transformer with 1 Amp. minimum capability.

## High Voltage (EHT)

$24.3 \pm 0.8$  kV at 0 mA Beam,  
 $22.8 \pm 0.8$  kV at 0.75 mA Beam

Note: Condition for above is that line voltage equals 120 V

**Table 1 Video Display Adjustment Controls**

### MAIN PC BOARD

Vertical Hold Control, VR301  
 Vertical Size Control, VR303  
 Horizontal Hold Control, VR351  
 Vertical Shift Control, VR901  
 Horizontal Centering Adjustment Jumper (3 positions)  
 Horizontal Shift Control, VR352  
 Screen Control (Part of H.V. Unit), T352  
 Focus Control (Part of H.V. Unit), T352  
 Horizontal Size Coil, L352  
 Black Level Control, VR201  
 Vertical Damping Control, VR302

### NECK PC BOARD

Video Drive Controls: Red (VR401), Green (VR402)  
 CRT Cut-off Controls: Red (VR403), Green (VR404), Blue (VR405)

# Control Adjustments

### NOTE

Horizontal vs. Vertical: Some models have the picture tube mounted vertically rather than horizontally. That is, the picture tube is mounted in the frame such that the long dimension of the tube is up and down. Other than the physical orientation of the picture tube, there is no electrical difference between these models and their horizontal counterparts. The vertical circuits produce and control deflection along the short dimension of the tube in all models.

The horizontal circuits produce and control deflection along the long dimension of the tube in all models. Therefore, wherever "vertical" appears in this manual or on the video display, the word refers to the *short* dimension of the picture tube; wherever "horizontal" appears, that word refers to the *long* dimension of the picture tube.

## 1.0 Black Level Control

This control has been set at the factory to 140 VDC (see Figure 10) and should not need further attention. However, when a game is connected to the video display, you may have to slightly adjust the screen control to obtain the proper black level (the black portion of the picture just extinguished).

## 2.0 Vertical Size (Height)

The location of this control is shown in Figure 1. If necessary, adjust this control slowly until the picture or test pattern has the correct vertical proportions.

### NOTE

This adjustment interacts with the vertical damping adjustment described in the section below. You may have to readjust the vertical size after adjusting the vertical damping control.

### 3.0 Vertical Damping

You will have to adjust this control only if the video display is being used with a game in which the top several raster lines are visible on the screen. Adjust the vertical damping control for uniform spacing of the top raster lines.

### 4.0 Circuit Protection

A 4.0 Amp pigtail fuse is mounted on the Main Board. This fuse protects the power output circuit.

### 5.0 Focus

Adjust the focus control, located on the high-voltage unit (T352), for maximum overall definition and fine picture detail.

### 6.0 Horizontal Hold Control, VR351

You should allow a warm-up period of at least five minutes before aligning the video display. With the display being driven from the game signal, short TP601 to TP31. Adjust VR351 (see Figure 1) until the picture stops sliding horizontally. Remove the short.

### 7.0 Horizontal Video Position

If the video is off center on the raster, you can compensate somewhat by adjusting this control.

### 8.0 Vertical Raster Position

If the video is off center vertically, you can compensate somewhat by turning the vertical raster position control.

### 9.0 Horizontal Raster Position

If the video is off center horizontally, you can compensate somewhat by moving the horizontal raster position adjustment jumper to either position "R" or "L."

### 10.0 Horizontal Width

The horizontal width coil is adjusted with a hexagonal tuning tool. Adjust this control slowly, if necessary, until the picture or test pattern has the correct horizontal proportions.




Figure 1 Input Connectors and Controls

# Servicing Adjustments

## NOTE

After replacing any parts in the CRT assembly, you must make all five adjustments described in this section. Before making these adjustments, apply a suitable power source to the video display through an isolation transformer. Then apply a suitable signal source to the Main PCB through P201 and P202.

## 1.0 Degaussing

**Summary:** Demagnetize the shadow mask and all surrounding metal parts with an external degaussing coil.


All video displays are equipped with automatic degaussing coils (L701) that demagnetize the picture tube every time the video display is turned on after being off for a minimum of five minutes. Should any part of the chassis become magnetized, you will have to degauss the affected area with a manual degaussing coil. Move the coil slowly over the screen and over all surrounding metal parts. Then slowly withdraw the coil for a distance of 6 feet before turning off the coil.

## 2.0 Color Purity

**Summary:** Adjust the purity magnets and the yoke position to produce an overall uniform color.


## NOTE

Purity and static convergence adjustments will interact. The video display must have been operating 15 minutes before you start this procedure.



**Figure 2** Convergence and Purity Adjustments

- 2.1 For best results, we recommend that the purity adjustment be made after the video display is placed in its final location. If the display must be moved, make this adjustment with it facing east or west.
- 2.2 Set the converger assembly on the CRT neck with the centerline of the purity adjustment magnet over the gap between grids no. 3 and 4 (see Figures 2 and 6).
- 2.3 Make certain that the magnetic ring pairs are in their correct positions before starting this procedure. This produces a zero-correction condition on the CRT beam and helps you make adjustments.
- 2.4 Make certain that the vertical raster position control is at the center of its rotation.
- 2.5 Remove the R/G/B signal from the video display.
- 2.6 Turn the green cutoff control (VR404) on the Neck Board fully clockwise (see Figure 3).
- 2.7 Turn the red and blue cutoff controls (VR403 and VR405) fully counterclockwise.
- 2.8 Pull the deflection yoke backward so that a green belt appears on the screen (see Figure 4).
- 2.9 Decrease the horizontal width of the raster, if necessary, to see the right and left edges of the raster.



**Figure 3 Neck Board—Component Side  
(With Horizontally Mounted CRT)**


- 2.10 Move the two purity magnets with respect to each other to center the raster horizontally on the screen and the green belt on the raster horizontally.
- 2.11 Gradually push the deflection yoke forward; fix it at the place where the green screen becomes uniform throughout.
- 2.12 Turn the cutoff and drive controls. Confirm that each color is uniform.
- 2.13 If any color is not uniform, readjust it, moving the purity magnets slightly.
- 2.14 Turn all three cutoff controls fully counterclockwise. Slowly turn the red cutoff control up or clockwise until a red raster is just barely visible.
- 2.15 Slowly turn up the green and blue cutoff controls so that their associated colors, mixed with the red, result in a white or grey raster.
- 2.16 Make certain that the white or grey color is uniform throughout the screen.
- 2.17 Insert a wedge temporarily as shown in Figure 4; adjust the angle of the deflection yoke.

### 3.0 Static Convergence


Summary: Converge red and blue on green in the center of the screen.

- 3.1 Connect a crosshatch signal or grid pattern to the video display.

- 3.2 A pair of 4-pole convergence magnets is provided to converge the blue and red beams (see Figure 6). When the pole opens to the left and right  $45^\circ$  symmetrically, the magnetic field is maximized. Red and blue beams move to the left and right (see Figure 5). Vary the angle between the tabs to adjust the convergence of red and blue vertical lines.
- 3.3 Rotate both 4-pole convergence magnet tabs as a pair to adjust the convergence of the red and blue horizontal lines.
- 3.4 A pair of 6-pole convergence magnets is provided to converge the magenta (red + blue) to the green beams (see Figure 6). When the pole opens to the left and right  $30^\circ$  symmetrically, the magnetic field is maximized. Red and blue beams both move to the left and right (see Figure 5). Vary the opening angle to adjust the convergence of magenta to green vertical lines.
- 3.5 Rotate both 6-pole convergence magnet tabs as a pair to adjust the convergence of magenta to green horizontal lines.



**Figure 4 Video Image for Color Purity Adjustment**



**Figure 5 Adjustment of Red and Blue Beams During Static Convergence**


## 4.0 Dynamic Convergence

Summary: Converge red and blue at the edges of the screen.


- 4.1 Feed a crosshatch signal or grid pattern to the video display.
- 4.2 Temporarily insert a rubber wedge as shown in Figure 7.
- 4.3 Tilt the angle of the yoke up and down to adjust the crossover of both vertical and horizontal red and blue lines. See Figure 8 (a) and (b).
- 4.4 Tilt the angle of the yoke sideways to adjust the parallel convergence of both horizontal and vertical

lines at the edges of the screen. See Figure 9 (a) and (b).

- 4.5 After you have positioned the yoke, insert three more rubber wedges in the positions shown in Figure 7. Do NOT force the permanent wedges in: insert the wedges until they just make contact with the yoke.
- 4.6 Fix the three permanent rubber wedges with chloroprene rubber adhesive.
- 4.7 After the adhesive has dried enough to hold the wedges in place, carefully remove the temporarily installed wedge.



**Figure 6 Location of Color Purity and Convergence Controls**



**Figure 7 Proper Positioning of Rubber Wedges Under Deflection Yoke**

## 5.0 White Balance

Summary: Set the grey and white brightness tracking.


To adjust the white balance of the video display, you will need an oscilloscope with a DC-coupled mode in the vertical amplifier.

Refer to Figure 1 and 3 while doing the following adjustments in subdued light after degaussing and setting the purity of the CRT.


- 5.1 Ground the R/G/B video inputs.
- 5.2 Set the red and green drive controls, VR401 and VR402, to approximately 80% of fully clockwise rotation.
- 5.3 Set the screen and R/G/B cutoff controls to their minimum (fully counterclockwise) positions.
- 5.4 Connect the test equipment to the collector of a video output transistors (Q401, Q402, and Q403) on the CRT neck PCB at TP47R, TP47G, and TP47B

(see Figure 3). Determine which color has the lowest black-level voltage. This is the lead color gun.


- 5.5 Adjust the black level control (VR201) of the lead color gun to obtain the waveform shown in Figure 10.
- 5.6 Slowly turn the screen control clockwise until the raster is just visible.
- 5.7 Adjust the screen control counterclockwise until the raster is just extinguished.
- 5.8 Connect a 1.5 VDC source to the R/G/B inputs. Then adjust the three cutoff controls for best grey uniformity.
- 5.9 Connect a 3.0 VDC source to the R/G/B inputs. Then adjust the R/G drive controls, if necessary, for best neutral white ( $7500^{\circ}$  K).
- 5.10 Repeat steps 5.8 and 5.9 until you obtain good tracking of white balance.



**Figure 8 Adjustment of Red and Blue Beams During Dynamic Convergence**



**Figure 9 Adjustment for Parallelism During Dynamic Convergence**



**Figure 10 Waveform for Black Level Voltage**

## Parts List

This monitor contains circuits and components included specifically for safety purposes. The two symbols described below are used in the parts list to mark components that you should replace only with exact factory replacement parts. Using substitute parts may create a shock, fire, radiation or other hazard. Only qualified personnel should perform service.

- ★ indicates parts that influence X-ray radiation in the horizontal deflection and high-voltage circuits, the picture tube, etc.
- ▲ indicates safety-critical parts

### Main Board

Refer. No.	Wells-Gardner Part No.	Description	Refer. No.	Wells-Gardner Part No.	Description
<b>Resistors</b>					
R201	203X6500-645	1 kΩ, ± 5%, ¼ W Carbon	R234	340X2820-934	82 Ω, ± 5%, ¼ W Carbon
R202	340X2680-934	68 Ω, ± 5%, ¼ W Carbon	R235	340X2820-934	82 Ω, ± 5%, ¼ W Carbon
R203	203X6500-405	100 Ω, ± 5%, ¼ W Carbon	R236	340X2820-934	82 Ω, ± 5%, ¼ W Carbon
R204	203X6700-327	100 Ω, ± 5%, ½ W Carbon	R237	340X2471-934	470 Ω, ± 5%, ¼ W, Carbon
R205	203X6700-421	270 Ω, ± 5%, ½ W Carbon	R238	340X2471-934	470 Ω, ± 5%, ¼ W, Carbon
R206	203X6500-540	390 Ω, ± 5%, ¼ W Carbon	R239	340X2471-934	470 Ω, ± 5%, ¼ W, Carbon
R207	340X2221-934	220 Ω, ± 5%, ¼ W, Carbon	R240	340X2471-934	470 Ω, ± 5%, ¼ W, Carbon
R208	203X6500-540	390 Ω, ± 5%, ¼ W Carbon	R301	203X6500-508	270 Ω, ± 5%, ¼ W Carbon
R209	340X2221-934	220 Ω, ± 5%, ¼ W, Carbon	R302	203X6500-863	8.2 kΩ, ± 5%, ¼ W Carbon
R210	203X6500-540	390 Ω, ± 5%, ¼ W Carbon	R303	203X6500-863	8.2 kΩ, ± 5%, ¼ W Carbon
R211	340X2221-934	220 Ω, ± 5%, ¼ W, Carbon	R304	203X6500-724	2.2 kΩ, ± 5%, ¼ W Carbon
R214	203X6500-645	1 kΩ, ± 5%, ¼ W Carbon	R305	203X6500-842	6.8 kΩ, ± 5%, ¼ W Carbon
R215	203X6501-126	100 kΩ, ± 5%, ¼ W Carbon	R306	203X6003-201	7.5 kΩ, 2%, ¼ W Carbon
R216	203X6500-645	1 kΩ, ± 5%, ¼ W Carbon	R307	203X6500-825	5.6 kΩ, ± 5%, ¼ W Carbon
R217	203X6500-405	100 Ω, ± 5%, ¼ W Carbon	R309	203X6500-965	22 kΩ, ± 5%, ¼ W Carbon
R218	203X6500-645	1 kΩ, ± 5%, ¼ W Carbon	R310	203X6500-988	39 kΩ, ± 5%, ¼ W Carbon
R219	203X6501-126	100 kΩ, ± 5%, ¼ W Carbon	R311	203X9014-709	3.3 kΩ, ± 5%, 1 W Carbon
R220	203X6500-645	1 kΩ, ± 5%, ¼ W Carbon	R312	203X9014-741	4.7 kΩ, ± 5%, 1 W Metal Oxide
R224	203X6500-169	10 Ω, ± 5%, ¼ W Carbon	R313	204X1527-528	470 Ω, ± 5%, 7 W Carbon
R225	203X6500-169	10 Ω, ± 5%, ¼ W Carbon	R314	203X6500-481	220 Ω, ± 5%, ¼ W Carbon
R226	203X6500-169	10 Ω, ± 5%, ¼ W Carbon	R315	203X6500-169	10 Ω, ± 5%, ¼ W Carbon
R227	203X6501-044	47 kΩ, ± 5%, ¼ W Carbon	R317	203X6700-061	8.2 Ω, ± 5%, ½ W Carbon
R228	340X2152-934	1.5 kΩ, ± 5%, ¼ W Carbon	R318	203X6500-584	560 Ω, ± 5%, ¼ W Carbon
R229	203X6700-421	270 Ω, ± 5%, ½ W Carbon	R319	203X6500-645	1 kΩ, ± 5%, ¼ W Carbon
R230	203X6500-863	8.2 kΩ, ± 5%, ½ W Composite	R320	203X6501-002	33 kΩ, ± 5%, ¼ W Carbon
R231	203X6500-863	8.2 kΩ, ± 5%, ½ W Composite	R321	203X6501-224	270 kΩ, ± 5%, ½ W Carbon
R232	203X6500-863	8.2 kΩ, ± 5%, ½ W Composite	R322	203X6500-886	10 kΩ, ± 5%, ¼ W Carbon
R233	340X2221-934	220 Ω, ± 5%, ¼ W, Carbon	R351	340X2183-934	18 kΩ, ± 5%, ¼ W, Carbon
			R352	203X6500-785	3.9 kΩ, ± 5%, ¼ W Carbon
			R353	340X2473-934	47 kΩ, ± 5%, ¼ W, Carbon

*Continued on next page*

**Main Board Continued**

<b>Refer. No.</b>	<b>Wells-Gardner Part No.</b>	<b>Description</b>	<b>Refer. No.</b>	<b>Wells-Gardner Part No.</b>	<b>Description</b>
R354	340X2332-934	3.3 kΩ, ± 5%, ¼ W, Carbon	R601	▲ ★ 204X1625-058	3.3 Ω, ± 5%, 10 W Wire-Wound
R355	203X9205-143	6.8 kΩ, ± 5%, 3 W Metal Oxide	R701	340X5022-633	2.2 Ω, ± 5%, 2 W, Metal Oxide
R358	340X3683-934	68 kΩ, ± 5%, ½ W Carbon	R702	203X6206-441	2.2 Ω, ± 5%, ½ W Carbon
R360	203X6500-561	470 Ω, ± 5%, ¼ W Carbon	VR201	204X2070-072	2 kΩ-B Semi-Fixed
R361	203X6500-886	10 kΩ, ± 5%, ¼ W Carbon	VR301	204X2070-084	5 kΩ-B Semi-Fixed
R362	203X9014-645	1.8 kΩ, ± 5%, 1 W Metal Oxide	VR302	204X2070-084	5 kΩ-B Semi-Fixed
R363	★ 204X1450-516	3.9 kΩ, ± 5%, 5 W Metal Oxide	VR303	204X2070-055	500 Ω-B Semi-Fixed
R364	203X6500-246	22 Ω, ± 5%, ¼ W Carbon	VR351	204X2070-072	2 kΩ-B Semi-Fixed
R365	340X2183-934	18 kΩ, ± 5%, ¼ W Carbon	VR352	204X2070-072	10 kΩ-B Semi Fixed
R367	203X6500-886	10 kΩ, ± 5%, ¼ W Carbon			<b>Capacitors</b>
R368	203X5602-185	330 kΩ, ± 5%, ½ W Composite	C201	203X0014-088	1000 μF, 16 V, Electrolytic
R369	203X5602-329	680 kΩ, ± 5%, ½ W Composite	C202	202X7200-064	330 pF, 500 V, Ceramic
R370	340X2223-934	22 kΩ, ± 5%, ¼ W, Carbon	C203	202X7200-043	220 pF, 500 V, Ceramic
R371	203X9014-584	1 kΩ, ± 5%, 1 W Metal Oxide	C204	202X7200-043	220 pF, 500 V, Ceramic
R372	203X9104-809	12 kΩ, ± 5%, 2 W Metal Oxide	C205	203X0014-076	470 μF, 16 V, Electrolytic
R375	203X9014-724	3.9 kΩ, ± 5%, 1 W Carbon	C206	203X1810-149	0.1 μF, 125 V, Mylar
R376	203X9104-404	270 Ω, ± 5%, 2 W Metal Oxide	C207	349X2232-109	.022 μF, 100 V, Mylar
R377	203X6500-447	150 Ω, ± 5%, ¼ W Carbon	C301	203X0014-065	330 μF, 50 V, Electrolytic
R378	203X6500-886	10 kΩ, ± 5%, ¼ W Carbon	C302	203X1600-563	.022 μF, 50 V, Mylar
R379	203X6500-886	10 kΩ, ± 5%, ¼ W Carbon	C303	203X0629-037	2.2 μF, 50 V, Electrolytic
R380	203X6500-865	8.2 kΩ, ± 5%, ¼ W Carbon	C304	203X1600-366	.0068 μF, 50 V, Mylar
R381	203X6500-724	2.2 kΩ, ± 5%, 1 W Metal Oxide	C306	203X0412-012	2.2 μF, 16 V, Tantalum
R383	203X9014-387	150 Ω, ± 5%, 1 W Metal Oxide	C307	203X1600-634	0.033 μF, 50 V, Mylar
R384	203X6501-088	68 kΩ, ± 5%, ¼ W Carbon	C308	203X0025-163	2.2 μF, 50 V, Electrolytic
R385	340X2122-934	1.2 kΩ, ± 5%, ¼ W Carbon	C309	203X1207-100	0.068 μF, 100 V, Polypropylene
R389	340X5183-633	18 kΩ, ± 5%, 2 W Metal Oxide	C310	203X0629-061	10 μF, 100 V, Electrolytic
R390	340X4222-633	2.2 kΩ, ± 5%, 1 W Metal Oxide	C311	203X0041-162	4.7 μF, 160 V, Electrolytic
R391	340X4222-633	2.2 kΩ, ± 5%, 1 W, Metal Oxide	C312	203X1201-265	0.33 μF, 200 V, Polypropylene
R394	43X0478-001	680 Ω, ± 5%, 5 W, Wirewound	C313	203X0040-068	100 μF, 160 V, Electrolytic
R502	203X6500-886	10 kΩ, ± 5%, ¼ W Carbon	C314	203X1201-096	0.039 μF, 200 V, Polypropylene
R503	43X0481-001	180 Ω, ± 5%, 25 W, Wirewound	C315	203X0629-023	1 μF, 50 V, Electrolytic
R504	203X9014-267	47 Ω, ± 5%, 1 W Metal Oxide	C351	203X0629-023	1 μF, 50 V, Electrolytic
R505	203X6501-209	220 kΩ, ± 5%, ¼ W Carbon	C352	203X0619-045	47 μF, 25 V, Electrolytic
R506	204X1425-196	15 Ω, ± 5%, 5 W Wire-Wound	C353	203X1190-015	0.0082 μF, 50 V, Polystyrene
R507	203X5602-185	330 kΩ, ± 5%, ½ W Composite	C354	203X0619-045	47 μF, 25 V, Electrolytic
			C355	203X1600-366	0.0068 μF, 50 V, Mylar
			C356	203X1130-287	0.0047 μF, 50 V, Mylar
			C359	202X8065-606	100 pF, 500 V, Ceramic
			C360	202X7050-366	0.0033 μF, 500 V, Ceramic
			C361	202X7050-483	0.01 μF, 500 V, Ceramic
			C362	202X7203-032	0.01 μF, 50 V, Ceramic
			C363	▲ ★ 203X1270-911	8700 pF, 1.5 kV, Polypropylene
			C365	46X0536-046	0.39 μF, 200 V, Polypropylene
			C366	203X0019-026	22 μF, 25 V, Electrolytic
			C367	202X8065-162	6 pF, 500 V, Ceramic

*Continued on next page*

Refer. No.	Wells-Gardner Part No.	Description	Refer. No.	Wells-Gardner Part No.	Description
C368	203X1100-858	0.1 $\mu$ F, 50 V	Q206	200X3181-523	Transistor (NPN), 2SC1815GR
C369	203X1207-087	0.047 $\mu$ F, 100 V, Polypropylene	Q207	200X3181-523	Transistor (NPN), 2SC1815GR
C372	203X1207-125	0.1 $\mu$ F, 100 V, Polypropylene	Q208	200X3181-523	Transistor (NPN), 2SC1815GR
C373	203X0029-021	1 $\mu$ F, 50 V, Electrolytic	Q209	200X3181-523	Transistor (NPN), 2SC1815GR
C380	202X7200-087	470 pF, 500 V, Ceramic	Q210	200X3181-523	Transistor (NPN), 2SC1815GR
C381	80X0099-006	470 pF, 500 V, Ceramic	Q301	200X3181-523	Transistor (NPN), 2SC1815GR
C501	▲★ 203X1810-149	0.1 $\mu$ F, 125 V, Mylar	Q302	200X3207-306	Transistor (NPN), 2SC2073LBGL2
C502	▲★ 202X7050-282	1500 pF, 500 V, Ceramic	Q303	200X3207-306	Transistor (NPN), 2SC2073LBGL2
C503	▲★ 202X7810-214	2200 pF, 125 V, Ceramic	Q351	200X3248-217	Transistor (NPN), 2SC2482BK
C504	▲★ 202X7810-214	2200 pF, 125 V, Ceramic	Q352	86X0178-001	Transistor (NPN), 2SD870
C505	203X0220-075	560 $\mu$ F, 200 V, Electrolytic	ZD202	66X0040-019	Diode, Zener, 3.9 V, $\pm 5\%$ , $\frac{1}{2}$ W
C506	203X0040-034	22 $\mu$ F, 160 V, Electrolytic	ZD301	66X0040-031	Diode, Zener 24 V, $\pm 3\%$ , $\frac{1}{2}$ W
C507	203X0041-057	47 $\mu$ F, 160 V, Electrolytic	IC301	200X2300-033	Integrated Circuit, HA 11423
C701	203X0019-092	1000 $\mu$ F, 25 V, Electrolytic	IC501	▲★ 86X0179-001	Integrated Circuit, STR381
C702	203X0634-061	10 $\mu$ F, 100 V, Electrolytic	L352	★ 9A2838-002	Transformers and Coils Horizontal Size Coil
C703	202X7050-248	1000 pF, 500 V, Ceramic	L353	9A2851-001	Linearity Coil
<b>Semiconductors</b>			L701	611X0005-005	Degaussing Coil
D203	201X2010-159	Diode, IS2076-27	T351	202X1300-080	Horizontal Drive Transformer
D204	201X2010-159	Diode, IS2076-27	T352	▲★ 200X9720-301	HV Unit, M-11
D205	201X2010-159	Diode, IS2076-27	F501	▲★ 204X7120-073	<b>Miscellaneous</b> Fuse, 4 Amp, 125V
D206	201X2010-159	Diode, IS2076-27	J402	206X5008-632	Receptacle, W Wire 3P-M-BG
D207	201X2010-159	Diode, IS2076-27	P201	204X9600-466	Plug, PWB 3P-J
D208	201X2010-159	Diode, IS2076-27	P202	204X9601-477	Plug, PWB 6P-Q
D209	201X2010-159	Diode, IS2076-27	P401	204X9600-298	Plug, PWB 4P-B
D302	201X2010-159	Diode, IS2076-27	P501	204X9600-249	Plug, PWB 2P-B
D303	201X2010-159	Diode, IS2076-27	P601	204X9600-304	Plug, PWB 4P-C
D304	201X2120-009	Diode, RH-1V	TH501	201X0100-112	Thermistor
D305	201X2120-009	Diode, RH-1V	<b>Final Assembly Parts</b>		
D306	201X2010-159	Diode, IS2076-27	▲★ 88X0138-506	Cathode-Ray Tube, RCA Type 19VLT22	
D307	201X2010-165	Diode, ISS81	▲★ 202X1111-258	Deflection Yoke	
D310	66X0084-001	Diode, GFE 10R	or 202X1111-264		
D311	66X0083-001	Diode, RGP 10G	291X5004-262	Automatic Degaussing Coil Unit	
D501	▲★ 201X3120-216	Diode, RM-1AV	205X9800-158	Purity/Convergence Assembly	
D502	▲★ 201X3120-216	Diode, RM-1AV			
D503	▲★ 201X3120-216	Diode, RM-1AV			
D504	▲★ 201X3120-216	Diode, RM-1AV			
D505	201X3120-216	Diode, RM-1AV			
D506	201X3120-216	Diode, RM-1AV			
D701	201X2130-234	Diode, RU-2V			
D702	201X2120-009	Diode, RH-1V			
Q201	200X3181-523	Transistor (NPN), 2SC1815GR			
Q202	200X3181-523	Transistor (NPN), 2SC1815GR			
Q203	200X4056-260	Transistor (PNP), 2SA562-Y-TM			
Q204	200X4056-260	Transistor (PNP), 2SA562-Y-TM			
Q205	200X4056-260	Transistor (PNP), 2SA562-Y-TM			

## Neck Board

<b>Refer. No.</b>	<b>Wells-Gardner Part No.</b>	<b>Description</b>	<b>Refer. No.</b>	<b>Wells-Gardner Part No.</b>	<b>Description</b>			
<b>Resistors</b>								
R401	203X6000-729	220 Ω, ± 5% ¼ W Carbon	R421	203X6500-741	2.7 kΩ, ± 5% ¼ W Carbon			
R402	203X6500-540	390 Ω, ± 5% ¼ W Carbon	VR401	204X2115-014	500 Ω, -B Semi-Fixed			
R403	203X6000-661	820 Ω, ± 5% ¼ W Carbon	VR402	204X2115-014	500 Ω, -B Semi-Fixed			
R404	203X6000-729	220 Ω, ± 5% ¼ W Carbon	VR403	204X2115-006	5 kΩ, -B Semi-Fixed			
R405	203X6500-540	390 Ω, ± 5% ¼ W Carbon	VR404	204X2115-006	5 kΩ, -B Semi-Fixed			
R406	203X6000-661	820 Ω, ± 5% ¼ W Carbon	VR405	204X2115-006	5 kΩ, -B Semi-Fixed			
R407	203X6000-729	47 Ω, ± 5% ¼ W Carbon	<b>Capacitors</b>					
R408	203X6000-998	270 Ω, ± 5% ¼ W Carbon	C401	80X0099-021	820 pF, 500 V, Ceramic			
R409	203X6000-661	820 Ω, ± 5% ¼ W Carbon	C402	202X7050-248	1000 pF, 500 V, Ceramic			
R410	203X9104-824	15 kΩ, ± 5%, 2 W. Metal Oxide	C403	202X7050-248	1000 pF, 500 V, Ceramic			
R411	203X9104-824	15 kΩ, ± 5%, 2 W, Metal Oxide	C404	202X7050-282	1500 pF, 1.5 kV, Ceramic			
R412	203X9104-824	15 kΩ, ± 5%, 2 W, Metal Oxide	C405	202X7050-483	0.01 μF, 500 V, Ceramic			
R413	203X6000-998	2.7 kΩ, ± 5% ½ W Composite	<b>Semiconductors</b>					
R414	203X6000-998	2.7 kΩ, ± 5% ½ W Composite	Q401	200X3206-800	Transistor, (NPN) 2SC2068LB			
R415	203X6000-998	2.7 kΩ, ± 5% ½ W Composite	Q402	200X3206-800	Transistor, (NPN) 2SC2068LB			
R416	203X9105-154	2.2 Ω, ± 5% 2 W Metal Oxide	Q403	200X3206-800	Transistor, (NPN) 2SC2068LB			
R419	203X6500-741	2.7 kΩ, ± 5% ¼ W Carbon	J401	206X5009-296	Miscellaneous Receptacle, W Wire 4P-E			
R420	203X6500-741	2.7 kΩ, ± 5% ¼ W Carbon	P402	204X9600-254	Plug, PWB 3P-A			
			P403	204X9600-981	Plug, 1-Pin			
			P701	204X9601-020	Plug, PWB 4P-E			
				204X9301-255	CRT Socket			


## Vertical Position Board (P344)

<b>Refer. No.</b>	<b>Wells-Gardner Part No.</b>	<b>Description</b>
<b>Resistors</b>		
VR901	40X0645-001	25 kΩ Vert. Position Control
<b>Semiconductors</b>		
Q901	86X0127-001	Transistor, (NPN) TPS98


**Table 2 Typical DC Voltages With Input Signal**

<b>Transistor Number</b>	<b>Collector</b>	<b>Transistor Base</b>	<b>Emitter</b>
Q201	8.1	0.43	0.36
Q202	9.8	8.1	9.3
Q203	0.0	0.35	1.0
Q204	0.0	0.35	1.0
Q205	0.0	0.35	1.0
Q206	9.7	5.5	4.8
Q207	9.7	5.5	4.8
Q208	9.7	5.5	4.8
Q209	15.4	-0.30	0.01
Q210	14.0	0.31	0.17
Q301	15.5	4.7	4.2
Q302	79.0	37.8	37.7
Q303	37.0	0.51	0.0
Q351	41.4	0.41	0.0
Q352	Do not measure	-0.03	0.0
Q401	88.3	8.5	8.4
Q402	88.3	8.5	8.4
Q403	88.3	8.5	8.4
Q901	34.6	17.5	16.9


<b>I. C. 301</b>		<b>I. C. 501</b>	
<b>Pin No.</b>	<b>Voltage</b>	<b>Pin No.</b>	<b>Voltage</b>
1	1.16	1	159
2	4.0	2	123
3	6.8	3	0
4	3.9	4	125
5	12.1		
6	4.1		
7	4.1		
8	1.9		
9	12.2		
10	14.2		
11	3.6		
12	7.9		
13	6.8		
14	12.8		
15	1.52		
16	0.0		
17	0.83		
18	0.0		




**Figure 11 Main PC Board Assembly (Component Side)**



**Figure 12 Main PC Board Assembly (Foil or Circuit Side)**




### **VIEW OF COMPONENT SIDE**



**VIEW OF FOIL SIDE**

**Figure 13 Neck PC Board**

N O T E S






Figure 14 Schematic Diagram

Atari Games Corporation  
1272 Borregas Avenue  
P.O. Box 3618  
Sunnyvale, California 94088  
(408) 747-2700 • Telex GRT 3719986