

•

## FD-235F-3100 3112 3405



I. GENERAL

jumper Tonderessee	: DESCRIPTIONS	: NOTE
	: DRIVE SELECT O TO 3	: Only one on at a time.
FG ML	: Connact electrical ground : Activate MOTOR-ON in 2 sel : OFF-MOTOR ON signal : ON - MOTOR ON + LED ON ( D	ections.
IR	: Turn-on condition of LED : OFF- DRIVE SELECT : ON-DRIVE SELECT * READY	
ACD	: Inhibit the auto-chucking : installation. : OFF-AUTO-CHUCKING OPERATIC : ON-AUTO-CHUCKING IS INHIBI	N EXECUTED
REN	: Execute the auto-recalibra : OFF-AUTO RECALIBRATION IS : ON-AUTO-RECALIBRATION IS E	INHIBITED
HMK, NMK	: Straps to select an output	condition of

		;	the	INDEX				pulses.	
--	--	---	-----	-------	--	--	--	---------	--

Strap			Output condition of INDEX/READ DATA		
HMK	NMK	Name			
-	-	Full mask	Pulse detection * DRIVE SELECT * READY * Seek-complete * (Write operation)		
ON	-	Half mask	Pulse detection * DRIVE SELECT * READY * (Write-operation)		
	ON	No mask	Pulse detection * DRIVE SELECT *MTR ON * (Write-operation)		

DC,RY : Select output signals for terminal #2 ,#4,#34

J	umper	setti	ng	0		
RY34	DC34	DC2	DC4	PIN 2	PIN 4	PIN 34
ON	OFF	OFF	OFF	OPEN	OPEN	READY
OFF	ON	OFF	OFF	OPEN	OPEN	DISK CHANGE
OFF	OFF	ON	OFF	DISK CHANGE	OPEN	OPEN
OFF	CFF	OFF	ON	OPEN	DISK CHANGE	OPEN

## FD235F, HF - 3XXX SERIES

11. FD-235F-3XXX 720KB Model

JUMPER ==========	: DESCRIPTION	: NOTE
НА	: 1MB Mode fixed	: This strap : must be on- : state.
	ہے ہے، انہ انداز کا کا کا کا کا کا پیچ ہو چند کا حاصل ہے ہے، پر داند انداز کا کہ ان	

III. FD-235HF-3XXX 1.44MB & 720KB COMBINATION Density

HA, HI2, HO2, LHI, and LHO : Select density mode by either pin #2 or sensor

	Strap setting Signals						Density		
нох	HI2	HA	LHI	LHO	Pín 2	Pin X	HD	<u>HOST</u> Key-in or	FDD HD IN (HOST)
-	ON		-	-	HD IN	OPEN	HIGH	software	
	ON		-	-	HD IN	OPEN	LOW	Key-in or	Auto by
-	-	ON	-	-	OPEN	OPEN	-	software	sensor
								HD OUT	Auto
ON	-	*ON	-	-	OPEN	HD OUT	HIGH	from FDD	by sensor
ON	-	*ON	ON	ON	OPEN	HD OUT	LOW		
ON	ON	_	-	-	HD IN	HD OUT	HIGH	ID OUT or (Key-in)	LLD IN from
ON	ON	-	ON	ON	HD IN	HD OUT	LOW	(ve)-tu)	soft

NOTES: 1."-" mark indicates the off-state of the strap. 2."X" of HOX and pin X means 2 or 4 corresponing

1

to HO2, or HO4 strap.
3. " \* ON " will activate the HD sensor which is incorporated in the drive. With these selections, the use of disk types is important.

a. When HD diskette with 2 window holes is used, the drive will operate in high density mode. (1.44MB) b. When DSDD diskette is used, it will be in 720K

mode.





DS1: Drive Select 1 DS1 must be shorted.

.

FD-235HF-4201 4217 4240 4291



HA: Inteligent mode Sensing disk type

**DS1: Drive Select 1** 

DS1 and HA must be shorted

#### FD235HF-4XXX

## I. GENERAL

 JUMPER
 : DESCRIPTIONS
 : NOTE

 DO,D1
 : DRIVE SELECT signal 0 and 1
 : Use only one

 :
 :
 :

## II. FD-235HF-4XXX 1.44MB & 720KB COMBINATION

HA,HI,HO,LHI : Select density mode by either Signal interface pin #2 or Hi Density hole sensor.

METHOD					PIN 2 DEF.	HD LEVEL	DENSITY DESIGNATION		
METHOD	HA	HI	но	LHI	DEF.		HOST	FDD	
1A	-	ON	-	_	HD IN	HIGH	KEY-IN OR SOFT-	HD IN	
1B	-	ON	-	ON	HD IN	LOW	WARE	FROM HOST	
2	ON	-		-	OPEN	-	KEY-IN OR SOFT- WARE	AUTOMATIC BY SENSOR	
3	-	-	ON	-	HD OUT	HIGH	HD OUT FDD	AUTOMATIC BY SENSOR	

This specification provides a description for the TEAC FD-235HF, double sided, dual density, 3.5 inch floppy disk drive. This table shows the outline of the floppy disk drive as well as the factory default jumper settings.

Model Name	FD-235HF-52XX & 54XX	······					
Safety standard on label	UL & CSA						
Operation modes	High density mode,	Normal density mode,					
	Write and read	Write and read					
3.5" disk used	High density (2HD)	Normal density (2DD)					
Unformatted data capacity	2M bytes	1M bytes					
Data transfer rate	500k bits/sec	250 bits/sec					
Disk rotational speed	300 грт						
Track density	135tpi						
Track to track time	3msec						
Required power	+5v single (4.5 - 5.5V)						
Front bezel & flap							
Eject button							
LED indicator color	Green						
Signal output driver	Open collector TTL						
Input signal terminator	$1k \pm 5\%$ , unremovable						
Customer selectable strap	2 selections						
Function setting at	1. Strap setting						
Delivery	1.1 DS1: DRIVE SELECT 1	on pin 12					
	2. Other function setting	-					
	2.1 Automatic density setting	g by HD hole					
	2.2 LED turn-on condition: 1	DRIVE SELECT					
	2.3 Motor rotating condition	: MOTOR ON					
	2.4 Ready and seek-complete	e gate (full –mask)					
	For INDEX and READ I	DATA output pulses					
	2.5 Disk Change on pin 34						
	2.6 Auto-chucking, auto-reca	2.6 Auto-chucking, auto-recalibration					
	2.7 FDD frame is electrically shorted on DC 0V.						
Interface connector	34 pin right angle header com	nector and power connector					
Other optional function	Not equipped						

FDD name	Front color	Parts N	OS
		Font bezel Ass'y	Button
FD-235HF-5240	PC/AT	17968300-03	16788039-03
FD-235HF-5291	PS/2	17967696-04	16788039-04
FD-235HF-5429	Black	17967696-00	16788039-00

.

.

#### Jumper settings for models FD235HF-52XX & 54XX

Customer Selectable Straps

Function Summary of Straps

The FDD is equipped with the following selectable straps on the main PCBA. Insertion of a short bar onto the post pin is defined as the on-state of the strap.

Strap	Function
DS0	DRIVE SELECT 0 input on pin 10
DS1	DRIVE SELECT 1 input on pin 12





DSO and DS1 Straps

(1) In the multiplex control, these straps designate the address of the FDD.

(2) By the combination with the DRIVE SELECT 0 and 1 signals, two addresses, can be designated.

## TURN ON CONDITION OF INDICATOR AND SPINDLE MOTOR

## Front Bezel Indicator

The indicator (LED) turns-on while the DRIVE SELECT signal is TRUE. However, the indicator keeps off until 3. Imsec has passed after the DRIVE SELECTION to avoid the polling operation of the DRIVE SELECT signal.

#### Spindle Motor

1

- (1) The spindle motor rotates while the MOTOR ON signal is TRUE. However, the spindle motor does not rotate at any condition while no disk is installed.
- (2) Auto-chucking operation is executed at each disk installation by rotating the spindle motor for 490msec, approx. (500msec, Max.).

This specification provides a description for the TEAC FD-235HF, double sided, dual density, 3.5 inch floppy disk drive. This table shows the outline of the floppy disk drive as well as the factory default jumper settings.

Model Name	FD-235HF-62XX					
Safety standard on label	UL, CSA & IEC950 (CB)					
Operation modes	High density mode,	Normal density mode,				
-	Write and read	Write and read				
3.5" disk used	High density (2HD)	Normal density (2DD)				
Unformatted data capacity	2M bytes	1M bytes				
Data transfer rate	500k bits/sec	250 bits/sec				
Disk rotational speed	300 rpm					
Track density	135tpi					
Track to track time	3msec					
Required power	+5v single (4.5 - 5.5V)					
Front bezel & flap						
Eject button						
LED indicator color	Green					
Signal output driver	Open collector TTL	Open collector TTL				
Input signal terminator	$1k\Omega \pm 5\%$ , unremovable	1kQ+ 5%, unremovable				
Customer selectable strap	2 selections, refer to item 11.	1				
Function setting at	1. Strap setting					
Delivery	1.1 DS1: DRIVE SELECT 1	on pin 12				
	2. Other function setting					
	2.1 Automatic density setting					
	2.2 LED turn-on condition: I					
	2.3 Motor rotating condition					
	2.4 Ready and seek-complete					
	For INDEX and READ I	DATA output pulses				
	2.5 Disk Change on pin 34					
	2.6 Auto-chucking, auto-recalibration					
	2.7 FDD frame is electrically					
Interface connector	34 pin right angle header con	nector and power connector				
Other optional function	Not equipped					

FDD name	Front color	Parts Nos.		
		Font bezel Ass'y	Button	
FD-235HF-6240	PC/AT	17968300-03	16788039-03	
FD-235HF-6291	PS/2	17967696-04	16788039-04	

.

1

This specification provides a description for the TEAC FD-235HF, double sided, dual density, 3.5 inch floppy disk drive. This table shows the outline of the floppy disk drive as well as the factory default jumper settings.

Model Name	FD-235HF-64XX				
Safety standard on label	UL, CSA & IEC950 (CB)				
Operation modes	High density mode, Write and read	Normal density mode, Write and read			
3.5" disk used	High density (2HD)	Normal density (2DD)			
Unformatted data capacity	2M bytes	1M bytes			
Data transfer rate	500k bits/sec	250 bits/sec			
Disk rotational speed	300 rpm				
Track density	135tpi				
Track to track time	3msec				
Required power	+5v single (4.5 - 5.5V)				
Front bezel & flap	Black				
Eject button	Black				
LED indicator color	Green				
Signal output driver	Open collector TTL				
Input signal terminator	1kQ± 5%, unremovable				
Customer selectable strap	2 selections, refer to item 11.1				
Function setting at	1. Strap setting	···			
Delivery	1.1 DS1: DRIVE SELECT 1	on pin 12			
	2. Other function setting	•			
	2.1 Automatic density setting	by HD hole			
		2.2 LED turn-on condition: DRIVE SELECT			
	2.3 Motor rotating condition:	MOTOR ON			
	2.4 Ready and seek-complete	e gate (full –mask)			
	For INDEX and READ D	OATA output pulses			
	2.5 Disk Change on pin 34	-			
	2.6 Auto-chucking, auto-reca				
		2.7 FDD frame is electrically shorted on DC 0V.			
Interface connector	34 pin right angle header connector and power connector				
Other optional function	Not equipped				

•

---

سر بہ دیسے

/

·-· ,

## Jumper settings for models FD235HF-62XX & 64XX

**Customer Selectable Straps** 

Function Summary of Straps

The FDD is equipped with the following selectable straps on the main PCBA. Insertion of a short bar onto the post pin is defined as the on-state of the strap.

Strap	Function
DS0	DRIVE SELECT 0 input on pin 10
DS1	DRIVE SELECT 1 input on pin 12



DS1: Drive Select 1 DS1 must be shorted.

DSO and DS1 Straps

,

(1) In the multiplex control, these straps designate the address of the FDD.

(2) By the combination with the DRIVE SELECT 0 and 1 signals, two addresses, can be designated.

## TURN ON CONDITION OF INDICATOR AND SPINDLE MOTOR

#### Front Bezel Indicator

The indicator (LED) turns-on while the DRIVE SELECT signal is TRUE. However, the indicator keeps off until 3. Imsec has passed after the DRIVE SELECTION to avoid the polling operation of the DRIVE SELECT signal.

#### Spindle Motor

1

- (1) The spindle motor rotates while the MOTOR ON signal is TRUE. However, the spindle motor does not rotate at any condition while no disk is installed.
- (2) Auto-chucking operation is executed at each disk installation by rotating the spindle motor for 490msec, approx. (500msec, Max.).

This specification provides a description for the TEAC FD-235HF, double sided, dual density, 3.5 inch floppy disk drive. This table shows the outline of the floppy disk drive as well as the factory default jumper settings.

Model Name	FD-235HF-6391					
Safety standard on label	UL, CSA & IEC950 (CB)					
Operation modes	2MB mode,	1MB mode,				
•	Write and read	Write and read				
3.5" disk used	High density (2HD)	Normal density (2DD)				
Data transfer rate	500k bits/sec	250 bits/sec				
Disk rotational speed	300 rpm	300rpm				
Track density	135tpi					
Track to track time	3msec					
Required power	+5v  single  (4.5 - 5.5V)					
Front bezel & flap	Beige (PS)					
Eject button	Beige (PS)					
LED indicator color	Green	Green				
Signal output driver	Open collector TTL					
Input signal terminator	1kQ+ 5%, unremovable					
Customer selectable strap	10 selections4					
Function setting at	1. Strap setting					
Delivery	1.1 DS1: DRIVE SELECT					
		1.2 DC34: DISK CHANGE on pin 34				
		1.3 HA: Automatic density setting by HD Hole				
	2. Other function setting					
	2.1 LED turn-on condition:					
	2.2 Motor rotating condition					
		te gate (full-mask) for INDEX and READ				
	Data output pulses.	<b></b> .				
	2.4 Auto-chucking at disk ir	nstallation				
	2.5 Auto-recalibration at po					
Interface connector		34 pin right angle header connector and power connector				
Other optional function	Not equipped					

-

1

#### HA/H12/HO2 Straps

- (1) Straps to select designating method of the density mode and to select a signal pin number.
- (2) Table 21 shows the combination of the straps and selectable functions.

SEL. No.	Strap setting		Input	Output	Dutput Density designation		
	HO2	H12	HA	Pin 2	Pin 2	Host side	FDD
Α	-	ON	-	HD IN	OPEN	Key-in or software	HD in from host
В	-	_	ON	OPEN	OPEN	Key-in or software	Automatic By sensor
С	ON	-	ON	OPEN	HD OUT	HD OUT from FDD	Automatic by sensor

Note: 1. "\_" mark indicates the off-state of the strap.

#### RY34/DC34/DC2 Straps

- (1) RY34 strap is used to output the READY signal on interface pin No. 34
- (2) DC34/DC2 straps are used to output the DISK CHANGE signal on interface pin No. 34, 2.

#### **IR Strap**

IR strap is used to select a turn-on condition of the front bezel indicator (LED).

#### **ACD and REN Straps**

- (1) ACD strap is used to inhibit the auto-chucking at disk installation.
- (a) When the ACD strap is off-state, the auto-chucking operation is executed. The spindle motor Automatically rotates for 490ms, approx. (500ms, Max.), and all of the interface signals are effective during the above auto-checking operation.
- (b) When the ACD strap is on-state, the auto-chucking operation is inhibited.
- (2) REN strap is used to execute the auto-recalibration is inhibited.
- (a) When the REN strap is off-state, the auto-recalibration is inhibited.
- (b) When the REN strap is on-state, the auto-recalibration is executed at power-on.

مسر

#### FG Strap

FG strap is used to electrically connect the FDD frame to DC 0V.

## RY34/DC34/DC2 Straps

,

- (1) RY34 strap is used to output the READY signal on interface pin 34.
   (2) DC34/DC2 straps are used to output the DISK CHANGE signal on interface pin No. 34, 2.

.

## TURN ON CONDITION OF INDICATOR AND SPINDLE MOTOR

## **Front Bezel Indicator**

The indicator (LED) turns-on while the DRIVE SELECT signal is true. However, the indicator keeps off until 3.1msec has passed after the DRIVE Selection to avoid the polling operation of the DRIVE SELECT Signal.

## **Spindle Motor**

... <sup>.</sup>

1

The spindle motor rotates while the MOTOR ON signal is TRUE. However the spindle motor does not rotate at any condition while no disk is installed.

Auto-chucking operation is executed at each disk installation by rotating the spindle motor for 490msec, approx. (500msec, Max.) All the interface signals are valid while the auto-chucking operation is in progress.

## CUSTOMER SELECTABLE STRAPS

## FUNCTION SUMMARY OF STRAPS

The FDD is equipped with the following selectable straps on the main PCBA. Insertion of a short bar onto the post pin is defined as the on-state of the strap.

Strap	FUNCTION
DS0	DRIVE SELECT 0 input on pin 10
DS1	DRIVE SELECT 1 input on pin 12
DS2	DRIVE SELECT 2 input on pin 14
DS3	DRIVE SELECT 3 input on pin 6
*RY34	READY output on pin 34
*DC34	DISK CHANGE output on pin 34
*DC2	DISK CHANGE output on pin 2
*HA	Density set automatically
*HI2	Density set by HD IN on pin 2
*HO2	HD OUT output on pin 2



Notes: 1. \*Straps overlap with other strap posts. Insert a short bar according to your priority.

This specification provides a description for the TEAC FD-235HF, double sided, dual density, 3.5 inch floppy disk drive. This table shows the outline of the floppy disk drive as well as the factory default jumper settings.

Model Name	FD-235HF-65XX					
Safety standard on label	UL, CSA & IEC950 (CB)					
Operation modes	2MB mode,	1MB mode,				
• ,	Write and read	Write and read				
3.5" disk used	High density (2HD)	Normal density (2DD)				
Unformatted data capacity	2M bytes	1M bytes				
Data transfer rate	500k bits/sec	250 bits/sec				
Disk rotational speed	300 rpm	300rpm				
Track density	135tpi					
Track to track time	3msec					
Required power	+5v  single (4.5 - 5.5V)					
Front bezel & flap		<u></u>				
Eject button						
LED indicator color	Green					
Signal output driver	Open collector TTL					
Input signal terminator	1kn± 5%, unremovable					
Customer selectable strap	14 selections					
Function setting at	1. Strap setting					
Delivery	1.1 DS1: DRIVE SELECT					
	1.2 DC34: DISK CHANGE					
	1.3 HA: Automatic density					
	1.4 REN: Auto-recalibration					
	1.5 FG: Frame is electricall	y shorted to DC UV				
	2. Other function setting 2.1 LED turn-on condition:					
	2.2 Motor rotating condition					
		te gate (full-mask) for INDEX and READ				
	DATA output pulses	astallation				
	2.4 Auto-chucking at disk installation					
Interface connector	(ACD strap OFF)	nector				
	Not equipped	34 pin right angle header connector				
Other optional function	I not equipped					

.

.

/

The parts numbers of the front bezel Ass'y and button differ depending on the color of the front panel.

FDD Name	Front color	Par	ts Nos.
		Front bezel Ass'y	Button
FD-235HF-6529	Black	17968300-00	16788039-00
FD-235HF-6540	PC/AT	17968300-03	16788039-03
FD-235HF-6591	PS/2	17967696-04	16788039-04

· · · · · · · · ·

.

/

## CUSTOMER SELECTABLE STRAPS

#### FUNCTION SUMMARY OF STRAPS

The FDD is equipped with the following selectable straps on the main PCBA. Insertion of a short bar onto the post pin is defined as the on-state of the strap.



Notes: 1. \*Straps overlap with other strap posts. Insert a short bar according to your priority. 2. You may select one of the two short bar positons, (A) and (B), for ACD strap.

## DS0/DS1 and DS2/DS3 Straps

- In the multiplex control, these straps designate the address of the FDD
   By the combination with the DRIVE SELECT 0 ~ 4 signals, four addresses, Max. can be designated.

## HA/HI2/HO2 Straps

,

- (1) Straps to select a designating method of the density mode and to select a signal pin number.
- (2) Table 78 shows the combination of the straps and selectable functions.

Sel.	el. Strap Setti		ng	Input	Output	HD	Density de	signation
No.	HO2	HO2 HI2 HA Pin 2 Pin 2 level		level	Host side	FDD		
1	-	ON	-	HD IN	OPEN	HIG	Key-in or	HD IN
						H	software	From host
2	-	-	ON	OPEN	OPEN		Key-in or	Automatic by
							software	sensor
3	ON	4	ON	OPEN	HD	HIG	HD OUT from	Automatic by
					OUT	Н	FDD	sensor

ಂಭವನ್ ಜ್ಯಾಜನ್ನು

Notes: 1. "---" mark indicates the off-state of the strap

#### RY34/DC34/DC2 Straps

- (1) RY34 strap is used to output the READY signal on interface pin No. 34.
- (2) DC34/DC2 straps are used to output the disk change signal on interface pin No. 34, 2.

#### IR Strap

IR strap is used to select a turn-on condition of the front bezel indicator (LED).

## **ACD and REN Straps**

- (1) ACD strap is used to inhibit the auto-chucking at disk installation.
- (a) When the ACD strap is off-state, the auto-chucking operation is executed. The spindle motor automatically rotates for 490msec, approx. accordance during the above auto-chucking operation.
- (b) When the ACD strap is on-state, the auto-chucking operation is inhibited.
- (2) REN strap is used to execute the auto-recalibration (heads move to track 00) at power-on.
  - (a) When the REN strap is off-state, the auto-recalibration is inhibited.
  - (b) When the REN strap is on-state, the auto-recalibration is executed at power-on.

## FG Strap

FG Strap is used to electrically connect the FDD frame to DC 0V.

## TURN ON CONDITION OF INDICATOR AND SPINDLE MOTOR

#### Front Bezel Indicator

Two types of indicator (LED) turn-on condition are offered for selection using the IR strap. However, the indicator keeps off until 3.1ms has passed after the DRIVE Selection to avoid the polling operation of the DRIVE SELECT signal.

Strap	Turn-on condition of LED			
IR				
-	DRIVE SELECT			
ON	DRIVE SELECT * Ready state			

Note: 1. "\_" mark indicates the off-state of the strap and "\*" mark indicates the AND condition.

## Spindle Motor

,

The spindle motor rotates while the MOTOR ON signal is TRUE. However, the spindle motor does not rotate at any condition while no disk is installed.

When the ACD strap is off-state, auto-chucking operation is executed at disk installation.

## Model #: FD235HF-65xx & -75xx . Multi-function versions.

These models are equipped with a PCB board that has multi-function capability through jumper straps. However, the factory default jumper straps are configured so that these models are 100% interchangeable with the standard models. The jumper (strap) matrix is as follows:



On all of the above mentioned models the factory jumper (strap) setting will allow you to configure your drive as either the "A" drive or the "B" drive with out needing to reconfigure the jumper (strap) settings. Simply connect the drive to the correct connector position on you floppy drive interface cable, as shown on the HARDWARE CONNECTION section.

For listing of common system level problems (i.e., DRIVE NOT READY, GENERAL FAILURE ERRORS & other) request DOC # 8500.

This specification provides a description for the TEAC FD-235HF, double sided, dual density, 3.5 inch floppy disk drive. This table shows the outline of the floppy disk drive as well as the factory default jumper settings.

Model Name	FD-235HF-75XX			
Safety standard on label	UL, CSA & TUV			
Operation modes	2MB mode,	1MB mode,		
*	Write and read	Write and read		
3.5" disk used	High density (2HD)	Normal density (2DD)		
Unformatted data capacity	2M bytes	1M bytes		
Data transfer rate	500k bits/sec	250 bits/sec		
Disk rotational speed	300 rpm	300rpm		
Track density	135tpi			
Track to track time	3msec			
Required power	+5v single (4.5 - 5.5V)			
Front bezel & flap	Black			
Eject button	Black	· · · · · · · · · · · · · · · · · · ·		
LED indicator color	Green			
Signal output driver	Open collector TTL			
Input signal terminator	$1k\Omega + 5\%$ , unremovable			
Customer selectable strap	14 selections (DC0~3, RY34, DC34, DC2, HO2, H12, HA, REN			
	ACD, IR, FG)			
Function setting at	1. Strap setting			
Delivery	1.1 DS1: DRIVE SELECT 1 on pin 12			
	1.2 DC34: Disk Change on p			
		etting for 2DD (1MB) disk or 2HD		
	2HD (2.0MB) disk.			
	1.4 REN: Auto-recalibration			
	1.5 FG: Frame is electrically	y shorted to DC 0V.		
	2. Other interface setting			
	2.1 Pin2: Open			
	2.2 Pin4: Open			
	3. Other function setting			
	3.1 LED turn on condition: ]			
	3.2 Motor rotating condition	: MOTOK ON		
	5.5 Keady and seek-complet	te gate (full-mask) for INDEX and READ		
	DATA output pulses.			
Interface connector	3.4 Auto-chucking at disk in	stanation (ACD strap OFF)		
Power connector	34 pin right angle header con	mector and power connector		
Other optional function	Equipped			
	Not equipped			

· ·

.

.....

1

## **CUSTOMER SELECTABLE STRAPS**

## FUNCTION SUMMARY OF STRAPS

The FDD is equipped with the following selectable straps on the main PCBA. Insertion of a short bar onto the post pin is defined as the on-state of the strap.

STRAP	FUNCTION
DS0	DRIVE SELECT 0 input on pin 10
DS1	DRIVE SELECT 1 input on pin 12
DS2	DRIVE SELECT 2 input on pin 14
DS3	DRIVE SELECT 3 input on pin 6
*RY34	READY output on pin 34
*DC34	DISK CHANGE output on pin 34
*DC2	DISK CHANGE output on pin 2
*HA	Density set automatically
*H12	Density set by HD IN on pin 2
*HO2	HD OUT output on pin 2
*IR	LED on: DRIVE SELECT *Ready
*ACD	Disable for auto-chucking
*REN	Enable for auto-recalibration
FG	Short between FDD frame and DC 0V



NOTES: 1. \*Straps overlap with other strap posts. Insert a short bar according to your priority.

2. You may select one of the tow short bar positions, (A) and (B), for ACD strap.

## DS0/DS1 and DS2/DS3 Straps

In the multiplex control, these straps designate the address of the FDD.

By the combination with the DRIVE SELECT 0-4 signals, four addresses, Max. can be designated.

## DS0/DS1 and DS2/DS3 Straps

- (1) In the multiplex control, these straps designate the address of the FDD.
- (2) By the combination with the DRIVE SELECT 0 ~ 4 signals, four addresses, Max can be designated.

#### HA/HI2/HO2 straps

(1) Straps to select a designating method of the density mode and to select a signal pin number

Sel.	Strap Setting		Input Output		HD	Density designation		
No.	HO2	HI2	HA	Pin 2	Pin 2	LEVEL	Host side	FDD
1		ON	-	HD IN	OPEN	HIGH	Key-in or software	HD IN from host
2	-	-	ON	OPEN	OPEN	-	Key-in or software	Automatic by sensor
3	ON		ON	OPEN	HD OUT	HIGH	HD OUT from FDD	Automatic by sensor

. .

2 -

Notes: 1. "---" mark indicates the off-state of the strap.

· · · · ·

- .-

·· · •

## TURN ON CONDITION OF INDICATOR AND SPINDLE MOTOR

#### **Front Bezel Indicator**

Two types of indicator (LED) turn-on condition are offered for selection using the IR strap. However, the indicator keeps off until 3.1msec has passed after the DRIVE SELECTion to avoid the polling operation of the DRIVE SELECT signal.

STRAP	Turn-on condition of LED
<u> </u>	DRIVE SELECT
ON	DRIVE SELECT * Ready state

Notes: 1. "-" mark indicates the off-state of the strap and "\*" mark indicates the AND condition.

#### **Spindle Motor**

- (1) The spindle motor rotates while the MOTOR ON signal is TRUE. However, the spindle motor does not rotate at any condition while no disk is installed.
- (2) When the ACD strap is off-state, auto-chucking operation is executed at disk installation..

This specification provides a description for the TEAC FD-235HF, double sided, dual density, 3.5 inch floppy disk drive. This table shows the outline of the floppy disk drive as well as the factory default jumper settings.

Model Name	FD-235HF-8240/8291/8429			
Safety standard on label	UL, CSA & TUV	UL, CSA & TUV		
Operation modes	2MB mode,	1MB mode,		
	Write and read	Write and read		
3.5" disk used	High density (2HD)	Normal density (2DD)		
Unformatted data capacity	2M bytes	1M bytes		
Data transfer rate	500k bits/sec	250 bits/sec		
Disk rotational speed	300 rpm	300rpm		
Track density	135tpi			
Track to track time	3msec			
Required power	+5v single (4.5 - 5.5V)			
Front bezel & flap	AT-Gray/PS/2 Beige/Black			
Eject button	AT-Gray/PS/2 Beige/Black			
LED indicator color	Green			
Signal output driver	Open collector TTL	Open collector TTL		
Input signal terminator	1ka±30%			
Function setting at	1. Interface setting			
Delivery	1.1 Pin 12: DRIVE SELEC	T 1 input		
	1.2 Pin 34: DISK CHANG	E output		
	2. Other function setting			
	2.1 Automatic density settin (2MB) disk.	ng for 2DD (1MB) disk or 2HD		
	2.2 LED turn on condition:	DRIVE SELECT		
	2.3 Motor rotating condition			
		te gate (full-mask) for INDEX and READ		
	Data output pulses.			
	2.5 Auto-chucking at disk i	nstallation		
	2.6 Auto-recalibration at po	ower on		
	2.7 Frame is electrically she	orted to DC 0V.		
Interface connector		34 pin right angle header connector		
Power connector	Equipped			
Other optional function	Not equipped			

.

. .

· \_

/

## PHYSICAL SPECIFICATION

/

-

Width	101.6mm [4.00 in], Nom.	
Height	25.4mm [1.00 in], Nom.	
Depth	145mm [5.71 in], Nom., excluding front bezel	
Weight	345g [0.76lbs.], Nom., 360g [0.79 lbs.], Max.	
External view	See fig. 1.	
Cooling	Natural air cooling	
Mounting	<ul> <li>Mountings for the following directions are acceptable.</li> <li>(a) Front loading, mounted vertically.</li> <li>(b) Front loading, mounted horizontally with spindle motor down.</li> <li>(c) Mounting angle in items (a) and (b) should be less than 25 with front bezel up or down.</li> <li>Note: As to the other mounting directions than the above will be considered separately.</li> </ul>	
Installation	With installation holes on the frame of the FDD.	
Material of flame	Aluminum die-cast	
Material of front bezel	PPHOX (Complying with UL94-5V)	

\_\_\_\_\_

•



(Fig.1) FDD external view

v

## ENVIRONMENTAL CONDITIONS

1

	Operating	Storage	Transportation
Ambient temperature	4~51.7°C [39~125 F]	-22~60°C [-8~140 F]	-40~65°C [-40~149 F]
Temperature gradient	20°C [36 F] or less per hour	30°C [54 F] or less per hour	30°C [54 F] or less per hour
Relative humidity	20-80% (no condensation) Max. wet bulb temperature shall be 29.4°C [85°F]	5~90% (no condensation) Max. wet bulb temperature shall be 40°C [104°F]	5-95% (no condensation) Max. wet bulb temperature shall be 45°C [113°F]
Vibration	14.7m/s [1.5G] or less (10~100hz, 1 octave/m sweep rate) 9.8m/s [1.0G] or less (100~200Hz, 1 octave/m sweep rate) 4.9m/s [0.5G] or less (200~600Hz, 1 octave/m sweep rate)		19.6m/s [2G] or less (10~100Hz, <sup>1</sup> / <sub>4</sub> octave/m sweep rate)
Shock	Write & read: 49m/S [5G] (11ms, ½ sine wave) or less Read only: 98m/S [10G} (11ms, ½ sine wave)or less		686m/S [70G] (11ms, ½ sine wave) or less
Altitude	-300m [-980feet]~ 5,000m[16,400feet] Notes: The above requirements are applied for the FDD without shipping box. When a long period is required for transportation such as by ship, Storage environmental conditions should be applied.		

.

## RELIABILITY

1

MTTF	· · · · ·	30,000 power on hours or more (for typical operation duty)		
MITR				
MIIIK		When failure, the FDD should be replaced in unit of the drive and not repaired		
		in unit of parts or assemblies.		
	component life	5 Years		
Disk life		3 X 10 passes/track or more		
Disk ins	ertion	1.5 X 10 times or more		
Seek op	eration	1 X 10 random seeks or more		
Preventi	ve maintenance	Not required (for typical operation duty)		
	Soft error	1 or less per 10 bits read		
		A soft (recoverable) error means that it can be recovered		
Error		correctly within three retries.		
rate	Hard error	1 or less per 10 bits read		
		A hard (unrecoverable) error means that it cannot be recovered		
		Correctly within tree retries. However, it is recommended to be		
		Followed by a recalibration to track 00 and four additional retries.		
	Seek error	1 or less per 10 seeks		
	- k	A seek error means that it can seek to a target track within one		
		Retry including a recalibration to track 00.		
Safety standard		Approved by UL, CSA and TUV		
Electro-static dischange		15kV (150pF, 330 )or more		
test		No hard error and/or no component damage occur when the test is applied to the		
		operator access area. (front bezel area).		

•

# Memo

To:TEAC CustomersFrom:Data Storage Products DivisionRe:FD-235-HF-A2XX & FD-235-HF-A4XX

## **Dear Customers:**

Please be informed that the models mentioned above are fixed 1.44M drives. They are factory preconfigured and do not have a block of jumpers for configuration.

# 1. OUTLINE

This specification provides a description for the TEAC FD-235HF, dual density (2/1MB, 2-modes), 3.5-inch micro floppy disk drive (hereinafter referred to as FDD). Table 1-1 shows the outline of the FDD, and Table 1-2 shows the signal interface pin-assignment.

Model name	FD-235HF-A291			
Front bezel	Beige (PS)			
Eject button	Beige (PS)			
LED indicator	Green			
Safety standard	UL, CSA & TÜV	UL, CSA & TÜV		
Operation modes	2MB mode1MB modeWrite and readWrite and read			
3.5 inch disk used	High density (2HD)	Normal density (2DD)		
Unformatted data capacity	2M bytes	1M bytes		
Data transfer rate	500k bits/s	250k bits/s		
Disk rotational speed	300rpm	300rpm		
Track density	5.3track/mm (135tpi)			
Track to track time	3ms			
Required power	+5V single (4.5 ~ 5.5V)			
Signal output driver	Open collector TTL			
Input signal pull-up	1kΩ ±30%			
Function setting at delivery	<ol> <li>Interface setting         <ol> <li>Pin12: DRIVE SELECT 1 input</li> <li>Pin34: DISK CHANGE output</li> </ol> </li> <li>Other function setting         <ol> <li>Automatic density setting for 2DD (1MB) disk or 2HD (2MB) disk.</li> <li>LED turn on condition: DRIVE SELECT</li> <li>Motor rotating condition: MOTOR ON</li> <li>Ready and seek-complete gate (full-mask) for INDEX and READ DATA output pulses.</li> <li>Auto-chucking at disk installation</li> <li>Auto-recalibration at power on</li> <li>Frame is electrically shorted to DC 0V.</li> </ol> </li> </ol>			
Interface connector	34 pin right-angled header connector			
Power connector		Equipped		
Other optional function	Other optional function Not equipped			

# (Table 1-1) Specification outline

# 3. PHYSICAL SPECIFICATION

Width	101.6mm (4.00 in), Nom.	
Height	25.4mm (1.00 in), Nom.	
Depth	145mm (5.71 in), Nom., excluding front bezel	
Weight	345g (0.76lbs), Nom., 360g (0.79 lbs), Max.	
External view	See fig.3-1.	
Cooling	Natural air cooling	
Mounting	<ul> <li>Mountings for the following directions are acceptable.</li> <li>(a) Front loading, mounted vertically.</li> <li>(b) Front loading, mounted horizontally with spindle motor down.</li> <li>(c) Mounting angle in items (a) and (b) should be less than 25° with front bezel up or down.</li> <li>Note: As to the other mounting directions than the above will be considered separately.</li> </ul>	
Installation	With installation holes on the frame of the FDD. Refer to Fig.3-1.	
Material of flame	Aluminium die-cast	
Material of front bezel	PPHOX (Complying with UL94-5V)	

.

------

# (Table 3-1) Physical specification



1



۰.,

## OUTLINE

This specification provides a description for the TEAC FD-235HF, dual density (2/1MB, 2-modes), 90mm (3.5-inch) micro floppy disk drive (hereinafter referred to as FDD). Table 1-1 shows the outline of the FDD, and Table 1-2 shows the signal interface pin-assignment.

Model name	FD-235HF-A529	FD-235HF-A5		
Front bezel	Black Beige (AT)		Beige (PS)	
Eject button	Black	Beige (AT)	Beige (PS)	
LED indicator	Green			
Safety standard	UL, CSA & TÜV			
Operation modes	2MB mode Write and read	1	MB mode rite and read	
90mm (3.5-inch) disk used	High density (2HD)		ormal density DD)	
Unformatted data capacity	2M bytes	11	M bytes	
Data transfer rate	500k bits/s	2:	50k bits/s	
Disk rotational speed	300rpm	30	00rpm	
Track density	5.3track/mm (135t	pi)		
Track to track time	3ms			
Required power	+5V single (4.5 ~ 5	+5V single (4.5 ~ 5.5V)		
Signal output driver	CMOS, 3-state			
Input signal pull-up	$1k\Omega \pm 30\%$ , unremovable			
Customer selectable strap	14 selections (DC0 ~ 3, RY34, DC34, DC2, HO2, HI2, HA, REN ACD, IR, FG) Refer to item 11.1			
Function setting at delivery	<ol> <li>Strap setting         <ol> <li>1.1 DS1 : DRIVE SELECT 1 on pin 12</li> <li>1.2 DC34 : DISK CHANGE on pin 34</li> <li>1.3 HA : Automatic density setting for 2DD (1MB) disk or 2HD (2MB) disk.</li> </ol> </li> <li>1.4 REN : Auto-recalibration at power on.         <ol> <li>5 FG : Frame is electrically shorted to DC 0V.</li> <li>Other interface setting</li> <li>1 Pin2 : Open</li> <li>Other function setting</li> <li>1 LED turn on condition: DRIVE SELECT</li> <li>2 Motor rotating condition: MOTOR ON</li> <li>3 Ready and seek-complete gate (full-mask) for INDEX and READ DATA output pulses.</li> <li>3.4 Auto-chucking at disk installation</li> </ol> </li> </ol>			
Interface connector	34 pin right-angled	34 pin right-angled header connector		
Power connector	Equipped	Equipped		
Other optional function	Not equipped			

## (Table 1-1) Specification outline

## CUSTOMER SELECTABLE STRAPS

#### **Function Summary of Straps**

The FDD is equipped with the following selectable straps on the main PCBA. Insertion of a short bar onto the post pin is defined as the on-state of the strap. Refer to Table 1-1 in item 1. as to the strap setting at delivery and selectable straps.

Strap	Function
DS0	DRIVE SELECT 0 input on pin 10
DS1	DRIVE SELECT 1 input on pin 12
DS2	DRIVE SELECT 2 input on pin 14
DS3	DRIVE SELECT 3 input on pin 6
*RY34	READY output on pin 34
*DC34	DISK CHANGE output on pin 34
*DC2	DISK CHANGE output on pin 2
*HA	Density set automatically
*H12	Density set by HD IN on pin 2
*HO2	HD OUT output on pin 2
*IR	LED on: DRIVE SELECT * Ready
*ACD	Disable for auto-chucking
*REN	Enable for auto-recalibration
FG	Short between FDD frame and DC 0V





Strap post layout

Notes : 1. \*straps overlap with other strap posts. Insert a short bar according to your priority.

2. You may select one of the two short bar positions, (A) and (B), for ACD strap.

## DS0/DS1 and DS2/DS3 Straps

- (1) In the multiplex control, these straps designate the address of the FDD.
- (2) By the combination with the DRIVE SELECT 0 ~ 3 signals, four addresses, Max. can be designated. Refer to Fig. 8.2-1 and Table 11.1-1.

## HA/HI2/HO2 Straps

- (1) Straps to select a designating method of the density mode and to select a signal pin number.
- (2) Table 11.3-1 shows the combination of the straps and selectable functions.
- (3) Refer to Table 11.1-1 as to selection of signal pin number and overlapping with the other strap function.

Sel.	el. Strap setting		Input	Output	Density designation		
No.	HO2	H12	HA	Pin 2	Pin 2	Host side	FDD
Α	-	ON		HD IN	OPEN	Key-in or software	HD IN from host
В	_		ON	OPEN	OPEN	Key-in or software	Automatic by sensor
С	ON		ON	OPEN	HD OUT	HD OUT from FDD	Automatic by sensor

(Table 11.3-1) Designating methods for density mode

Notes : 1. "-" mark indicates the off-state of the strap.

- 2. Refer to Table 11.1-1 as to overlapping with the other strap functions.
- 3. Refer to item 8.3.14 as to the detailed signal functions.

## RY34/DC34/DC2 Straps

- (1) RY34 strap is used to output the READY signal on interface pin No.34.
- (2) DC34/DC2 straps are used to output the DISK CHANGE signal on interface pin No.34, 2.
- (3) Refer to Table 11.1-1 as to selection of signal pin number and overlapping with the other strap functions.

#### **IR Strap**

IR strap is used to select a turn-on condition of the front bezel indicator (LED). Refer to item 12.1 as to the detailed explanation.

#### ACD and REN Straps

- (1) ACD strap is used to inhibit the auto-chucking at disk installation.
  - (a) When the ACD strap is off-state, the auto-chucking operation is executed. The spindle motor automatically rotates for 490ms, approx. (500ms, Max.), and all of the interface signals are effective in accordance with the explanation in item 8.3 during the above auto-chucking operation.
  - (b) When the ACD strap is on-state, the auto-chucking operation is inhibited.
- (2) REN strap is used to execute the auto-recalibration (heads move to track 00) at power-on.
  - (a) When the REN strap is off-state, the auto-recalibration is inhibited.
  - (b) When the REN strap is on-state, the auto-recalibration is executed at power-on.

#### FG Strap

FG strap is used to electrically connect the FDD frame to DC 0V. Refer to item 10. as to the detailed explanation.

## • PHYSICAL SPECIFICATION

Width	101.6mm (4.00 in), Nom.
Height	25.4mm (1.00 in), Nom.
Depth	145mm (5.71 in), Nom., excluding front bezel
Weight	345g (0.76lbs), Nom., 360g (0.79 lbs), Max.
External view	See Fig. 3-1.
Cooling	Natural air cooling
Mounting	<ul> <li>Mountings for the following directions are acceptable.</li> <li>(a) Front loading, mounted vertically.</li> <li>(b) Front loading, mounted horizontally with spindle motor down.</li> <li>(c) Mounting angle in items (a) and (b) should be less than 25° with front bezel up or down.</li> <li>Note: As to the other mounting directions than the above will be considered separately.</li> </ul>
Installation	With installation holes on the frame of the FDD. Refer to Fig. 3-1.
Material of flame	Aluminium die-cast
Material of front bezel	PPHOX (Complying with UL94-5V)

## (Table 3-1) Physical specification



